

USER MANUAL

SERIES R-P I/O

WITH PROTOCOL

PROFINET IO



SENECA S.r.l.
Via Austria 26 – 35127 – Z.I. - PADOVA (PD) - ITALY
Tel. +39.049.8705355 – 8705355 Fax +39 049.8706287
www.seneca.it



ORIGINAL INSTRUCTIONS

Introduction

The content of this documentation refers to products and technologies described in it.

All technical data contained in the document may be changed without notice.

The content of this documentation is subject to periodic review.

To use the product safely and effectively, read the following instructions carefully before use.

The product must be used only for the use for which it was designed and manufactured: any other use is under the full responsibility of the user.

Installation, programming and set-up are allowed only to authorized, physically and intellectually suitable operators.

Set-up must be performed only after correct installation and the user must follow all the operations described in the installation manual carefully.

Seneca is not responsible for failures, breakages and accidents caused by ignorance or failure to apply the stated requirements.

Seneca is not responsible for any unauthorized modifications.

Seneca reserves the right to modify the device, for any commercial or construction requirement, without the obligation to promptly update the reference manuals.

No liability for the contents of this document can be accepted.

Use the concepts, examples and other content at your own risk.

There may be errors and inaccuracies in this document that could damage your system, so proceed with caution, the author(s) will not take responsibility for it.

Technical specifications are subject to change without notice.

CONTACT US

Technical support	supporto@seneca.it
Product information	commerciale@seneca.it

This document is the property of SENECA srl.
Copies and reproduction are prohibited unless authorised.

Document revisions

DATE	REVISION	NOTES	AUTHOR
20/02/2023	0	First revision Supported devices: R-32DIDO-1-P, R-16DI-8DO-P, R-8AI-8DIDO-P	MM
02/03/2023	1	Added chapter "Protection of digital outputs"	MM
16/03/2023	2	Added chapter on FW Update Moved chapter on configuring gsdml file parameters Added information on the procedure to restore the device to factory configuration Added I/O reaction time on R-32DIDO-P Added warning for complete hardware compilation on Tia portal	MM
31/05/2023	4	Default IP changed and Dip Switch chapter added for new firmware Deleted chapter "Restoring the device to factory configuration". Deleted chapter "CONNECTING THE DEVICE TO AN ETHERNET NETWORK" Added R-32DIDO-2-P model	MM
28/11/2023	5	Replaced model R-8AI-8DIDO-P with new hardware version	MM
05/03/2023	6	Added new info on new redesigned model of R-8AI-8DIDO-P	MM
15/03/2024	7	Updated timing for new R-32DIDO-P firmware rev 1016, chapter 2.2 updated. Updated chapter 3.2. Updated chapter 2.4 and 3.1	MM
20/03/2024	8	Added new product R-SG3-P	MM

TABLE OF CONTENTS

1. INTRODUCTION	6
2. R-P SERIES DEVICES	6
2.1. INFORMATION ABOUT THE PROFINET IO PROTOCOL	6
2.2. R-32DIDO-P	6
2.2.1. PROTECTION OF DIGITAL OUTPUTS.....	7
2.2.2. I/O UPDATE TIME	7
2.3. R-16DI-8DO-P	7
2.4. R-8AI-8DIDO-P	7
2.4.1. ANALOG INPUT UPDATE TIME	8
2.4.2. DIGITAL I/O UPDATE TIME	8
2.5. R-SG3-P.....	8
2.5.1. LOAD CELL CONNECTION	9
2.5.2. 4- OR 6-WIRE LOAD CELL CONNECTION	9
2.5.3. CHECKING THE LOAD CELL OPERATION	9
2.5.3.1. CHECKING CABLES WITH A DIGITAL MULTIMETER	9
2.5.4. CONNECTION OF MORE LOAD CELLS IN PARALLEL	10
2.5.5. TRIMMING 4-WIRE LOAD CELLS	11
3. DIP SWITCH	12
3.1. MEANING OF THE DIP SWITCHES FOR THE R-8AI-8DIDO-2-P MODEL	13
3.2. MEANING OF THE DIP SWITCHES FOR THE R-32DIDO-2-P MODEL.....	14
3.3. MEANING OF THE DIP SWITCHES FOR THE R-SG3-P MODEL.....	15
4. WEB SERVER	16
4.1. ACCESS TO THE WEB SERVER.....	16
5. EXAMPLE OF CREATING A PROJECT WITH SIEMENS PLC (TIA PORTAL 16)...	18
5.1. INSTALLING THE GSDML FILE.....	19
5.2. INSERTION OF THE SIEMENS PLC IN THE PROJECT	20
5.3. INSERTION OF THE PROFINET SENECA IO	23
5.4. CONFIGURATION OF THE PARAMETERS OF THE SENECA DEVICE	26
5.5. CONFIGURATION PARAMETERS OF THE GSDML FILE.....	27
5.5.1. R-32DIDO-P	27
5.5.2. R-16DI-8DO-P	27
5.5.3. R-8AI-8DIDO-P	28
5.5.4. R-SG3-P	30
5.6. R-32DIDO-P I/O DATA.....	36
5.7. R-16DI-8DO-P I/O DATA	39
5.8. R-8AI-8DIDO-P I/O DATA	44
5.9. R-SG3-P I/O DATA.....	46
5.10. COMPILED AND SENDING OF THE PROJECT TO THE SIEMENS PLC	49
6. EXAMPLE OF CREATING A PROJECT WITH PLC CODESYS 3.5	52

6.1.1.	INSERTION OF THE CODESYS PLC IN THE PROJECT	52
6.1.2.	INSTALLING THE GSD	56
6.1.3.	INSTALLATION OF THE SENECA PROFINET IO	58
6.1.4.	CONFIGURATION OF THE PARAMETERS OF THE SENECA IO	59
6.1.5.	READING AND WRITING THE SENECA IO FROM CODESYS.....	61
7.	CABLE HARNESS FOR MODELS WITH DOUBLE ETHERNET PORT	63
7.1.	CHAIN ETHERNET CONNECTION (DAISY CHAIN).....	63
7.2.	LAN FAULT-BYPASS FUNCTION	65
8.	SEARCH AND MODIFICATION OF THE DEVICE IP WITH SENECA DISCOVERY TOOL.....	65
9.	FIRMWARE UPDATE.....	67

1. INTRODUCTION



This user manual extends the information from the installation manual to the configuration of the device. Use the installation manual for more information.



In any case, SENECA s.r.l. or its suppliers will not be responsible for the loss of data/revenue or consequential or incidental damages due to negligence or bad/improper management of the device, even if SENECA is well aware of these possible damages.

SENECA, its subsidiaries, affiliates, group companies, suppliers and distributors do not guarantee that the functions fully meet the customer's expectations or that the device, firmware and software should have no errors or operate continuously.

2. R-P SERIES DEVICES

The R series I/O devices support the Profinet IO protocol

2.1. INFORMATION ABOUT THE PROFINET IO PROTOCOL

Type of protocol: Class A Device, Cyclic Real-time (RT) and Acyclic Data

The device has been tested using the following PLCs:

SIEMENS S7 1200 firmware revision 4.3 (Tia Portal 16)
CODESYS Runtime 3.5 (Codesys 3.5)

2.2. R-32DIDO-P

The device allows the use of 32 digital channels that can be individually configured for input or output.

CODE	ETHERNET PORTS
R-32DIDO-2-P	2 10/100 Mbit PORTS (Switch mode)

2.2.1. PROTECTION OF DIGITAL OUTPUTS

The outputs are protected against overload and against overtemperature, they open cyclically until the fault is repaired or the output opens.

The limit current is between 0.6 and 1.2 A.

2.2.2. I/O UPDATE TIME

The update of the 32 digital I/Os is performed every 2ms.

2.3. R-16DI-8DO-P

The devices allow the use of 16 digital input channels and 8 digital output channels (relay).

CODE	ETHERNET PORTS
R-16DI8DO-P	2 10/100 Mbit PORTS (Switch mode)

2.4. R-8AI-8DIDO-P

The devices allow the use of 8 analog input channels and 8 digital channels that can be individually configured for input or output.

CODE	ETHERNET PORTS
R-8AI-8DIDO-2-P	2 10/100 Mbit PORTS (Switch mode)

2.4.1. ANALOG INPUT UPDATE TIME

Sampling time can be configured from 4ms to 400ms per each channel.

By activating 8 channels and setting a sampling time of 4 ms, you get an input update every: $4 \times 8 = 32$ ms.

Note (only if thermocouple channels are enabled):

In the case of a thermocouple input, the Burnout check is carried out every 10 seconds.

The duration of this check takes a sampling on each enabled thermocouple channel.

For example, with 3 active thermocouples, every 10 seconds the following are used:

4ms x 3 channels = 12 ms for Burnout evaluation.



IF ANALOG INPUT 1 IS CONFIGURED IN RTD PT100 MODE, THE MINIMUM SAMPLING TIME FOR THIS CHANNEL TO OBTAIN A CORRECT MEASUREMENT IS 25 ms

2.4.2. DIGITAL I/O UPDATE TIME

The update time of the 8 digital I/Os is 4ms.

2.5. R-SG3-P

The device allows the use of an analogue channel for strain gauge load cells and 2 digital channels that can be individually configured for input or output.

CODE	ETHERNET PORTS
R-SG3-P	1 10/100 Mbit PORT (Switch mode)

The measurement, carried out with the 4 or 6 wire technique.

The device is equipped with a new noise filter specifically developed to obtain a rapid response time.

2.5.1. LOAD CELL CONNECTION

It is possible to connect the converter to the load cell in 4- or 6-wire mode. 6-wire measurement is preferable for measurement accuracy.

The load cell power supply is provided directly by the device.

2.5.2. 4- OR 6-WIRE LOAD CELL CONNECTION

A load cell can have a four-wire or six-wire cable. In addition to having the +/- excitation and +/- signal lines a six-wire cable also has the +/- sense lines. It is a common misconception to think that the only difference between 4- or 6-wire load cells is the possibility of the latter to measure the actual voltage at the load cell. A load cell is compensated to work within specifications in a certain temperature range (usually -10 - +40°C). Since the cable resistance depends on the temperature, the response of the cable to temperature changes must be eliminated. The 4-wire cable is part of the load cell temperature compensation system. The 4-wire load cell is calibrated and compensated with a certain amount of cable connected. For this reason, never cut the cable of a 4-wire load cell. The cable of a 6-wire cell, on the other hand, is not part of the load cell temperature compensation system. The sense lines are connected to the R-SG3 sense terminals, to measure and adjust the actual voltage of the load cell. The advantage of using this "active" system is the possibility of cutting (or extending) the 6-wire load cell cable to any length. It must be considered that a 6-wire load cell will not reach the performance declared in the specifications if the sense lines are not used.

2.5.3. CHECKING THE LOAD CELL OPERATION

Before starting the configuration of the device it is necessary to verify the correctness of the wiring and the integrity of the load cell.

2.5.3.1. CHECKING CABLES WITH A DIGITAL MULTIMETER

First you need to check with the load cell manual that there are about 5V DC between the +Excitation and – Excitation cables. If the cell has 6 wires check that the same voltage is also measured between +Sense and – Sense.

Now leave the cell at rest (without the tare) and check that the voltage between the +Signal and – Signal cables is around 0 V.

Now unbalance the cell by applying a compression force, checking that the voltage between the +Signal and – Signal cables increases until it reaches the full scale (if possible) where the measurement will be approximately:

5* (cell sensitivity) mV.

For example, if the declared cell sensitivity is 2 mV/V, $5 * 2 = 10$ mV must be obtained.

In the case of bipolar measurement only (compression/traction) it is necessary to completely unbalance the cell even in traction, in this case the same value must be measured between the +Signal and -Signal cables but with the negative sign:

-5* (cell sensitivity) mV.

2.5.4. CONNECTION OF MORE LOAD CELLS IN PARALLEL


It is possible to connect up to a maximum of 8 load cells (and in any case without ever falling below the minimum 87 Ohms).

It is therefore possible to connect:


NUMBER OF LOAD CELLS IN PARALLEL	
IMPEDANCE OF THE STATED LOAD CELL [Ohm]	MAXIMUM NUMBER OF CONNECTABLE CELLS IN PARALLEL
350	4
1000	8

For the connection of 4 load cells Seneca recommends using the SG-EQ4 product.

To connect 2 or more 4-wire cells in parallel with the SG-EQ4 junction box, use the following diagram:




To connect 2 or more 6-wire cells in parallel with the SG-EQ4 junction box use the following diagram:



For more details, refer to the SG-EQ4 Junction Box accessory manual.

2.5.5. TRIMMING 4-WIRE LOAD CELLS

The figure below shows a diagram of three trimmed load cells.



A variable resistor, independent of the temperature, or a typically $20\ \Omega$ potentiometer is inserted in the +Excitation cable of each load cell. There are two ways to trim the load cells. The first method is to adjust the potentiometers by trial, shifting the calibration weights from one corner to another.

All the potentiometers must be adjusted so as to set the maximum sensitivity for each cell, turning them all completely clockwise. Then, once the angle with the lowest output is located, act on the trimmers of the other cells until obtaining the same minimum output value. This method can be very long, especially for large scales where the use of test weights on the corners is not very practical. In these cases the second, more suitable method is to "pre-trim" the potentiometers using a precision voltmeter (at least 4 1/2 digits). You can use the following procedure:

- 1) Determine the exact mV/V ratio of each load cell, shown in the calibration certificate of the cell itself.
- 2) Determine the exact excitation voltage provided by the indicator/meter (for example Z-SG), measuring this voltage with the voltmeter (for example 10.05 V).
- 3) Multiply the lowest mV/V value found (point 1) by the excitation voltage (point 2).
- 4) Divide the trimming factor calculated in point 3 by the mV/V value of the other load cells.
- 5) Measure and adjust the excitation voltage of the other three load cells using the respective potentiometer. Check the results and make a final adjustment by moving a test load from corner to corner.

3. DIP SWITCH



ATTENTION!
THE DIP SWITCH SETTINGS ARE READ ONLY AT THE START. AT EACH CHANGE, IT IS NECESSARY TO RESTART.



DEPENDING ON THE MODEL IT MAY BE NECESSARY TO REMOVE THE REAR COVER OF THE DEVICE TO ACCESS THE DIP SWITCHES

3.1. MEANING OF THE DIP SWITCHES FOR THE R-8AI-8DIDO-2-P MODEL

ATTENTION!

FROM THE 1010 FIRMWARE REVISION THE DEVICES ARE SUPPLIED WITHOUT AN IP ADDRESS (0.0.0.0).

MULTIPLE DEVICES CAN THEREFORE BE INSERTED IN THE SAME PROFINET NETWORK AND IDENTIFIED THROUGH THE SCAN OF THE PROFINET NETWORK ITSELF

TO SET AN IP ADDRESS (FOR EXAMPLE TO ACCESS THE WEB SERVER OR TO CONNECT TO THE SENECA DISCOVERY DEVICE TOOL) USE THE PROFINET CONFIGURATION ENVIRONMENT OR FORCE THE ADDRESS 192.168.90.101 WITH THE APPROPRIATE DIP SWITCH

DIP1	DIP2	MEANING
OFF	OFF	Normal operation: The device loads the configuration from the flash.
ON	ON	Resets the device to its factory configuration: (With IP address 0.0.0.0) In this case the STS LED will start flashing to indicate that the device does not have a configured IP address.
OFF	ON	Disables access to the Web server
ON	OFF	Forces the device IP address to the standard value of SENECA Ethernet products: 192.168.90.101

ATTENTION!

TO INCREASE THE SECURITY OF THE DEVICE DISABLE THE WEB SERVER VIA THE DIP SWITCHES

3.2. MEANING OF THE DIP SWITCHES FOR THE R-32DIDO-2-P MODEL

Below is the meaning of the SW1 dip switches:

ATTENTION!

FROM THE 1010 FIRMWARE REVISION THE DEVICES ARE SUPPLIED WITHOUT AN IP ADDRESS (0.0.0.0).

MULTIPLE DEVICES CAN THEREFORE BE INSERTED IN THE SAME PROFINET NETWORK AND IDENTIFIED THROUGH THE SCAN OF THE PROFINET NETWORK ITSELF

TO SET AN IP ADDRESS (FOR EXAMPLE TO ACCESS THE WEB SERVER OR TO CONNECT TO THE SENECA DISCOVERY DEVICE TOOL) USE THE PROFINET CONFIGURATION ENVIRONMENT OR FORCE THE ADDRESS 192.168.90.101 WITH THE APPROPRIATE DIP SWITCH

DIP1	DIP2	MEANING
OFF	OFF	Normal operation: The device loads the configuration from the flash.
ON	ON	Resets the device to its factory configuration: (With IP address 0.0.0.0) In this case the STS LED will start flashing to indicate that the device does not have a configured IP address.
OFF	ON	Disables access to the Web server
ON	OFF	Forces the device IP address to the standard value of SENECA Ethernet products: 192.168.90.101

ATTENTION!

TO INCREASE THE SECURITY OF THE DEVICE DISABLE THE WEB SERVER VIA THE DIP SWITCHES

3.3. MEANING OF THE DIP SWITCHES FOR THE R-SG3-P MODEL

Below is the meaning of the SW1 dip switches:



THE DEVICES ARE SUPPLIED WITHOUT AN IP ADDRESS (0.0.0.0).

MULTIPLE DEVICES CAN THEREFORE BE INSERTED IN THE SAME PROFINET NETWORK
AND IDENTIFIED THROUGH THE SCAN OF THE PROFINET NETWORK ITSELF

TO SET AN IP ADDRESS (FOR EXAMPLE TO ACCESS THE WEB SERVER OR TO CONNECT TO THE
SENECA DISCOVERY DEVICE TOOL) USE THE PROFINET CONFIGURATION ENVIRONMENT OR
FORCE THE ADDRESS 192.168.90.101 WITH THE APPROPRIATE DIP SWITCH

DIP1	DIP2	MEANING
OFF	OFF	Normal operation: The device loads the configuration from the flash.
ON	ON	Resets the device to its factory configuration: (With IP address 0.0.0.0) In this case the STS LED will start flashing to indicate that the device does not have a configured IP address.
OFF	ON	Disables access to the Web server
ON	OFF	Forces the device IP address to the standard value of SENECA Ethernet products: 192.168.90.101



TO INCREASE THE SECURITY OF THE DEVICE DISABLE THE WEB SERVER VIA THE DIP SWITCHES

4. WEB SERVER

ATTENTION!

BEFORE ACCESSING THE WEB SERVER, DISCONNECT THE DEVICE FROM THE PROFINET NETWORK

ATTENTION!

SOME MODELS ARE SUPPLIED WITHOUT AN IP ADDRESS (0.0.0.0) IN THIS CASE THE “STS” LED FLASHES.

TO SET AN IP ADDRESS (FOR EXAMPLE TO ACCESS THE WEB SERVER OR TO CONNECT TO THE SENECA DISCOVERY DEVICE TOOL) USE THE PROFINET CONFIGURATION ENVIRONMENT OR FORCE THE ADDRESS 192.168.90.101 WITH THE APPROPRIATE DIP SWITCH

The main purpose of the web server is to:

- Configure the Profinet name of the device without using an external development environment (Tia Portal, Codesys...)
- Allow the device firmware update

4.1. ACCESS TO THE WEB SERVER

Access to the web server takes place using a web browser and entering the IP address of the device.

On first access the user name and password will be requested.

The default values are:

User Name: admin

Password: admin

ATTENTION!


DEPENDING ON THE DEVICE MODEL AND THE FIRMWARE INSTALLED IN THE DEVICE, IT MAY BE NECESSARY TO ACTIVATE THE DIP SWITCHES TO USE THE WEB SERVER

ATTENTION!

AS LONG AS THE STS LED IS FLASHING IT MEANS THE DEVICE HAS NOT SET AN IP ADDRESS. IN THIS SITUATION IT WILL NOT BE POSSIBLE TO ACCESS THE WEB SERVER

ATTENTION!

AFTER THE FIRST ACCESS CHANGE USER NAME AND PASSWORD IN ORDER TO PREVENT ACCESS TO THE DEVICE TO UNAUTHORIZED PEOPLE.



⚠ ATTENTION!


IF THE PARAMETERS TO ACCESS THE WEB SERVER HAVE BEEN LOST, IT IS NECESSARY TO
RESET THE FACTORY-SET CONFIGURATION

⚠ ATTENTION!

AVOID INSERTING SPECIAL CHARACTERS IN THE PROFINET NAME OF THE DEVICE


5. EXAMPLE OF CREATING A PROJECT WITH SIEMENS PLC (TIA PORTAL 16)

Creating a new project:




5.1. INSTALLING THE GSDML FILE

Install the GSDML file of the Seneca product (it is possible to obtain the file on the web page of the device on the www.seneca.it site):





Point to the directory where the file is and press OK, then the list of GSD files in the folder will appear:




Click on "install".

5.2. INSERTION OF THE SIEMENS PLC IN THE PROJECT


Now insert the Siemens PLC (in our example a SIEMATIC S7 1200), click on "Add new device ...":




Confirm and the PLC will be added to the rack:




Now click on the PLC and select Profinet interface -> Ethernet addresses



Set the IP you want (in this case 192.168.90.44) and the PLC subnet:




Move on to the network view:




5.3. INSERTION OF THE PROFINET SENECA IO



On the right, select "Hardware Catalogue" and then under "Additional Field Device" -> PROFINET IO -> I/O -> Seneca R-Series-> Header module (in the example an R-16DI-8DO device is shown):




Drag the device to the network view:



Now associate it to the PLC by clicking with the left mouse on "Not assigned" and then select the PLC:




Click twice on the Seneca device and configure the IP address here too (for example 192.168.90.48):



In Profinet the devices are identified by their name, so right click on the Seneca device and select "Assign device name"

⚠ ATTENTION!

AVOID INSERTING SPECIAL CHARACTERS IN THE PROFINET NAME OF THE DEVICE




Scan the network with "Update list" and set (if necessary) the device name with "Assign name".

5.4. CONFIGURATION OF THE PARAMETERS OF THE SENECA DEVICE

It is also possible to directly configure the device IO without any external software.

To configure the device, click on the IO so that the "Unit parameters" appear:



At the next start, the PLC will send the desired configuration to the device.

5.5. CONFIGURATION PARAMETERS OF THE GSDML FILE

5.5.1. R-32DIDO-P

SET DIGITAL IO INPUT/OUTPUT

Selects whether the selected input will work as an input or output.

SET DIGITAL INPUT NORMALLY HIGH/LOW

If selected as digital input, it configures whether the input is normally high or low.

SET DIGITAL OUTPUT NORMALLY OPEN/CLOSE

If selected as digital output, it configures whether the output is normally open or closed.

SET DIGITAL OUTPUT WATCHDOG

If selected as digital output, it sets the output watchdog mode.

If "Disabled", it disables the watchdog function for the selected output.

If "Enabled on Profinet Communication" the output goes into "Watchdog state" if there has been no generic Profinet communication within the set time.

SET DIGITAL OUTPUT WATCHDOG STATE

Sets the value that the digital output must adopt if the watchdog has been triggered.

SET DIGITAL OUTPUT WATCHDOG TIMEOUT [s]

Represents the watchdog time of the digital output in seconds. If the PLC stops communicating with the device within the set time, then the outputs will go into the "Watchdog state" condition (if the function is enabled).

5.5.2. R-16DI-8DO-P

SET DIGITAL INPUTS FILTER DELAY [ms]

Sets the filtering of the counters, the value is expressed in [ms].

The filter cut-off frequency corresponds to:

$$\text{[ms]} = 1000 / (2 * \text{[Hz]})$$

For example, if the filter counter is 100ms the cutting frequency will be:

$$\text{[Hz]} = 1000 / (2 * \text{[ms]}) = 5$$

So all input frequencies greater than 5 Hz will be cut.

SET ALL DIGITAL INPUTS NPN/PNP

Sets the input operating mode to between npn "Sink" and pnp "Source"

ENABLE DIGITAL OUTPUTS FAULT TIMEOUT

Set whether the digital output watchdog is to be activated. When enabled, if within the timeout time there has been no communication from the master to the device, the outputs go into a Fail state. This mode allows to obtain a safe system in case of malfunction of the master.

SET DIGITAL OUTPUTS FAULT TIMEOUT [s]

Set the watchdog time of the digital outputs.

SET DIGITAL OUTPUT FAULT STATES OPEN/CLOSE

They set the states of each of the outputs under normal conditions.

SET DIGITAL OUTPUT NORMALLY OPEN/CLOSE

They set the states of each of the outputs in fail conditions.

5.5.3. R-8AI-8DIDO-P**SET DIGITAL IO INPUT/OUTPUT**

Selects whether the selected input will work as an input or output.

SET DIGITAL INPUT NORMALLY HIGH/LOW

If selected as digital input, it configures whether the input is normally high or low.

SET DIGITAL OUTPUT NORMALLY OPEN/CLOSE

If selected as digital output, it configures whether the output is normally open or closed.

SET DIGITAL OUTPUT WATCHDOG

If selected as digital output, it sets the output watchdog mode.

If "Disabled", it disables the watchdog function for the selected output.

If "Enabled on Profinet Communication" the output goes into "Watchdog state" if there has been no generic Profinet communication within the set time.

SET DIGITAL OUTPUT WATCHDOG STATE

Sets the value that the digital output must adopt if the watchdog has been triggered.

SET DIGITAL OUTPUT WATCHDOG TIMEOUT [s]

Represents the watchdog time of the digital output in seconds. If the PLC stops communicating with the device within the set time, then the outputs will go into the "Watchdog state" condition (if the function is enabled).

SET ANALOG MODE

Set the type of measurement for the selected input.

It is possible to choose between the following types of input:

+100mV

+30V

+24 mA

Thermocouple

PT100 3 wires (only for analog input 1).

SAMPLING TIME

Set the sampling time of the channel, selectable between 4 ms and 400 ms, it is also possible to disconnect the input.

SET ANALOG INPUT MOVING FILTER (10 SAMPLES)

Set whether or not to activate the 10-sample moving average filter.

SET ANALOG INPUTS MEASURE OFFSET

Set an offset for analog measurements

SET INPUT START/END SCALE

Represents the start of the electrical scale of the analog measurement used for the register of the engineering measurement.

The value to enter is in the unit of measurement based on the type of input chosen [V], or [mV], or [uA], or [°C]

SET INPUT START/END ENG. SCALE

Represents the electrical full scale of the analog measurement used for the engineering measurement register.

Example:

ANALOG INPUT START SCALE = 4 [mA]

ANALOG INPUT STOP SCALE = 20 [mA]

ANALOG INPUT ENG STOP SCALE = -200 [metri]

ANALOG INPUT ENG START SCALE = 200 [metri]

With a 12 mA input the engineering value will be 0 metres.

SET ANALOG INPUTS TC TYPE

In the case of thermocouple measurement, it allows to select the type of thermocouple between: J, K, R, S, T, B, E, N, L

SET ANALOG INPUTS TC COLD JUNCTION MODE

In the case of thermocouple measurement, it enables or disables the automatic cold junction offset of the device.

SET ANALOG INPUTS TC COLD JUNCTION OFFSET

In the case of thermocouple measurement, set an offset in the cold junction measurement in [°C]

SET ANALOG INPUTS TC BURNOUT MODE

In the case of thermocouple measurement, it selects the behaviour in case of sensor failure: In the case of "Last Value" the value is stopped at the last valid value, in the case of "Fail Value" the "Burnout" value is loaded in the registers.

SET ANALOG INPUTS TC BURNOUT VALUE

In the case of thermocouple measurement, if the ANALOG INPUT BURNOUT MODE = "FAIL VALUE" mode is activated and the sensor is in the "burn" state, it allows you to set a value in °C to be taken by the measurement register.

PT100 3 WIRE

Allows you to choose whether the temperature value detected by input 1 is used for cold junction compensation of all TCs (which have cold junction compensation enabled) or as a temperature measurement.

5.5.4. R-SG3-P

FUNCTION MODE

It allows to configure the basic operation of the device, can be set to factory calibration or to Calibration with standard weight:

FACTORY CALIBRATION

It is used when a load cell with declared sensitivity is available.

In this mode, calibration only consists in acquiring the tare directly in the field with a direct measurement. If it is not possible to acquire the tare with a direct measurement (for example in the case of an already filled silo) it is possible to manually enter the tare value in the desired unit of measurement (kg, t, etc.).

CALIBRATION WITH STANDARD WEIGHT

It is used when a sample weight is available (as far as possible towards the load cell full scale).

In this mode the calibration consists in acquiring both the tare and the sample weight directly on the field.

MEASURE TYPE

It allows to configure the operation of the device between:

BALANCE (UNIPOLAR)

It is used when a scale is being created in which the load cell is only compressed, in this case the maximum resolution of the compression measurement is obtained.

COMPRESSION AND TRACTION (BIPOLAR)

It is used when a measurement system (typically of force) is being created that can both compress and extend the load cell. In this case the direction of the force can also be decided, if compression the measurement will have the + sign, if traction it will have the - sign. A typical case of use is to link the direction of the force to the analog output so that, for example, 4mA correspond to the maximum traction force and 20mA correspond to the maximum compression force (in this case the cell at rest will provide 12mA).

MEASURE UNIT

Sets the unit of measurement for the weighing in g, Kg, etc.

CELL SENSIBILITY

It is the declared cell sensitivity value expressed in mV/V (in most cells it is 2mV/V).

CELL FULL SCALE

It is the full scale value of the cell expressed in the selected unit of measurement.

STANDARD WEIGHT VALUE

It represents the value of the sample weight that will be used in the calibration if the operating mode with standard weight has been chosen.

NOISE FILTER

Enables or disables measurement filtering.

FILTER LEVEL

Allows you to set the measurement filter level according to the following table:

FILTER LEVEL	RESPONSE TIME [ms]
0	2
1	6.7
2	13
3	30
4	50
5	250
6	850
ADVANCED	Configurable

The higher the filter level the more stable (but slow) the weight measurement will be.

If you select the advanced filtering level (Advanced), the configuration will allow you to select the following parameters:

ADC SPEED Selects the ADC acquisition speed from 4.7 Hz to 960 Hz

NOISE VARIATION It is the variation in ADC points due to noise alone (represents the measurement uncertainty due to noise) or how much we expect the measurement to vary (the unit of measurement is in raw ADC points).

FILTER RESPONSE SPEED

Represents a parameter related to the filter response speed, it can vary from 0.001 (slowest response) to 1 (fastest response). Represents the variance of the process.

NET WEIGHT RESOLUTION

It is the resolution with which the value of the net weighing is represented, it can be worth:

MAXIMUM RESOLUTION

It will represent the net weight with the highest possible resolution

MANUAL

It will represent the net weight with the manual resolution set (in engineering units).

For example, by setting 0.1 Kg you will get that the net weight can only vary by multiples of 100g.

AUTOMATIC RESOLUTION

It will represent the net weight with a calculated resolution of about 20000 points. Unlike Maximum or Manual resolution, this setting limits also the ADC value and therefore affects all measurements.



Keep in mind that in the "Calibration with sample weight" mode, using the "Manual Resolution", the correct sample weight value may not be perfectly represented:

For example, you have:

Cell full scale 15000 g

Sample weight 14000 g

Manual Resolution 1.5 g

The value of the sample weight (14000 g) cannot be represented with the resolution in 1.5g steps ($14000/1.5g = 9333.333$ is not an integer value) so it will be represented as: $9333*1.5g = 13999.5g$. To avoid this effect, use a resolution that allows the value to be represented (for example 1g or 2g).

SAMPLE PIECE WEIGHT

Sets the weight of a single piece in technical units for the mode. By setting the net weight of a single element in this register, the converter will be able to indicate the number of pieces present in the scales special register according to the relation:

$$Nr\ Pezzi = \frac{Peso\ Netto}{Peso\ Pezzo\ Campione}$$

AUTOMATIC TARE TRACKER

It allows you to enable or disable the automatic tare reset.

ADC VALUE

It allows to set the number of ADC points within which to reset the tare automatically.

If after 5 seconds of stable weighing condition the ADC value of the net weight deviates by less than this value then a new tare is acquired.

DELTA WEIGHT

Weight variation that contributes to the definition of "Stable Weight"


DELTA TIME [x100ms]

Time variation that contributes to the definition of "Stable Weight"

STABLE WEIGHT (Stable weighing condition)

The stable weighing condition is used to indicate that the net weight measurement is stable if:

The net weight remains within the weight $\Delta peso_netto$ over time $\Delta tempo$ or if the slope of the curve drawn by the net weight is less than $\frac{\Delta peso_netto}{\Delta tempo}$:



*You will be prompted to enter Delta Net Weight (**Delta Weight**) (in engineering units) and Delta Time (**Delta Time**) (in 0.1 seconds).*

ANALOG OUTPUT WORKING MODE

Select whether the analogue output is linked to the net measurement or controlled by the Profinet io protocol.

ANALOG OUTPUT TYPE

Select whether the analogue output is Voltage or Current

DIGITAL I/O MODE

Configure the device's digital I/O as input or output

FUNCTION

Configure the operation if the I/O is configured as a digital input:

ACQUIRE TARE

In this mode, if the digital input is activated for a time longer than 3 seconds, a new tare value is acquired (in RAM, then it is lost upon restart). It is equivalent to sending the command 49594 (decimal) in the command register.

DIGITAL INPUT

The input is configured as a digital input whose value can be read from the appropriate register.

DIGITAL OUTPUT MODE

In the case of configuring the I/O as a digital output it is possible to choose whether this should be configured as normally open (**Normally Open**) or as normally closed (**Normally Close**)

DIGITAL OUTPUT CONFIGURATION

Here you can choose the behaviour of the digital output:

FULL SCALE CELL

The digital output is activated if the cell has reached the measurement full scale.


THRESHOLD AND STABLE WEIGHT

In this mode, the output activates when the net weight reaches the threshold and the weigh is in a stable weighing condition

STABLE WEIGHT

The stable weighing condition is used to indicate that the net weight measurement is stable if:

The net weight remains within the weight $\Delta \text{peso_netto}$ over time Δtempo or if the slope of the curve drawn by the net weight is less than $\frac{\Delta \text{peso_netto}}{\Delta \text{tempo}}$:



STABLE WEIGHT


In this mode the output is activated if the weighing is in the stable weighing condition.

COMMANDABLE FROM PROFINET

In this mode the digital output can be controlled by the Profinet IO protocol.


THRESHOLD WITH HYSTERESIS

In this mode the output is activated when the net weight reaches the threshold, the alarm is cancelled when the net weight falls below the Threshold-Hysteresis value:



5.6. R-32DIDO-P I/O DATA

Define the PLC tags directly in the "standard tag table":



Now let's add the variables related to the IO, the addresses are shown here:

Vista generale dispositivi							
	Modulo	Telaio...	Posto ...	Indirizzo I	Indirizz...	Tipo	Nº di articolo
	▼ r32didop	0	0			R-32DIDO-P Ethern...	R-32DIDO-P
	► PN-IO	0	0 X1			r32didop	
	32DIDO	0	1	1...4	1...4	32DIDO	

So:

The bytes from I1 to I4 contain the inputs (bit 0 is IO1, bit 1 is IO2 etc.)

Bytes Q1 to Q4 contain the outputs (bit 0 is IO1, bit 1 is IO2 etc ...), obviously only the outputs are writable.

Below is the default mapping of available IOs:

INPUT/OUTPUT	DEFAULT ADDRESS IO CONFIGURED AS AN INPUT	DEFAULT ADDRESS IO CONFIGURED AS AN OUTPUT
IO1	I1.0	Q1.0
IO2	I1.1	Q1.1
IO3	I1.2	Q1.2
IO4	I1.3	Q1.3
IO5	I1.4	Q1.4
IO6	I1.5	Q1.5
IO7	I1.6	Q1.6
IO8	I1.7	Q1.7
IO9	I2.0	Q2.0
IO10	I2.1	Q2.1
IO11	I2.2	Q2.2
IO12	I2.3	Q2.3
IO13	I2.4	Q2.4
IO14	I2.5	Q2.5
IO15	I2.6	Q2.6
IO16	I2.7	Q2.7
IO17	I3.0	Q3.0
IO18	I3.1	Q3.1
IO19	I3.2	Q3.2
IO20	I3.3	Q3.3
IO21	I3.4	Q3.4
IO22	I3.5	Q3.5
IO23	I3.6	Q3.6
IO24	I3.7	Q3.7
IO25	I4.0	Q4.0
IO26	I4.1	Q4.1
IO27	I4.2	Q4.2
IO28	I4.3	Q4.3
IO29	I4.4	Q4.4
IO30	I4.5	Q4.5
IO31	I4.6	Q4.6
IO32	I4.7	Q4.7

So if, for example, I need 16 inputs and 16 outputs, I can use the Booleans from I1.0 to I2.7 for the inputs (which will therefore be found in the IO1 ... IO16) and the Booleans from Q3.0 to Q4.7 for the outputs (which will then be found in the IO17 ... IO32).

ATTENTION!


An IO configured as an input cannot be controlled as an output.
An IO configured as an output cannot be read as an input.

Always following our example (16 inputs and 16 outputs) we define the 16 inputs and 16 outputs in the standard variables table:

	i	Nome	Indirizzo	Formato visualizz..	Valore di controllo	Valore di comando	⚡
1		"IN1"	%I1.0	Bool	TRUE		<input type="checkbox"/>
2		"IN2"	%I1.1	Bool	TRUE		<input type="checkbox"/>
3		"IN3"	%I1.2	Bool	TRUE		<input type="checkbox"/>
4		"IN4"	%I1.3	Bool	TRUE		<input type="checkbox"/>
5		"IN5"	%I1.4	Bool	FALSE		<input type="checkbox"/>
6		"IN6"	%I1.5	Bool	FALSE		<input type="checkbox"/>
7		"IN7"	%I1.6	Bool	FALSE		<input type="checkbox"/>
8		"IN8"	%I1.7	Bool	FALSE		<input type="checkbox"/>
9		"IN9"	%I2.0	Bool	TRUE		<input type="checkbox"/>
10		"IN10"	%I2.1	Bool	FALSE		<input type="checkbox"/>
11		"IN11"	%I2.2	Bool	FALSE		<input type="checkbox"/>
12		"IN12"	%I2.3	Bool	FALSE		<input type="checkbox"/>
13		"IN13"	%I2.4	Bool	FALSE		<input type="checkbox"/>
14		"IN14"	%I2.5	Bool	FALSE		<input type="checkbox"/>
15		"IN15"	%I2.6	Bool	FALSE		<input type="checkbox"/>
16		"IN16"	%I2.7	Bool	FALSE		<input type="checkbox"/>
17		"OUT17"	%Q3.0	Bool	<input checked="" type="checkbox"/>		<input type="checkbox"/>
18		"OUT18"	%Q3.1	Bool			<input type="checkbox"/>
19		"OUT19"	%Q3.2	Bool			<input type="checkbox"/>
20		"OUT20"	%Q3.3	Bool			<input type="checkbox"/>
21		"OUT21"	%Q3.4	Bool			<input type="checkbox"/>
22		"OUT22"	%Q3.5	Bool			<input type="checkbox"/>
23		"OUT23"	%Q3.6	Bool			<input type="checkbox"/>
24		"OUT24"	%Q3.7	Bool			<input type="checkbox"/>
25		"OUT25"	%Q4.0	Bool			<input type="checkbox"/>
26		"OUT26"	%Q4.1	Bool			<input type="checkbox"/>
27		"OUT27"	%Q4.2	Bool			<input type="checkbox"/>
28		"OUT28"	%Q4.3	Bool			<input type="checkbox"/>
29		"OUT29"	%Q4.4	Bool			<input type="checkbox"/>
30		"OUT30"	%Q4.5	Bool			<input type="checkbox"/>
31		"OUT31"	%Q4.6	Bool			<input type="checkbox"/>
32		"OUT32"	%Q4.7	Bool			<input type="checkbox"/>
33		<Aggiungi>					<input type="checkbox"/>

Now compile, send the project and go online with the PLC.

Once online, press the glasses icon to update the status of the variables.




Under the "Control value" column you can read the I/O value in real time.

To control the outputs, it is necessary to enter "TRUE" or "FALSE" in the "Command value" column and then press the icon with the lightning bolt to order the writing. Note the status of the LED relating to the commanded output.

In the "Control value" column, the status of the outputs is also read in real time.

5.7. R-16DI-8DO-P I/O DATA


Define the PLC tags directly in the "standard tag table":



Add the tags related to the IO (in the example it is an R-16DI-8DO that is 16 digital inputs and 8 digital outputs). The addresses are written here:

Vista generale dispositivi							
	Modulo	Telaio...	Posto ...	Indirizzo I	Indirizzo Q	Tipo	Nº di articolo
	r16di8do	0	0	0 X1		R-16DI-8DO Ethern...	R-16DI-8DO
	PN-HO	0				r16di8do	
	16DI-8DO_1	0	1	1...2	1	16DI-8DO	


So bytes I1 and I2 contain the 16 inputs, byte Q1 the 8 outputs:



Nome	Tipo di dati	Indirizzo	Riten...	Acces...	Scrivi...	Visibil...	Commento
DI(1)	Bool	%I1.0		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(2)	Bool	%I1.1		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(3)	Bool	%I1.2		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(4)	Bool	%I1.3		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(5)	Bool	%I1.4		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(6)	Bool	%I1.5		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(7)	Bool	%I1.6		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(8)	Bool	%I1.7		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(9)	Bool	%I2.0		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(10)	Bool	%I2.1		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(11)	Bool	%I2.2		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(12)	Bool	%I2.3		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(13)	Bool	%I2.4		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(14)	Bool	%I2.5		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(15)	Bool	%I2.6		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DI(16)	Bool	%I2.7		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
DO1	Bool	%Q1.0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
DO2	Bool	%Q1.1		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
DO3	Bool	%Q1.2		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
DO4	Bool	%Q1.3		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
DO5	Bool	%Q1.4		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
DO6	Bool	%Q1.5		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
DO7	Bool	%Q1.6		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
DO8	Bool	%Q1.7		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<Aggiungi>				<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	


After this operation, define a new control table:

Click on "Add new control table" and then insert the variables




i	Nome	Indirizzo	Formato visualizz..	Valore di controllo	Valore di coman...
1	<Aggiungi>				

Since you have already defined them previously, just select the ones we want to monitor from the list:




	i	Nome	Indirizzo	Formato visualizz..	Valore di controllo	Valore di comando	⚡
1		<Aggiungi>					
		↳ DI "DI(1)"		Bool	%I1.0		
		↳ DI "DI(2)"		Bool	%I1.1		
		↳ DI "DI(3)"		Bool	%I1.2		
		↳ DI "DI(4)"		Bool	%I1.3		
		↳ DI "DI(5)"		Bool	%I1.4		
		↳ DI "DI(6)"		Bool	%I1.5		
		↳ DI "DI(7)"		Bool	%I1.6		
		↳ DI "DI(8)"		Bool	%I1.7		

Once you have added all of them you will get:



	i	Nome	Indirizzo	Formato visualizz..	Valore di controllo	Valore di comando	⚡	Commento	Commento della variabile
1		"DI(1)"	%I1.0	Bool					
2		"DI(2)"	%I1.1	Bool					
3		"DI(3)"	%I1.2	Bool					
4		"DI(4)"	%I1.3	Bool					
5		"DI(4)"	%I1.3	Bool					
6		"DI(5)"	%I1.4	Bool					
7		"DI(6)"	%I1.5	Bool					
8		"DI(7)"	%I1.6	Bool					
9		"DI(8)"	%I1.7	Bool					
10		"DI(8)"	%I1.7	Bool					
11		"DI(9)"	%I2.0	Bool					
12		"DI(10)"	%I2.1	Bool					
13		"DI(11)"	%I2.2	Bool					
14		"DI(12)"	%I2.3	Bool					
15		"DI(13)"	%I2.4	Bool					
16		"DI(14)"	%I2.5	Bool					
17		"DI(15)"	%I2.6	Bool					
18		"DI(16)"	%I2.7	Bool					
19		"DO1"	%Q1.0	Bool					
20		"DO2"	%Q1.1	Bool					
21		"DO3"	%Q1.2	Bool					
22		"DO4"	%Q1.3	Bool					
23		"DO5"	%Q1.4	Bool					
24		"DO6"	%Q1.5	Bool					
25		"DO7"	%Q1.6	Bool					
26		"DO8"	%Q1.7	Bool					
27		<Aggiungi>							


Now compile, send the project and go online with the PLC (all operations seen previously):
Once online, press the glasses icon to update the status of the variables:



	Nome	Indirizzo	Formato visualizz.	Valore di controllo	Valore di comando	Commento
1	"DI(1)"	%I1.0	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
2	"DI(2)"	%I1.1	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
3	"DI(3)"	%I1.2	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
4	"DI(4)"	%I1.3	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
5	"DI(5)"	%I1.3	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
6	"DI(6)"	%I1.4	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
7	"DI(7)"	%I1.5	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
8	"DI(8)"	%I1.6	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
9	"DI(9)"	%I1.7	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
10	"DI(10)"	%I1.7	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
11	"DI(11)"	%I2.0	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
12	"DI(12)"	%I2.1	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
13	"DI(13)"	%I2.2	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
14	"DI(14)"	%I2.3	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
15	"DI(15)"	%I2.4	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
16	"DI(16)"	%I2.5	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
17	"DO1"	%Q1.0	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
18	"DO2"	%Q1.1	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
19	"DO3"	%Q1.2	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
20	"DO4"	%Q1.3	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
21	"DO5"	%Q1.4	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
22	"DO6"	%Q1.5	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
23	"DO7"	%Q1.6	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
24	"DO8"	%Q1.7	Bool	<input checked="" type="checkbox"/> FALSE	<input type="checkbox"/>	
25						
26						
27						

Under the "Control value" column you can read the I/O value in real time.

To control the outputs, it is necessary to enter "TRUE" in the "Command value" column and then press the icon with the lightning bolt to order the writing:




	i	Nome	Indirizzo	Formato visualizz..	Valore di controllo	Valore di comando	⚡	Comando
1		"DI(1)"	%I1.0	Bool	FALSE			
2		"DI(2)"	%I1.1	Bool	FALSE			
3		"DI(3)"	%I1.2	Bool	FALSE			
4		"DI(4)"	%I1.3	Bool	FALSE			
5		"DI(4)"	%I1.3	Bool	FALSE			
6		"DI(5)"	%I1.4	Bool	FALSE			
7		"DI(6)"	%I1.5	Bool	FALSE			
8		"DI(7)"	%I1.6	Bool	FALSE			
9		"DI(8)"	%I1.7	Bool	FALSE			
10		"DI(8)"	%I1.7	Bool	FALSE			
11		"DI(9)"	%I2.0	Bool	FALSE			
12		"DI(10)"	%I2.1	Bool	FALSE			
13		"DI(11)"	%I2.2	Bool	FALSE			
14		"DI(12)"	%I2.3	Bool	FALSE			
15		"DI(13)"	%I2.4	Bool	FALSE			
16		"DI(14)"	%I2.5	Bool	FALSE			
17		"DI(15)"	%I2.6	Bool	FALSE			
18		"DI(16)"	%I2.7	Bool	FALSE			
19		"DO1"	%Q1.0	Bool	TRUE	TRUE		
20		"DO2"	%Q1.1	Bool	TRUE			
21		"DO3"	%Q1.2	Bool	FALSE			
22		"DO4"	%Q1.3	Bool	FALSE			
23		"DO5"	%Q1.4	Bool	FALSE			
24		"DO6"	%Q1.5	Bool	FALSE			
25		"DO7"	%Q1.6	Bool	FALSE			
26		"DO8"	%Q1.7	Bool	FALSE			
27		<Aggiungi>						

In the "Control value" column, the outputs are now correctly read to "True".

5.8. R-8AI-8DIDO-P I/O DATA

Define the PLC tags directly in the "standard tag table":



Let's now add the variables relating to the IO. For example the addresses are written here:

Vista generale dispositivi						
	Modulo	Telaio...	Posto connettore	Indirizzo I	Indirizzo Q	Tipo
	▼ r8ai8didop	0	0			R-8AI-8DIDO-P Ethe...
	► PN-IO	0	0 X1			r8ai8didop
	8AIN Integer value_1	0	1	68...83		8AIN Integer value
	8DIDO_1	0	2	1	1	8DIDO
	8AIN_1	0	3	84...115		8AIN
	AIN Burn State_1	0	4	2		AIN Burn State

So byte I1 contains the 8 digital inputs (those as inputs), byte Q1 the 8 outputs (those configured as outputs). Bytes from I68 to I83 show the values of the 8 analog inputs (2 bytes per input). Bytes from I84 to I15 show the values of the 8 analog inputs floating point (4 bytes per input). Byte I2 shows the burnout status of the analog inputs configured by thermocouple.

Below is the default mapping of the available digital IOs:

INPUT/OUTPUT	DEFAULT ADDRESS IO CONFIGURED AS AN INPUT	DEFAULT ADDRESS IO CONFIGURED AS AN OUTPUT
IO1	I1.0	Q1.0
IO2	I1.1	Q1.1
IO3	I1.2	Q1.2
IO4	I1.3	Q1.3
IO5	I1.4	Q1.4
IO6	I1.5	Q1.5
IO7	I1.6	Q1.6
IO8	I1.7	Q1.7


The default mapping of the analog IOs is as follows:

INTEGER ANALOG INPUT	DEFAULT ADDRESS INPUT
AIN1	IW2
AIN 2	IW4
AIN 3	IW6
AIN 4	IW8
AIN 5	IW10
AIN 6	IW12
AIN 7	IW14
AIN 8	IW16

FLOATING POINT ANALOG INPUT	DEFAULT ADDRESS INPUT
AIN1	ID18
AIN 2	ID22
AIN 3	ID26
AIN 4	ID30
AIN 5	ID34
AIN 6	ID38
AIN 7	ID42
AIN 8	ID44


5.9. R-SG3-P I/O DATA

Define the PLC tags directly in the "standard tag table":



Let's now add the variables relating to the IO.

For example the addresses are written here:



Modulo	Telaio...	Posto ...	Indirizzo I	Indirizz...	Tipo	Nº di articolo
ze-r-sg3-p	0	0			ZE/R-SG3-P Etherne...	ZE/R-SG3-P
► PN-I/O	0	0 X1			ze-r-sg3-p	
Weight (Integer)_1	0	1	68...81		Weight (Integer)	
DIN/DOUT_1	0	2	1	1	DIN/DOUT	
	0	3				
	0	4				
	0	5				
	0	6				

WEIGHT (INTEGER)

Name	Data Type
Net weight	Integer32
Gross weight	Integer32
Tare weight	Integer32
Num. pieces	Unsigned16

Where:

WEIGHT INTEGER	DEFAULT ADDRESS INPUT
NET WEIGHT	ID2
GROSS WEIGHT	ID4
TARE WEIGHT	ID6
NUM. PIECES	IW8

DIN/DOUT

Name	Data Type	Display as Bits
Digital Inputs (1..2)	Unsigned8	Bit 0: Digital Input 1 Bit 1: Digital Input 2

Name	Data Type	Display as Bits
Digital Outputs (1..2)	Unsigned8	Bit 0: Digital Output 1 Bit 1: Digital Output 2

INPUT/OUTPUT	DEFAULT ADDRESS IO CONFIGURED AS AN INPUT	DEFAULT ADDRESS IO CONFIGURED AS AN OUTPUT
IO1	I1.0	Q1.0
IO2	I1.1	Q1.1

Optionally you can add:

ANALOGUE OUTPUT (NOT USABLE ON THE R-SG3-P MODEL)

Name	Data Type
Analog output value	Unsigned16

It allows you to control the analogue voltage/current output by providing the value in uA or mV

COMMAND

Name	Data Type
Command value	Unsigned16

It allows you to send commands to the device:

COMMAND (DECIMAL)	FUNCTION
43948	Reboot the device
49594	Acquires the tare in RAM (at reboot is lost)
49914	Acquires the tare in Flash for the calibration procedure in both operating modes (factory calibration and with sample weight)
50700	Acquires the sample weight value in Flash for calibration with standard weight
50773	Acquires the tare value from the register MANUAL TARE (only for the factory calibration mode)
49151	Reset the maximum net weight
45056	Reset the register with the minimum net weight

DIAGNOSTIC

Name	Data Type
Diagnostic	Unsigned16

BIT 0 LSBIT (RO)

Bit 0 = 1 THRESHOLD AND STABLE WEIGHT for DIDO 1

BIT 1 (RO)

Bit 1 = 1 FULL SCALE CELL

BIT 2 (RO)

Bit 2 = 1 NET WEIGHT < 0

BIT 3 (RO)

Bit 3 =1 THRESHOLD AND STABLE WEIGHT for DIDO 2

BIT 4 (RO)

Bit 4 = 1 Stable weight

BIT 5-6 Not used

BIT 7 (RO)

Bit 7 = 1 Threshold with hysteresis for DIDO 1

BIT 8 (RO)

Bit 8 = 1 automatic tare tracker (if enabled)

BIT 9 (RO)

Bit 9 = 1 Threshold with hysteresis for DIDO 2

BIT 10..15 Not used

WEIGHT (FLOAT)


Name	Data Type
Net weight	Float32
Gross weight	Float32
Tare weight	Float32
Max Net weight	Float32
Min Net weight	Float32

5.10. COMPILED AND SENDING OF THE PROJECT TO THE SIEMENS PLC


Now that the devices are configured, all that remains is to compile and send the configuration to the PLC.




YOU MUST ALWAYS DO A FULL HARDWARE COMPILE BEFORE SENDING A PROJECT TO THE DEVICE:




Before sending the project to the PLC, you are asked to select the ethernet interface and start the search, in order to select the PLC and press "Load".




Once the project has been sent, RUN the PLC:



And go On-Line so as to check if there are any errors:




If everything is correct you will get a green icon next to the Seneca device:




6. EXAMPLE OF CREATING A PROJECT WITH PLC CODESYS 3.5

Create a new standard project:




6.1.1. INSERTION OF THE CODESYS PLC IN THE PROJECT


Configure the PLC by selecting it in the tree on the left and then browsing the network:




Select the PLC after scanning the network:




The PLC is now connected to the system:




Now that the PLC has been detected, move on to insert a Profinet port on standard Ethernet:
Right click on device and "add device":




Then add the Profinet IO Master:



Double click on Ethernet, set the Ethernet port and the IP address of the PLC (in this case use 192.168.90.44):



Set also the address range for the Profinet peripheral, double click on PN_Controller:




6.1.2. INSTALLING THE GSD


Now you need to connect the Seneca slave device PROFINET IO to the profinet master (controller).

First install the GSD file of the Seneca IO.

Select Tools->Device Repository:



Now import the GSD file by selecting Profinet IO Slave and then Install:




Now point to the correct folder and press OK.

Codesys has now added the GSD file correctly.


At this point you can scan the network in search of Slave devices (Device).

First compile the project and log in to the PLC:




6.1.3. INSTALLATION OF THE SENECA PROFINET IO


Now that you are connected to the PLC, run the scan to find the devices:



In the list of devices, select the Seneca IO and then "Copy to project":




At this point you have added the device to the project:




6.1.4. CONFIGURATION OF THE PARAMETERS OF THE SENECA IO

If you want to change the IO configuration parameters, you can set them from here:



Check that everything is correct by compiling and running the PLC.

The PLC (Raspberry-pi) is quite slow and not real time, consequently it cannot manage the profinet at maximum speed so we modify the values by setting safety parameters:




6.1.5. READING AND WRITING THE SENECA IO FROM CODESYS

Now see how it is possible to read and write IO on the Seneca device.


To write and read the status of the IO you have to insert a few code lines under PRG.

In the program, read the inputs from the %IW2 address and write in the %QB0 address as it is obtained from here:




Declare an 8-bit (Word) variable for the 16 inputs and one byte for the 8 outputs.

In the program, instead, read the inputs from %IW2 and write the outputs on %QB0:




Go into login and start.

The value of the inputs can be read here:



while to write the outputs you just set the byte value in the "prepared value" column, for example by writing 255 decimal = 11111111 binary all the outputs will be brought to 1:




And then with "Write values" all the outputs are activated correctly.

7. CABLE HARNESS FOR MODELS WITH DOUBLE ETHERNET PORT

Models with double Ethernet port can be connected in daisy chain and take advantage of the Lan Fault Bypass.

7.1. CHAIN ETHERNET CONNECTION (DAISY CHAIN)


Using the daisy chain connection it is not necessary to use switches to connect the devices.
An example (in this case on R-16DI-8DO-P) of connection of 3 devices is as follows:




ATTENTION!

IT IS NOT POSSIBLE CREATE LOOPS WITH ETHERNET CABLES

If it is necessary to connect the devices to the switches, correct wiring is as follows:



In the Ethernet wiring there must be no loop, otherwise the communication will not work, some examples of incorrect wiring are the following:




7.2. LAN FAULT-BYPASS FUNCTION

The LAN fault-bypass function allows you to keep the connection between the two Ethernet ports of the device ON, in the event of power failure problems.

If a device turns off, the chain is not interrupted and the devices downstream of the switched-off one will still be accessible.

This function has a limited duration: the connection remains active for a few days, typically 4.

The Lan fault-bypass function requires that the sum of the lengths of the two cables connected to the switched off module is less than 100m.









8. SEARCH AND MODIFICATION OF THE DEVICE IP WITH SENECA DISCOVERY TOOL

When in the R series device the STS LED is on steady, it is possible to obtain the IP address which has been set using the "Seneca Discovery" tool too.

The software can be downloaded from:


<https://www.seneca.it/en/linee-di-prodotto/software/easy/sdd>

Pressing the "search" button starts the search for all Seneca devices present in the network even if with IP addresses not compatible with the current PC configuration:

Seneca Device Discovery - rev. 2.1.4.1										
Devices found										
#	IP	Mode	MAC	Ping	Name	Hostname	Firmware	CRC	Commands	
1	192.168.86.95	DHCP	00:A7:C5:F1:11:92	2 ms	R-16DI-8DO	192.168.86.95	997.1014	OK	<button>Assign</button>	
2	192.168.90.199	STATIC	C8:F9: 	Different Subnet	Z-KEY	192.168.90.199	126.0	OK	<button>Assign</button>	
3	192.168.85.8	STATIC	C8:F9: 	4 ms	Z-KEY		119.0	OK	<button>Assign</button>	
4	192.168.85.106	STATIC	C8:F9: 	4 ms	Z-PASS2-S		2940.343	OK	<button>Assign</button>	
5	192.168.84.156	STATIC	00:22: 	2 ms	Cloud BOX		7800.112	OK	<button>Assign</button>	
6	192.168.85.198	STATIC	C8:F9: 	2 ms	Z-PASS2-S		2940.335	OK	<button>Assign</button>	
7	192.168.84.192	STATIC	C8:F9: 	2 ms	Z-TWS4		2940.331	OK	<button>Assign</button>	
8	192.168.85.7	STATIC	C8:F9:	2 ms	Z-PASS2		3900.240	OK	<button>Assign</button>	
9	192.168.85.200	STATIC	C8:F9:	3 ms	Z-TWS4		2940.220	OK	<button>Assign</button>	
10	192.168.85.69	STATIC	00:50:	2 ms	Cloud BOX		7800.200	OK	<button>Assign</button>	
11	192.168.84.155	STATIC	00:22:	2 ms	Cloud BOX		7800.111	OK	<button>Assign</button>	
12	192.168.85.103	STATIC	C8:F9:	2 ms	Z-PASS2		3900.250	OK	<button>Assign</button>	
13	192.168.100.101	DHCP	C8:F9:	Different Subnet	Z-PASS2	192.168.100.101	3900.240	OK	<button>Assign</button>	

Found 14 devices

It is now possible to change the address by pressing the "Assign" button:



The software works on layer 2 level and it is therefore not necessary to have an Ethernet configuration compatible with the device you are looking for.

ATTENTION!

AS LONG AS THE STS LED IS FLASHING IT MEANS THE DEVICE HAS NOT SET AN IP ADDRESS. IN THIS SITUATION IT WILL NOT BE POSSIBLE TO SEARCH FOR THE DEVICE WITH THE SENECA DISCOVERY TOOL SOFTWARE

9. FIRMWARE UPDATE

The firmware update can be performed via the web server in the appropriate section.



BEFORE ACCESSING THE WEB SERVER, DISCONNECT THE DEVICE FROM THE PROFINET NETWORK



NOT TO DAMAGE THE DEVICE DO NOT REMOVE THE POWER SUPPLY DURING THE FIRMWARE UPDATE OPERATION.



SOME MODELS ARE SUPPLIED WITHOUT AN IP ADDRESS (0.0.0.0) IN THIS CASE THE “STS” LED FLASHES.

TO SET AN IP ADDRESS (FOR EXAMPLE TO ACCESS THE WEB SERVER OR TO CONNECT TO THE SENECA DISCOVERY DEVICE TOOL) USE THE PROFINET CONFIGURATION ENVIRONMENT OR FORCE THE ADDRESS 192.168.90.101 WITH THE APPROPRIATE DIP SWITCH