

USER MANUAL

ZC-3AO

SENECA s.r.l.

Via Austria, 26 – 35127 – PADOVA – ITALY

Tel. +39.049.8705355 – 8705359 Fax. +39.049.8706287

Web site: www.seneca.it

Technical assistance: supporto@seneca.it (IT), support@seneca.it (Other)

Commercial reference: commerciale@seneca.it (IT), sales@seneca.it (Other)



This document is property of SENECA srl. Duplication and reproduction of its are forbidden (though partial), if not authorized. Contents of present documentation refers to products and technologies described in it. Though we strive for reach perfection continually, all technical data contained in this document may be modified or added due to technical and commercial needs; it's impossible eliminate mismatches and discordances completely. Contents of present documentation is anyhow subjected to periodical revision. If you have any questions don't hesitate to contact our structure or to write us to e-mail addresses as above mentioned.

Seneca Z-PC Line module: **ZC-3AO**

The ZC-3AO supplies 3 single-ended analog signals (voltage or current type), with two types of communication: CANopen protocol, ModBUS protocol (RS232 serial).

General characteristics

Hardware

- Analog outputs either in current 0–20 mA or in bidirectional voltage -10 – 10 V
- High accuracy and resolution.
- Fast response time (typical <20ms)
- 1500 VAC isolation amongst outputs, power supply and CAN interface.
- Protection against ESD discharge up to 4 kV.
- Adjustable rejection at 50 and 60Hz.
- Simplified power supply and serial bus wiring by means of the bus housed in the DIN rail.
- Output protection, both in voltage output (against short circuit or applied voltage) or in current output (against applied voltage)

Software


- Singularly activable channels.
- Output either in current or in voltage selectable by programming
- Minimum and maximum values for the three analog outputs selectable independently each other
- Led Indications: Power Supply, CAN communication, MODBUS-RTU communication, Inputs fault.

Communication

- CAN Interface with CANopen protocol: up to 1 Mbps speed.
- CANopen Baud rate and Node ID configurability by DIP-switches or software.
- Node guarding or heartbeat
- RS232 Serial Communication with MODBUS-RTU protocol
- Complete configurability through specific software downloadable in the website www.seneca.it

Features

| OUTPUT | |
|------------------------------------|---|
| Number | 3 |
| Type | Selectable by programming Bidirectional -10.5 V..10.5V, push-pull configuration Unidirectional 0..20.5 mA, current source configuration |
| Accepted impedance | Voltage output: > 1 k Ω Current output: < 600 Ω |
| Max open circuit voltage | ~17 V for one current output |
| CONVERSION/ACCURACY SPECIFICATIONS | |
| DAC | 14 bits |
| Accuracy | Calibration: 0.01% Linearity: 0.02% |
| Thermal drift | < 100 ppm/°C |
| Noise rejection | 50 or 60 Hz |
| CONNECTIONS | |
| Removable terminals | Removable 3-way screw terminals, 5.08 mm pitch |
| IDC10 rear connector | CAN interface and power supply (for DIN rail) |
| Stereophonic frontal jack | 3.5 mm for RS232 connection (COM) |
| 1500 Vac ISOLATIONS | |
| | Between: power supply, CAN, outputs |



| POWER SUPPLY | |
|-------------------|---|
| Supply voltage | 10 – 40 Vdc or 19 – 28 Vac (50Hz - 60Hz) |
| Power consumption | Max: 2.5 W |

The power supply transformer necessary to supply the module must comply with EN60742 (Isolated transformers and safety transformers requirements).

NOTE: “0x” means a hexadecimal number interpretation.

CANOpen features

| TECHNICAL DATA | |
|-------------------------------|--|
| Baud rate | 20, 50, 125, 250, 500, 800, 1000 kbps |
| Typ min to max output time | 20 ms for all 3 outputs |
| Channel range in voltage mode | From -10.5 V to +10.5 V |
| Channel range in current mode | From 0 to 20.5 mA |
| CANOpen TECHNICAL DATA | |
| NMT | slave |
| Node ID | Node guarding, heartbeat |
| Node ID | HW switch or software |
| Number of PDO | 1 RX |
| PDO modes | Event triggered, Sync (cyclic), Sync (acyclic) |
| PDO mapping | Variable |
| PDO linking | supported |
| Number of SDO | 1 server |
| Error message | yes |
| Supported application | Cia 301 v4.02 |
| Layer | Cia 401 v2.01 |

CANOpen TPDOs transmission type supported

| Object Value 0x180x Sub 2 | TRANSMISSION TYPE |
|---------------------------|-----------------------|
| 0 | Synchronous - acyclic |
| From 1 to 240 | Synchronous - cyclic |
| 255 | Asynchronous |

CANOpen PDOs mapping

| OBJECTS FOR DEFAULT MAPPING | | | | |
|-----------------------------|---------------------------|----------------------------|--------|----------|
| PDO NR | COB-ID | MAPPED OBJECTS | INDEX | SUBINDEX |
| RPDO2 | 0x00000300 + NodeId | Output value CH1 ±10000 | 0x6411 | 1 |
| | | Output value CH2 ±10000 | 0x6411 | 2 |
| | | Output value CH3 ±10000 | 0x6411 | 3 |

Note that TPDO COB-ID must start with 0x4.

CANOpen emergency message

The Emergency message is composed by:

2 bytes of EEC (Emergency error code)

1 bytes of ER (Error register)

4 bytes MEF (Manufacturer error filled objects) (0x1002)

For EEC code 0xFF10, the emergency message is:

| EMERGENCY MESSAGE | | | | |
|-------------------|--------|--------|--------|--------|
| BYTE 0 | BYTE 1 | BYTE 2 | BYTE 3 | BYTE 4 |
| 0xFF10 | | 0x81 | MEF | |

With this MEF:

| MEF (Manufacturer-specific Error Field) for EEC 0xFF10 | | |
|--|-----------------------|--------------------------|
| BIT | DESCRIPTION | OBJECT FOR ERROR DETAILS |
| 15 | Disability ch1 | 0x2120 subindex 1 |
| 14 | Disability ch2 | 0x2120 subindex 2 |
| 13 | Disability ch3 | 0x2120 subindex 3 |
| 12 | NA | |
| 11 | Channel 1 saturation | |
| 10 | Channel 2 saturation | |
| 9 | Channel 3 saturation | |
| 8 | NA | |
| 7 | Communication error | 0x2121 subindex 1 |
| 6 | Channels global error | |
| 5..0 | NA | |

For “voltage error”, the emergency message is:

| EMERGENCY MESSAGE | | | | |
|-------------------|--------|--------|---------------|--------|
| BYTE 0 | BYTE 1 | BYTE 2 | BYTE 3 | BYTE 4 |
| 0xFF10 | | 0x85 | Object 0x2100 | |

For a “timeout command” or “error command”, the emergency message is:

| EMERGENCY MESSAGE | | | | | |
|-------------------|--------|--------|------------|----------------------------------|--------|
| BYTE 0 | BYTE 1 | BYTE 2 | BYTE 3 | BYTE 4 | BYTE 5 |
| 0xFF11 | | 0x81 | Channel ID | Object 0x2103 subindex channelID | |

Where the meaning of CHANNEL ID is:

| CHANNEL ID | |
|------------|-------------|
| CHANNEL ID | DESCRIPTION |
| 0x01 | Channel 1-2 |
| 0x02 | Channel 3-4 |
| 0x03 | Channel 5-6 |
| 0x04 | Channel 7-8 |

For “CPU ERROR” the Emergency message will be:

| EMERGENCY MESSAGE | | | | | | |
|-------------------|--------|--------|---------------|--------|--------|--------|
| BYTE 0 | BYTE 1 | BYTE 2 | BYTE 3 | BYTE 4 | BYTE 5 | BYTE 6 |
| 0xFF20 | | 0x81 | Object 0x1002 | | | |

| EEC | |
|--------|----------------------------------|
| CODE | DESCRIPTION |
| 0x0000 | No error |
| 0x1000 | Generic error |
| 0x4201 | CPU temperature over T_HIGH_HIGH |
| 0x4202 | CPU temperature over T_HIGH |
| 0x4203 | CPU temperature under T_LOW |
| 0x8110 | Communication Can Overrun |
| 0x8120 | Error passive |
| 0x8130 | Life Guard error |
| 0x8140 | Recovered from bus off |
| 0xFF10 | General input channels error |
| 0xFF11 | Command for input channel error |
| 0xFF20 | CPU error |

| ER | | | | | | | |
|---------|-------|---------|-------------|---------------|-------|-------|-------------|
| BIT 7 | BIT 6 | BIT 5 | BIT 4 | BIT 3 | BIT 2 | BIT 1 | BIT 0 |
| Generic | 0 | Voltage | temperature | communication | 0 | 0 | Manufacture |

Where bit equal to “0” means “no error”.

Object 0x1002: manufacturer status register

Object 0x1002 is the CPU status.

| OBJECT 1002 | |
|--------------------|----------------------|
| BIT | DESCRIPTION |
| 31..10 | NA |
| 9 | Good data value |
| 8 | Precision data value |
| 7..1 | NA |
| 0 | Flash CRC ERROR |

Object 0x1006: communication window lenght

| OBJECT 1006 | |
|---------------------|---------------------|
| MIN VAL [ms] | MAX VAL [ms] |
| 10 | 10000 |

Object 0x1007: synchronous window lenght

| OBJECT 1007 | |
|---------------------|---------------------|
| MIN VAL [ms] | MAX VAL [ms] |
| 2 | 2000 |

CANOpen manufacturer specific profile

If dip-switches are in “from memory” mode, the node address is selectable by **Object 0x2001**.

| NODE ADDRESS (Object 0x2001) | |
|-------------------------------------|--------------------|
| Object value | Description |
| 0..127 | Node address |

If dip-switches are in “from memory” mode, the baud rate is selectable by **Object 0x2002**.

| BAUDRATE (Object 0x2002) | |
|---------------------------------|--------------------|
| Object value | Description |
| 1 | 20 kbit/s |
| 2 | 50 kbit/s |
| 3 | 125 kbit/s |
| 4 | 250 kbit/s |
| 5 | 500 kbit/s |
| 6 | 800 kbit/s |
| 7 | 1 Mbit/s |

Object 0x2030 can be used to monitor the CPU temperature.

| CPU TEMPERATURE (Object 0x2030) | |
|--|---|
| Subindex | Description |
| 1 | Actual temperature [°C/10] |
| 2 | Temperature for HOT STOP ERROR [°C/10] 95.0°C |
| 3 | Temperature for HOT ERROR [°C/10] 90.0°C |
| 4 | Temperature for COLD ERROR [°C/10] -25.0°C |

The HOT STOP temperature sends in pre-operational the station.

The HOT ERROR and the COLD ERROR temperature sends the Emergency Object.

The Object is Read Only.

Object 0x2100 contains the channel status:

| CHANNEL STATUS (Object 0x2100) | |
|---------------------------------------|------------------------------|
| Command code | Description |
| 15 | Channel 1 disable |
| 14 | Channel 2 disable |
| 13 | Channel 3 disable |
| 12 | NA |
| 11 | Channel 1 saturation |
| 10 | Channel 2 saturation |
| 9 | Channel 3 saturation |
| 8 | NA |
| 7 | Channels communication error |
| 6 | Channels fail |
| 5..0 | NA |

Object 0x2106 contains the channel configuration:

| CHANNEL CONFIGURATION (Object 0x2106) | |
|--|---|
| Subindex | Description |
| 1 | Channel 1 enable (0=disable, 1=enable) |
| 2 | Channel 2 enable (0=disable, 1=enable) |
| 3 | Channel 3 enable (0=disable, 1=enable) |
| 4 | Channel 1 mode (0=voltage, 1=current) |
| 5 | Channel 2 mode (0=voltage, 1=current) |
| 6 | Channel 3 mode (0=voltage, 1=current) |
| 7 | Channel 1 fault action (0=last good, 1=load preset) |
| 8 | Channel 2 fault action (0=last good, 1=load preset) |
| 9 | Channel 3 fault action (0=last good, 1=load preset) |

Integer scale process

Integer input objects can be scaled by a BEGIN (referred to 0 mV or 0 µA) for a 0 integer value and a END (referred to 10000mV or 20000 µA) for a 10000 integer value.

The formula is: $Out = BGN + ((END - BGN) / 10000) * VAL$

Begin for integer scale

The object sets the customization of the associated mV or μ A output value to the 0 integer value.

| 0x2600 | |
|----------|--|
| Subindex | Description |
| 1 | Begin value for channel 1 [mV] or [μ A] |
| 2 | Begin value for channel 2 [mV] or [μ A] |
| 3 | Begin value for channel 3 [mV] or [μ A] |

End for integer scale

The object sets the customization of the associated mV or μ A output value to the 10000 integer value.

| 0x2601 | |
|----------|--|
| Subindex | Description |
| 1 | End value for channel 1 [mV] or [μ A] |
| 2 | End value for channel 2 [mV] or [μ A] |
| 3 | End value for channel 3 [mV] or [μ A] |

DIP-SWITCH configuration

| BAUD-RATE (Dip-Switches: SW1) | | | | | | | |
|-------------------------------|---|---|---|---|---|----|---|
| 1 | 2 | 3 | Meaning | | | | |
| | | | Only Baud-Rate is acquired from memory(EEPROM) | | | | |
| | | ● | 20 kbps | | | | |
| | ● | | 50 kbps | | | | |
| | ● | ● | 125 kbps | | | | |
| ● | | | 250 kbps | | | | |
| ● | | ● | 500 kbps | | | | |
| ● | ● | | 800 kbps | | | | |
| ● | ● | ● | 1 Mbps | | | | |
| ADDRESS (Dip-Switches: SW1) | | | | | | | |
| 4 | 5 | 6 | 7 | 8 | 9 | 10 | Meaning |
| | | | | | | | Only address is acquired from memory(EEPROM) |
| | | | | | | ● | Address=1 |
| | | | | | ● | | Address=2 |
| | | | | | ● | ● | Address=3 |
| | | | | ● | | | Address=4 |
| | | | | ● | | ● | Address=5 |
| X | X | X | X | X | X | X | |
| ● | ● | ● | ● | ● | ● | ● | Address=127 |

CANOpen LED description

| SERVICE (DIAGNOSTIC) LED DESCRIPTION | | |
|--------------------------------------|----------------|--|
| LED | LED status | Meaning |
| RUN | Blinking light | Pre-operational mode |
| | Single flash | Stop mode |
| | ON | Operational mode |
| ERROR | Single flash | At least one error counter has reached or exceed the warning level |
| | Double flash | Guard event |
| | Triple flash | The SYNC has not received within the configured communication cycle timeout period |
| | ON | The CAN controller is bus off |
| | OFF | No error |
| FAIL | Blinking | Data receiving from RS232 |
| | ON | At least one channel is in error mode |
| POWER | ON | Power supply |

Object for analog data

Object 0x6411 contains the ± 10000 values for channel 1..3 (in agreement with objects 0x2600, 0x2601 and 0x2106) (± 10000 for voltage mode, 0..10000 for current mode).

| OUTPUT VALUE (Object 0x6411) | |
|------------------------------|------------------------------------|
| Subindex | Description |
| 1 | Channel 1 ± 10000 output value |
| 2 | Channel 2 ± 10000 output value |
| 3 | Channel 3 ± 10000 output value |

Object 0x6443 contains the fault mode for outputs.

If FAULT MODE=0 Hold last value

If FAULT MODE=1 Load object 0x6444 value


| FAULT OUTPUT MODE (Object 0x6443) | |
|-----------------------------------|----------------------|
| Subindex | Description |
| 1 | Channel 1 fault mode |
| 2 | Channel 2 fault mode |
| 3 | Channel 3 fault mode |

Object 0x6444 contains the ± 10000 values for channels 1..3 to load in case of fault (± 10000 for voltage mode, 0..10000 for current mode).

| FAULT OUTPUT VALUE (Object 0x6444) | |
|------------------------------------|------------------------------|
| Subindex | Description |
| 1 | Channel 1 fault output value |
| 2 | Channel 2 fault output value |
| 3 | Channel 3 fault output value |

CANOpen functional diagram

counter mode ON (subindex 1 Object 0x6003="0")



CANOpen Object dictionary

COMMUNICATION PROFILE AREA

| INDEX | SUB INDEX | NAME | DESCRIPTION | TYPE | ACCESS | DEFAULT |
|--------|-----------|--|--|----------------|--------|------------|
| 0x1000 | 0 | Device type | Profile 401=0x191 | UNSIGNED 32 | RO | 0x00080191 |
| 0x1001 | 0 | Error register | Error register (DS401) | UNSIGNED 8 | RO | 0 |
| 0x1002 | 0 | Manufacturer Status register | Status register | UNSIGNED 32 | RO | 0 |
| 0x1005 | 0 | SYNC COB-ID | The device consumes the SYNC message | UNSIGNED 32 | RW | 0x00000080 |
| 0x1006 | 0 | Comm. window lenght | Sync interval [us] | UNSIGNED 32 | RW | 0 |
| 0x1007 | 0 | Synchronous window lenght | The window [us] for the PDO transmission after the SYNC | UNSIGNED 32 | RW | 0 |
| 0x1008 | 0 | Manufacturer Device name | Device name | VISIBLE STRING | RO | "ZC-3AO" |
| 0x1009 | 0 | Manufacturer HW version | Hardware version | VISIBLE STRING | RO | "SC000000" |
| 0x100A | 0 | Manufacturer SW version | Software version | VISIBLE STRING | RO | "SW001150" |
| 0x100C | 0 | Guard Time | [ms] | UNSIGNED 16 | RW | 0 |
| 0x100D | 0 | Life time factor | Max delay between two guarding telegrams= Guard_Time· Life_Time_Factor | UNSIGNED 8 | RW | 0 |
| 0x1010 | 0 | Store parameters/ number of mapped object | Max subindex number | UNSIGNED 8 | RO | 5 |
| | 1 | Save all parameters | Store not volatile parameters (write in ASCII "save" for store process MSB 0x65766173 LSB) | UNSIGNED 32 | RW | 1 |
| | 2 | Save communication parameters | Store not volatile parameters (write in ASCII "save" for store process MSB 0x65766173 LSB) | UNSIGNED 32 | RW | 1 |
| | 3 | Save application parameters | Store not volatile parameters (write in ASCII "save" for store process MSB 0x65766173 LSB) | UNSIGNED 32 | RW | 1 |
| | 4 | Save manufacturer parameters | Store not volatile parameters (write in ASCII "save" for store process MSB 0x65766173 LSB) | UNSIGNED 32 | RW | 1 |
| | 5 | Save slave parameters | Store not volatile parameters (write in ASCII "save" for store process MSB 0x65766173 LSB) | UNSIGNED 32 | RW | 1 |

| | | | | | | |
|--------|---|---|--|-------------|----|--------------------|
| | | | | | | |
| 0x1011 | 0 | Restore default/ number of mapped object | Max subindex number | UNSIGNED 8 | RO | 5 |
| | 1 | Restore all parameters | Restore not volatile parameters (write in ASCII "load" for store process MSB 0x64616F6C LSB) | UNSIGNED 32 | RW | 0 |
| | 2 | Restore communication parameters | Restore not volatile parameters (write in ASCII "load" for store process MSB 0x64616F6C LSB) | UNSIGNED 32 | RW | 0 |
| | 3 | Restore application parameters | Restore not volatile parameters (write in ASCII "load" for store process MSB 0x64616F6C LSB) | UNSIGNED 32 | RW | 0 |
| | 4 | Restore Manufacturer parameters | Restore not volatile parameters (write in ASCII "load" for store process MSB 0x64616F6C LSB) | UNSIGNED 32 | RW | 0 |
| | 5 | Restore slave parameters | Restore not volatile parameters (write in ASCII "load" for store process MSB 0x64616F6C LSB) | UNSIGNED 32 | RW | 0 |
| 0x1014 | 0 | COB-ID emergency Object | | UNSIGNED 32 | RO | \$NODEID+ 0x80 |
| 0x1017 | 0 | Heartbeat producer time | Time (ms) 0x0000=there is not heartbeat service | UNSIGNED 16 | RW | 0 |
| 0x1018 | 0 | Identity object/ number of mapped object | Max subindex number | UNSIGNED 8 | RO | 4 |
| | 1 | Vendor ID | Seneca srl | UNSIGNED 32 | RO | 0x00000249 |
| | 2 | Product code | ZC-3AO Machine ID Code | UNSIGNED 32 | RO | 0x0000001E |
| | 3 | Revision number | | UNSIGNED 32 | RO | 0 |
| | 4 | Serial number | | UNSIGNED 32 | RO | 0 |
| 0x1200 | 0 | 1 st SDO port/ number of mapped object | Max subindex number | UNSIGNED 8 | RO | 2 |
| | 1 | COB-ID SDO Client-> Server | COB-ID of receive SDO | UNSIGNED 32 | RO | \$NODEID+ 0x600 |
| | 2 | COB-ID SDO Server-> Client | COB-ID of transmit SDO | UNSIGNED 32 | RO | \$NODEID+ 0x580 |
| 0x1400 | 0 | 1 st receive PDO parameter/ | Max subindex number | UNSIGNED 8 | RO | 2 |

| | | | | | | |
|--------|---|--|--|-------------|----|---|
| | | number of mapped object | | | | |
| | 1 | COB-ID used by PDO | COB-ID of TxPDO1 | UNSIGNED 32 | RO | \$NODEID+ 0x200 |
| | 2 | Transmission type | | UNSIGNED 8 | RO | 255 |
| 0x1401 | 0 | 2nd receive PDO parameters /number of mapped object | Max subindex number | UNSIGNED 8 | RO | 3 |
| | 1 | COB-ID used by PDO | | UNSIGNED 32 | RW | \$NODEID+ 0x300 |
| | 2 | Transmission type | Transmission type forTxPDO2 0x00=synchronous- acyclic 0x01 to 0xF0 =synchronous- cyclic 0xFF=asynchronous | UNSIGNED 8 | RW | 0xFF |
| | 3 | Inhibit time | | UNSIGNED 16 | RW | 0x00 |
| 0x1600 | 0 | 1 st receive PDO mapping parameter/ number of mapped object | Max subindex number | UNSIGNED 8 | RO | 0 |
| 0x1601 | 0 | 2 nd receive PDO mapping parameter | Max subindex number | UNSIGNED 8 | RW | 3 |
| | 1 | 1 st object to be mapped | First object (default: channel 1, ±10000 output) | UNSIGNED 32 | RW | 0x64110110 Object=0x6411 Subindex=1 Length=16bit |
| | 2 | 2nd object to be mapped | Second object (default: channel 2, ±10000 output) | UNSIGNED 32 | RW | 0x64110210 Object=0x6411 Subindex=2 Length=16bit |
| | 3 | 3rd object to be mapped | Third object (default: channel 3, ±10000 output) | UNSIGNED 32 | RW | 0x64110310 Object=0x6411 Subindex=3 Length=16bit |

MANUFACTURER PROFILE AREA

| INDEX | SUB INDEX | NAME | DESCRIPTION | TYPE | ACCESS | DEFAULT |
|--------|-----------|----------------|---|------------|--------|----------|
| 0x2001 | 0 | Module address | Station address (only if dip switch 4,5,6,7,8,9,10 are OFF) | UNSIGNED 8 | RW | 0x7F=127 |
| 0x2002 | 0 | Baudrate | Station Baudrate (only if dip switch 1,2,3 are OFF) 1=20kbps 2=50kbps 3=125kbps 4=250kbps 5=500kbps 6=800kbps | UNSIGNED 8 | RW | 0x01 |

| | | | | | | |
|--------|---|---|--|-------------|----|-------|
| | | | 7=1Mbps | | | |
| 0x2003 | 0 | Master firmware code | | UNSIGNED 16 | RO | 1152 |
| 0x2030 | 0 | Device temperature/ number of parameters | Max subindex number | UNSIGNED 8 | RO | 4 |
| | 1 | Internal temperature | Station internal temperature [°C/10] | INTEGER 16 | RO | 0 |
| | 2 | Hi Hi temperature | Critical hot temperature (all operations stop) [°C/10] | INTEGER 16 | RO | 950 |
| | 3 | Hi temperature | Warning for too hot temperature [°C/10] | INTEGER 16 | RO | 900 |
| | 4 | Low temperature | Critical low temperature (all operations stop) [°C/10] | INTEGER 16 | RO | -250 |
| 0x2106 | 0 | Channel configuration/ number of parameters | Max subindex number | UNSIGNED 8 | RO | 6 |
| | 1 | Channel 1 enable | 0=disable 1=enable | UNSIGNED 8 | RW | 1 |
| | 2 | Channel 2 enable | 0=disable 1=enable | UNSIGNED 8 | RW | 1 |
| | 3 | Channel 3 enable | 0=disable 1=enable | UNSIGNED 8 | RW | 1 |
| | 4 | Channel 1 mode | 0=voltage 1=current | UNSIGNED 8 | RW | 0 |
| | 5 | Channel 2 mode | 0=voltage 1=current | UNSIGNED 8 | RW | 0 |
| | 6 | Channel 3 mode | 0=voltage 1=current | UNSIGNED 8 | RW | 0 |
| 0x2600 | 0 | Begin integer scale/ number of parameters | Max subindex number | UNSIGNED 8 | RO | 3 |
| | 1 | Begin scale CH1 | Begin scale [mV] or [μA] | INTEGER 16 | RW | 0 |
| | 2 | Begin scale CH2 | Begin scale [mV] or [μA] | INTEGER 16 | RW | 0 |
| | 3 | Begin scale CH3 | Begin scale [mV] or [μA] | INTEGER 16 | RW | 0 |
| 0x2601 | 0 | End integer scale | Max subindex number | UNSIGNED 8 | RO | 3 |
| | 1 | End scale CH1 | End scale [mV] or [μA] | INTEGER 16 | RW | 10000 |
| | 2 | End scale CH2 | End scale [mV] or [μA] | INTEGER 16 | RW | 10000 |

| | 3 | End scale CH3 | End scale [mV] or [μA] | INTEGER 16 | RW | 10000 |
|------------------------------|-----------|---|---|------------|--------|---------|
| STANDARD DEVICE PROFILE AREA | | | | | | |
| INDEX | SUB INDEX | NAME | DESCRIPTION | TYPE | ACCESS | DEFAULT |
| 0x6411 | 0 | ±10000 Output/ number of output | Max subindex number | UNSIGNED 8 | RO | 3 |
| | 1 | Output 1h | Channel 1 value ±10000 (from 0 to 10000 for current) | INTEGER 16 | RW | 0 |
| | 2 | Output 2h | Channel 2 value ±10000 (from 0 to 10000 for current) | INTEGER 16 | RW | 0 |
| | 3 | Output 3h | Channel 3 value ±10000 (from 0 to 10000 for current) | INTEGER 16 | RW | 0 |
| 0x6443 | 0 | Error mode output/ number of output | Max subindex number | UNSIGNED 8 | RO | 3 |
| | 1 | Error mode output 1 | 0=keep last 1=load object 0x6444 | UNSIGNED 8 | RW | 0 |
| | 2 | Error mode output 2 | 0=keep last 1=load object 0x6444 | UNSIGNED 8 | RW | 0 |
| | 3 | Error mode output 3 | 0=keep last 1=load object 0x6444 | UNSIGNED 8 | RW | 0 |
| 0x6444 | 0 | Error value output/ number of error value | Max subindex number | UNSIGNED 8 | RO | 3 |
| | 1 | Error value output 1 | Channel 1 integer analogue interrupt upper limit value [mV] or [μA] | INTEGER 16 | RW | 0 |
| | 2 | Error value output 2 | Channel 2 integer analogue interrupt upper limit value [mV] or [μA] | INTEGER 16 | RW | 0 |
| | 3 | Error value output 3 | Channel 3 integer analogue interrupt upper limit value [mV] or [μA] | INTEGER 16 | RW | 0 |

Easy-SETUP

To configure the Seneca Z-PC Line modules, it is possible to use Easy-SETUP software, free-downloadable from the www.seneca.it; the configuration can be performed by RS232 or RS485 bus communication.