

USER MANUAL

Z-GPRS3

Z-UMTS

Z-LOGGER3

Multi-protocol Datalogger, RTU, with ethernet, modem 2G/3G and embedded I/O

SENECA s.r.l.

Via Austria 26, PADOVA – ITALY

Tel. +39.049.8705355 – 8705359 Fax. +39.049.8706287

Web site: www.seneca.it

Customer service: supporto@seneca.it (IT), support@seneca.it (Other)

Commercial information: commerciale@seneca.it (IT), sales@seneca.it (Other)



This document is property of SENECA srl. Duplication and reproduction of its are forbidden (though partial), if not authorized. Contents of present documentation refers to products and technologies described in it. Though we strive for reach perfection continually, all technical data contained in this document may be modified or added due to technical and commercial needs; it's impossible eliminate mismatches and discordances completely. Contents of present documentation is anyhow subjected to periodical revision. If you have any questions don't hesitate to contact our structure or to write us to e-mail addresses as above mentioned.

MI004460_111_EN

Date	Version	Changes
21/07/2016	1.02	Added SEAL configuration and program Update from webserver. Updated Firmware Update procedure.
29/07/2016	1.03	Deleted the GET DOUT SMS commands
06/09/2016	1.04	Added UPS off mode (from Firmware version 2.2). Added Cloudbox Support.
08/09/2016	1.05	Added SMS commands for read/write extended variables
13/12/2016	1.06	Added Z-UMTS and Z-LOGGER3 Updated the Download FW and Download SETUP SMS commands Added Modbus RTU Slave Added Log on Trigger(s) Added info on UPS
01/02/2017	1.07	Fixed lower Supply voltage limit for Z-UMTS product
20/04/2017	1.08	Added Revision FW Registers Fix DOUT2 Commands (Supported commands from Modbus) Added new “Emergency Mode” function (from firmware 1.2.1 Z-UMTS, 2.4.2 Z-GPRS3/Z-LOGGER3)
11/05/2017	1.09	Added info about Internal Flash log Size
29/06/2017	1.10	Changed reference to Chrome browser Changed default IP address from 192.168.90.101 to 192.168.1.101 Added Chapter Z-GPRS3 consumption estimate for use with solar panels
06/07/2017	1.11	Fixed Modbus command value for “DOWNLOAD AND UPDATE PHONEBOOK FROM FTP SERVER”

Table of Contents

SENECA Z-GPRS3, Z-UMTS, Z-LOGGER3	7
PRELIMINARY INFORMATION.....	7
1. CHARACTERISTICS	9
1.1. RTU Models characteristics	9
1.2. Digital Inputs.....	11
1.3. Digital outputs	11
1.4. Analog Inputs.....	11
1.5. Communication Ports.....	12
1.6. Storage units.....	12
1.7. Power supply	12
1.8. Regulations	12
1.9. Case specifications	13
1.10. Insulation.....	13
2. CONNECTIONS.....	14
2.1. Power supply connections	14
2.2. Analog input connections.....	14
2.3. Auxiliary voltage connections	14
2.4. Serial communication RS485/RS232 ports connections.....	15
2.5. Digital outputs connections	15
2.6. Digital inputs connections.....	16
3. SIGNAL LEADS	17

3.1.	Z-GPRS3 leds	17
3.2.	Z-UMTS leds	18
3.3.	Z-LOGGER3 leds	19
4.	DEVICES OVERVIEW	20
5.	SWITCH ON, AND SWITCH OFF THE RTU	21
6.	SUPPORTED SIM CARDS (ONLY Z-GPRS3 / Z-UMTS).....	21
7.	GSM SIGNAL (ONLY Z-GPRS3 / Z-UMTS)	23
8.	INTERNAL UPS.....	24
9.	ADDRESS BOOK.....	25
9.1.	SENDING A SMS COMMAND USING THE PASSWORD (ONLY Z-GPRS3 / Z-UMTS)	26
9.2.	MICROSD CARD PHONE BOOK (ONLY Z-GPRS3 / Z-UMTS).....	26
10.	ACQUIRING AND SENDING LOG DATA.....	27
10.1.	THE EVENT LOGGER	27
10.1.1.	Sending event logger file to an FTP server.....	28
10.1.2.	Sending event logger file to an EMAIL server	29
10.1.3.	Saving event logger file to the microSD card	31
10.2.	THE DATA LOGGER AND THE DATA LOGGER ON TRIGGER	31
10.2.1.	Sending data logger file to a FTP server.....	32
10.2.2.	Sending data logger and data logger on trigger data to an E-MAIL server	33
10.2.1.	Sending data logger and data logger on trigger data to an HTTP server	35
10.2.2.	Saving data logger data to the microSD card.....	36
12.	ACTIONS AND MESSAGES.....	37
12.1.	ACTIONS.....	37
12.2.	TEXT AND AUDIO MESSAGES	37
13.	SENDING AUDIO (DTMF) COMMANDS TO Z-GPRS3 AND Z-UMTS.....	38
14.	THE WEBSERVER.....	38
14.1.	MAINTENANCE WEBSERVER	39

14.2.	CUSTOM WEBSERVER	40
15.	SEAL (SENECA ADVANCED LANGUAGE)	42
16.	FIRMWARE UPDATE.....	43
16.1.	Firmware update by Webservice	43
16.2.	Firmware update by microSD card	44
17.	SEAL PROGRAM AND SEAL CONFIGURATION REMOTE UPDATE	44
17.1.	SEAL PROGRAM AND SEAL CONFIGURATION UPDATE FROM WEBSERVER	44
17.2.	UPLOAD A PROJECT BACKUP TO THE RTU	45
18.	MODBUS TCP-IP SERVER AND MODBUS RTU SLAVE.....	46
18.1.	MODBUS ADDRESSES TABLE	47
18.2.	SUPPORTED COMMANDS FROM MODBUS	49
19.	SUPPORTED SMS COMMANDS (Z-GPRS3 AND Z-UMTS ONLY)	51
19.1.	Set the Telephone Sms Character Alphabet	51
19.2.	List of Supported Sms Commands	52
20.	EMERGENCY MODE	58
21.	Z-GPRS3 POWER ESTIMATE FOR USE WITH SOLAR PANELS.....	58
22.	TROUBLESHOOTING.....	59

Seneca Z-GPRS3, Z-UMTS, Z-LOGGER3

PRELIMINARY INFORMATION

CAUTION!

Contact your telephone provider for information on GSM and GPRS service costs. It is best to quantify log and SMS costs before setting up and installing Z-GPRS3, Z-UMTS OR Z-LOGGER3.

The use of Z-GPRS3 and Z-UMTS in data roaming (for example, abroad with an Italian SIM card) may generate unexpected costs. Contact your telephone provider for further information.

IN NO CASE MAY SENECA OR ITS SUPPLIERS BE HELD LIABLE FOR ANY INCOMING DATA OR PROFIT LOSSES DUE TO INDIRECT, CONSEQUENTIAL OR INCIDENTAL CAUSES (INCLUDING NEGLIGENCE) CONNECTED WITH THE USE OR INABILITY TO USE Z-GPRS3, Z-UMTS OR Z-LOGGER3, EVEN IF SENECA WAS INFORMED OF THE POTENTIAL OF THESE DAMAGES.

SENECA, ITS SUBSIDIARIES OR AFFILIATES OR GROUP PARTNERS OR DISTRIBUTORS AND SENECA DEALERS DO NOT GUARANTEE THAT THE FUNCTIONS FAITHFULLY MEET THE EXPECTATIONS AND THAT Z-GPRS3, Z-UMTS, Z-LOGGER3, THEIR FIRMWARE AND SOFTWARE ARE FREE OF ERRORS OR FUNCTION UNINTERRUPTEDLY.

SENECA HAS TAKEN THE UTMOST CARE AND CAUTION IN DRAFTING THIS MANUAL. HOWEVER, IT MAY CONTAIN ERRORS OR OMISSIONS. SENECA SRL RESERVES THE RIGHT TO MODIFY AND/OR VARY PARTS OF THIS MANUAL TO CORRECT ERRORS OR TO ADJUST TO PRODUCT FEATURE CHANGES WITHOUT ANY PRIOR NOTICE.

CAUTION!

-Contact your telephone service provider for GSM and GPRS service costs especially when using Z-GPRS3 and Z-UMTS with a sim issued by a country other than the one in which it is used (international roaming).

-It is best to estimate telephone costs before setting up Z-GPRS3 and Z-UMTS.

-The cost of each SMS is set by the telephone service provider.

-Internet send/receive costs can be tied to Kbytes sent/received, a monthly ceiling included in a package or internet connection time. Contact your telephone service provider for further information.

-For internet connections whose costs is associated with connection time, please remember that communications are active for an amount of time that depends on the number of log rows to be sent. Typically, a 2 Kbyte data log takes about 10-15 seconds (in GPRS mode) to be sent in addition to the time necessary to establish the connection (from 5 to 30 seconds) and the time due to any server login attempts.

-When use PPP the internet connection is ALWAYS ON

-Check the data quantity sent via internet and SMS before using Z-GPRS3 and Z-UMTS.

Please remember that mobile phone service providers also consider the entire communication that permits file transmission (and thus data transmission overhead, the number of connection attempts, etc.) and not just the dimensions as data traffic in each transaction.

1. CHARACTERISTICS

1.1. RTU Models characteristics

- *Supply voltage (Z-GPRS3 and Z-LOGGER3) 11..40 Vdc; 19..28 Vac max 6.5 W*
Supply voltage (Z-UMTS) 19..40 Vdc; 19..28 Vac max 6.5 W
- *Internal UPS for up to 1h works without external power*
- **MODEM:**
 - Z-Logger3:** *No modem*
 - Z-GPRS3:** *GSM/GPRS quad-band 850/900/1800/1900 MHz*
DL max: 85.6 Kbps, UL max: 42.8 Kbps
Coding scheme CS-1, CS-2, CS-3, CS-4
Class 4 (2W) at GSM 850 and EGSM 900
Class 2 (1W) at DCS 1800 and PCS 1900
GPRS multi slot class 10
 - Z-UMTS:** *HSPA+/UMTS dual-band 900/2100 MHz (standard)*
HSPA+/UMTS tri-band 850/1900/2100 MHz (optional)
GSM/GPRS/EDGE quad-band 850/900/1800/1900 MHz
GPRS: UL 85.6 kbit/s; DL 85.6 kbit/s
EDGE: UL 236.8 kbit/s; DL 236.8 kbit/s
WCDMA PS: UL 384 kbit/s; DL 384 kbit/s
HSPA+: UL 5.76 Mbit/s; DL 21.6 Mbit/s
- *500 Vac insulation between remaining circuit power*
- *Quick installation on DIN 46277 guide*
- *Status indication LED*
- *NR 4 digital inputs (PNP/NPN programmable)*
- *NR 2 16-bit voltage/current programmable analog inputs*
- *NR 2 relay digital outputs*
- *10/100 Mbps frontal Ethernet RJ45*
- *NR 1 RS232 or RS484 port*
- *NR 1 RS485 port*
- *1 microUSB port for settings*
- *MicroSD support (microSD or microSDHC max 32 Gb)*
- *NR4 32 bits max 30 Hz totalizers*
- *NR4 32 bits max 30 Hz resettable counters*
- *Possibility of expanding the number of I/O via Modbus TCP-IP or Modbus RTU*
- *Maximum number of channels on datalogger: 133 (of which 100 via Modbus RTU or Modbus TCP-IP)*
- *Supported system protocols via GSM: SMS, audio voice calls (also with zero cost command)*

- *Supported system protocols via 2G/3G or Ethernet: FTP client, SMTP client, ModBUS TCP-IP Server, ModBUS TCP-IP Client, Webserver, HTTP Rest, Custom Webserver (Web pages in Sd card)*
- *Protocol on RS485/RS232: Modbus RTU Master/Slave*
- *Memory expansion up to 32 GigaBytes with micro SD*
- *32 bits ARM processor*
- *Real Time multitasking operating system*
- *Firmware update via USB / microSD/ Webserver or by remote connection*

1.2. Digital Inputs

Channels number	4
Input type	PNP, NPN configurable.
Voltage supply	12 Vdc
Current supply	20 mA
Maximum frequency	30 Hz
Current consumption	3 mA

1.3. Digital outputs

Channels number	2
Output type	Relay
Maximum Voltage	250 Vac
Maximum Current	2 A

1.4. Analog Inputs

Channels number	2
Input type	Current / Voltage configurable
Voltage input	0..30V accuracy 0,1% FS
Current input	0..20 mA accuracy 0,1% FS
Input protection	yes, 12Vdc or 25mA
Resolution	16 bit

1.5. Communication Ports

RS 485 #1	Port #1, on IDC10 connector
RS 485 or RS232 #2	Port #2, terminals M10/M11/M12
Ethernet	10/100 Mbit, RJ45 with autoswitch
USB micro B	Micro B

1.6. Storage units

Internal Flash	8 Mbytes for configuration, datalogger and firmware update
MicroSD	microSD and microSDHC, max 32 GB (supplied with 4 GBytes* microSD) *= This value can be changed

1.7. Power supply

Voltage	11...40 Vdc; 19...28 Vac (Z-GPRS3 / Z-LOGGER3) 19..24 Vdc; 19...28 Vac (Z-UMTS)
Power consumption	6,5 W
Protection rating	IP20

1.8. Regulations


EN61000-6-4/2002-10	Electromagnetic emission, industrial environment.
----------------------------	--

EN61000-6-2/2006-10	Electromagnetic immunity, industrial environment.
EN 301 511 (only Z-GPRS3, Z-UMTS)	Harmonized standard for mobile stations in the GSM 900 and 1800 bands.
EN 301 489-1 (only Z-GPRS3, Z-UMTS)	ElectroMagnetic Compatibility standard for radio equipment and services.
EN 301 489-7 (only Z-GPRS3, Z-UMTS)	Specific (EMC) conditions for mobile radio equipment (GSM 900 and 1800).
EN 60950	Safety of information Technology Equipment.

1.9. Case specifications

Dimensions and weight	100 x 111 x 35 mm, 280 g
Material	Black PBT


1.10. Insulation



2. CONNECTIONS

2.1. Power supply connections


You can supply DC or AC power to terminals 2-3, in the case of DC power supply is not necessary to distinguish between the "+" from the "-" cable:



2.2. Analog input connections


The analog input 1 voltage / current is connected to terminal 4 (- sign for the voltage, the current exit) and 6 (+ sign to the voltage, the current incoming).

The analog input 2 voltage / current is connected to terminal 4 (- sign for the voltage, the current exit) and 5 (+ sign to the voltage, the current incoming).



2.3. Auxiliary voltage connections

The device can provide from 12 to 15 VDC (max 40mA) to an external sensor connected to terminals 1 (+) and 4 (-):




2.4. Serial communication RS485/RS232 ports connections

The RS485 port # 1 is connected to the bottom connector "IDC10" for connecting to the Z-BUS Seneca.

The Serial #2 port is connected to terminal 10-11-12, can be configured in RS232 or RS485 mode.

SW2 = ON Configure PORT#2 as RS232

SW2 = OFF Configure PORT#2 as RS485



10 = RS485#2 GND / RS232 GND

11 = RS485#2 A / RS232 RX

12 = RS485#2 B / RS232 TX

2.5. Digital outputs connections


The output relay is connected between terminals 19-20-21:



19 = Normally open relay #1

21 = Shared relay #1

22 = Normally close relay #1



22 = Normally open relay #2


23 = Shared relay #2

24 = Normally close relay #2

2.6. Digital inputs connections


It's possible to provide power to an external sensor by terminals 15-16 (max 40mA) .

The inputs can be configured in NPN or PNP mode, see below:




3. SIGNAL LEDS

3.1. Z-GPRS3 leds



LED	Color	Status	LEDs Meaning
DO1	Red	ON	Digital output 1, relay energized
		OFF	Digital output 1, relay de-energized
DO2	Red	ON	Digital output 2, relay energized
		OFF	Digital output 2, relay de-energized
485 ACT	Green	Slow blinking 2.8 sec ON ■ 0.4 sec OFF □	■■■■■■■■■■□□ RS485 activity or RS232 activity
		OFF □	RS485 or RS232 serial interface not used
		Fast blinking 0.2 sec ON ■ 0.2 sec OFF □	■□■□■□■□■□■□■□ Timeout on RS485 or RS232 communication
		OFF □	Modem GPRS OFF
GSM	Yellow	OFF □	Modem GPRS OFF
		Slow blinking	Connected to the GSM network
		Medium blinking	Searching the GSM or GPRS network
		Fast blinking	Connected to the GPRS network
DI1	Red	ON (NPN)	Digital Input 1: Energized (closed contact to GND)
		ON (PNP)	Digital Input 1: Energized (closed contact to +12V)
		OFF	Digital Input 1: De-energized (open contact)
DI2	Red	ON (NPN)	Digital Input 2: Energized (closed contact to GND)
		ON (PNP)	Digital Input 2: Energized (closed contact to +12V)
		OFF	Digital Input 2: De-energized (open contact)
DI3	Red	ON (NPN)	Digital Input 3: Energized (closed contact to GND)
		ON (PNP)	Digital Input 3: Energized (closed contact to +12V)
		OFF	Digital Input 3: De-energized (open contact)
DI4	Red	ON (NPN)	Digital Input 4: Energized (closed contact to GND)
		ON (PNP)	Digital Input 4: Energized (closed contact to +12V)
		OFF	Digital Input 4: De-energized (open contact)
PWR/STS	Green	ON ■	Z-GPRS3 ON inactive log (status=ready)
		OFF □	Z-GPRS3 OFF
		Slow blinking 2.8 sec ON ■ 0.4 sec OFF □	■■■■■■■■■■□□ Z-GPRS3 active log (status=normal)
		Slow blinking 1.6 sec ON ■ 1.6 sec OFF □	■■■■■■□□□□□□□□ Battery powered inactive log (status=battery backup)
		Medium blinking 0.8 sec ON ■ 0.8 sec OFF □	■■■■□□□□■■■■□□□□ Low battery warning
		Fast blinking 0.2 sec ON ■ 0.2 sec OFF □	■□■□■□■□■□■□■□ Z-GPRS3 initializing or shutdown
		Fast blinking 0.2 sec ON ■ 0.2 sec OFF □	■□■□□□□□■□□□□□ Error, please refer to the diagnostic
		OFF □	SD card mounted in the right way
SD/STS	Red	OFF □	SD card not present
		Medium blinking 0.8 sec ON ■ 0.8 sec OFF □	■■■■□□□□■■■■□□□□ SD card activity
		Fast blinking 0.2 sec ON ■ 0.2 sec OFF □	■□■□■□■□■□■□■□ SD card error
		OFF □	SD card not present
ETH LNK	Green	Blinking	RJ45 connection activated
ETH TRF	Yellow	Blinking	Traffic on Ethernet port

3.2. Z-UMTS leds



LED SIGNALING ON FRONT PANEL		
LED	Status	LED's meaning
DI1 (Red)	ON (NPN)	Digital Input 1: Energized (GND closed contact)
	ON (PNP)	Digital Input 1: Energized (+12V closed contact)
	OFF	Digital Input 1: De-energized (open contact)
DI2 (Red)	ON (NPN)	Digital Input 2: Energized (GND closed contact)
	ON (PNP)	Digital Input 2: Energized (+12V closed contact)
	OFF	Digital Input 2: De-energized (open contact)
DI3 (Red)	ON (NPN)	Digital Input 3: Energized (GND closed contact)
	ON (PNP)	Digital Input 3: Energized (+12V closed contact)
	OFF	Digital Input 3: De-energized (open contact)
DI4 (Red)	ON (NPN)	Digital Input 4: Energized (GND closed contact)
	ON (PNP)	Digital Input 4: Energized (+12V closed contact)
	OFF	Digital Input 4: De-energized (open contact)
PWR/STS (Green)	ON ■	Z-UMTS ON inactive log (status=ready)
	Slow Blinking 2.8 sec ON 0.4 sec OFF	■■■■■■■■■■□□ Z-UMTS active log (status=normal)
	Slow Blinking 1.6 sec ON 1.6 sec OFF	■■■■■■□□□□□□□□ Battery powered inactive log (status=battery backup)
	Medium Blinking 0.8 sec ON 0.8 sec OFF	■■■■□□□□■■■■□□□□ Low battery warning
	Fast Blinking 0.2 sec ON 0.2 sec OFF	■□■□■□■□■□■□■□ Z-UMTS initializing or shutdown
	Fast Blinking 0.6 sec ■□■ 1 sec OFF	■□■□□□□■□□□□□□□ Error, please refer to the diagnostic
	OFF □	Z-UMTS OFF
SD/STS (Red)	ON ■	SD card mounted in the right way
	Medium Blinking 0.8 sec ON 0.8 sec OFF	■■■■□□□□■■■■□□□□ SD card activity
	Fast Blinking 0.2 sec ON 0.2 sec OFF	■□■□■□■□■□■□■□■□ SD card error
	OFF □	SD card not present
ETH LNK (Green)	Blinking	RJ45 connection activated
ETH TRF (Yellow)	Blinking	Traffic on Ethernet port

LED	Status	LED's meaning
DI1 (Red)	ON (NPN)	Digital Input 1: Energized (GND closed contact)
	ON (PNP)	Digital Input 1: Energized (+12V closed contact)
	OFF	Digital Input 1: De-energized (open contact)
DI2 (Red)	ON (NPN)	Digital Input 2: Energized (GND closed contact)
	ON (PNP)	Digital Input 2: Energized (+12V closed contact)
	OFF	Digital Input 2: De-energized (open contact)
DI3 (Red)	ON (NPN)	Digital Input 3: Energized (GND closed contact)
	ON (PNP)	Digital Input 3: Energized (+12V closed contact)
	OFF	Digital Input 3: De-energized (open contact)
DI4 (Red)	ON (NPN)	Digital Input 4: Energized (GND closed contact)
	ON (PNP)	Digital Input 4: Energized (+12V closed contact)
	OFF	Digital Input 4: De-energized (open contact)
PWR/STS (Green)	ON ■	Z-LOGGER3 ON inactive log (status=ready)
	Slow Blinking 2.8 sec ON 0.4 sec OFF	■■■■■■■■■■■■■■■■■■■■ Z-LOGGER3 active log (status=normal)
	Slow Blinking 1.6 sec ON 1.6 sec OFF	■■■■■■■■■■■■■■■■■■■■ Battery powered inactive log (status=battery backup)
	Medium Blinking 0.8 sec ON 0.8 sec OFF	■■■■■■■■■■■■■■■■■■■■ Low battery warning
	Fast Blinking 0.2 sec ON 0.2 sec OFF	■■■■■■■■■■■■■■■■■■■■ Z-LOGGER3 initializing or shutdown
	Fast Blinking 0.6 sec ■■■ 1 sec OFF	■■■■■■■■■■■■■■■■■■■■ Error, please refer to the diagnostic
	OFF □	Z-LOGGER3 OFF
SD/STS (Red)	ON ■	SD card mounted in the right way
	Medium Blinking 0.8 sec ON 0.8 sec OFF	■■■■■■■■■■■■■■■■■■■■ SD card activity
	Fast Blinking 0.2 sec ON 0.2 sec OFF	■■■■■■■■■■■■■■■■■■■■ SD card error
	OFF □	SD card not present
ETH LNK (Green)	Blinking	RJ45 connection activated
ETH TRF (Yellow)	Blinking	Traffic on Ethernet port

4. DEVICES OVERVIEW

Z-GPRS3, Z-LOGGER3, Z-UMTS are equipped with 4 counters and 4 totalizers. Up to a maximum of 30 Hz signals can be acquired, 4 digital inputs, 2 analog inputs and 2 relay digital outputs.

A maximum of 100 External TAGs (Modbus RTU and/or Modbus TCP) and a maximum of 33 internal TAGs (Embedded IO and signals) can be logged.

The logs are sent in csv format (comma separated values, microsoft excel™ compatible) via ftp, email or microSD card.

Http REST functions can also be used for send logs, alarms and send/receive commands.

Z-GPRS3 and Z-UMTS can also send the last row of the log file via SMS.

An internal UPS is also available, in UPS mode the RTUs will works for about 1h without external power.

All configurations are possible via the SEAL software, available for free download at www.seneca.it in the Z-GPRS3 or Z-UMTS or Z-LOGGER3 section.

SEAL is a graphical environment that allow you to configure the datalogger and to create simple automation without knowing any programming language.

For more info refers to the SEAL help, SEAL is available for free download at address:

<http://www.seneca.it/en/linee-di-prodotto/software/seal/>

Others manuals, quickstart and examples on SEAL are availables on the SEAL RTUs sections on website.

5. SWITCH ON, AND SWITCH OFF THE RTU

RTUs are equipped with back-up batteries (internal UPS) to perform programmable actions in case of blackout.

Switch ON:

- 1) Supply power to the RTU via screw terminal or via BUS IDC10
- 2) The Board will boot-up (led PWR will flash)

Switch OFF:

- 1) Unplug the Power supply (from terminal or from BUS IDC10)
- 2) The board is powered by internal UPS
- 3) Press the button PS1 until the led PWR will flash fast.
- 4) Release the button, the board will power off.

6. SUPPORTED SIM CARDS (ONLY Z-GPRS3 / Z-UMTS)

Z-GPRS3 and Z-UTMS support the following types of SIM CARDS:

Top-up voice SIM CARD

Subscription voice SIM CARD

Data transmission only SIM CARD

"Zero cost" operations can be run only on voice type SIM CARDS, if the RTU receive a ring an action can be made.

For "top-up" SIM CARDS RTU can manage residual credit requesting the amount from the telephone service provider.

CAUTION!

-Before inserting the SIM CARD, CANCEL ALL MESSAGES ON THE CARD USING A MOBILE PHONE.

-Before inserting the SIM CARD, CANCEL ALL ADDRESS BOOK CONTACTS ON THE CARD USING A MOBILE PHONE.

-UMTS SIM CARDS are supported only on Z-UMTS product.

-The Product was tested with leading international provider SIM CARDS. However, operations are not guaranteed with all providers.

7. GSM SIGNAL (ONLY Z-GPRS3 / Z-UMTS)

The GSM signal level can be found via SEAL software (in the “test” section) or in the Webserver.

To view the GSM signal level, the SIM CARD must be inserted (signal may change radically based on the selected provider).

Into the log fileThe field is expressed in DBm where -115 dBm it’s the minimum, -52 dBm it’s the maximum.

This table can be used:

GSM Signal	GSM signal [dBm]
0 (MINIMUM)	-115
1	-106
2	-97
3	-88
4	-79
5	-70
6	-61
7 (MAXIMUM)	-52

Where 0 it’s the minimum, and 7 it’s maximum.

For correct ftp or email log operations the minimum required field level is 2/7 (please remember that the signal often fluctuates).

For SMS operations only the minimum required field level is 2/7.

Refer to the following table for signal values:

SIGNAL LEVEL 0 = NO SIGNAL (INSUFFICIENT)

SIGNAL LEVEL 1 = INSUFFICIENT SIGNAL (NOT RELIABLE FOR SMS AND GPRS)

SIGNAL LEVEL 2 = MINIMUM SIGNAL (MINIMUM SIGNAL FOR SMS AND GPRS)

SIGNAL LEVEL 3 = RELIABLE SIGNAL (RELIABLE FOR SMS AND GPRS)

SIGNAL LEVEL 4 = GOOD SIGNAL

SIGNAL LEVEL 5 = VERY GOOD SIGNAL

SIGNAL LEVEL 6 = OPTIMAL SIGNAL

SIGNAL LEVEL 7 = EXCELLENT SIGNAL

To increase the GSM signal level, Seneca provides various GSM antenna models to reach the minimum signal level in most situations.

Visit www.seneca.it, refer to the general catalogue or contact Seneca srl for further information.

CAUTION!

-Insert the SIM card only with RTU off.

-Before inserting the SIM card, delete all SMS on the SIM using a mobile phone

-Wait at least 5 minutes in order for the GSM signal to be correctly read.

CAUTION!

-Contact your telephone service provider for GSM and GPRS service costs especially when using the RTU with a sim issued by a country other than the one in which it is used (international roaming).

8. INTERNAL UPS

The RTUs are equipped with rechargeable battery.

In the event of a blackout the board can be configured for:


A) Will work for up to 1h without external power.


When the voltage batteries is insufficient the RTU will runs the following algorithm:

- 1) Ends sending data
- 2) Closes all files opened on microSD
- 3) Turned off

B) Will shutdown without external power.

C) Without external power the board will send log data and then shutdown

In SEAL this behavior can be changed in System Configuration  :



CAUTION!
RTUs ARE SUPPLIED WITHOUT CHARGED BATTERIES.

CHARGE THE BATTERIES BY POWER UP RTUs FOR AT LEAST 48H BEFORE USE

CAUTION!
THE BATTERIES CAN BE RECHARGED FOR A MAXIMUM OF ABOUT 300 TIMES.

CAUTION!
TO CONSERVE BATTERY, IN CASE OF DAILY BACKUP, USE THE CONFIGURATION WITH POWER-OFF WHEN BACKUP

9. ADDRESS BOOK

For security reason Z-GPRS3 and Z-UMTS accept SMS command or audio call only from numbers that are in the Address Book.

The address book is composed of a maximum of 8 telephone numbers / emails.

Groups of numbers/emails can be used for sending alarms/logs to a restrict number of users.

For more info refers to the SEAL Help on line.


9.1. SENDING A SMS COMMAND USING THE PASSWORD (ONLY Z-GPRS3 / Z-UMTS)

A SMS command can be accepted also if the telephone number isn't in the address book.

For obtain this feature you must insert before the SMS command a password.

The password is different for every RTUs and is obtained from the last 4 digits of the modem IMEI.

For obtain the password you must connect the RTU with SEAL:



So sending the SMS command:

"2966 NET"

The RTU will respond also if the telephone number isn't in the address book.

9.2. MICROSD CARD PHONE BOOK (ONLY Z-GPRS3 / Z-UMTS)

It's possible to expand the internal phone book using a file in the microSD card.

You can add a maximum of 1000 telephone number but this numbers are enabled only to send a ring (and so execute a ring command).

For editing the MicroSD card phone book refers to the SEAL Help on line.

10. ACQUIRING AND SENDING LOG DATA

When the logger is activated the RTU save data into an internal Flash, then can send it to email server, ftp server, http server or MicroSD card.

When the internal Flash space is full the oldest data will be overwritten (circular buffer).

The files are in standard csv text format (windows excel™ compatible).

There are 3 types of logs:

The Event Logger, The Data logger and the Data logger on Trigger

The internal flash stores at maximum of 8192 rows for the Event Logger, a new row will overwrite the oldest (circular buffer).

The number of rows that the Data Logger can store in the internal flash depends from the TAGs size (16, 32 or 64 bits) and the number of tags.

Activating all the embedded tags the maximum number of rows that can be stored in the internal flash is 16384, a new row will overwrite the oldest (circular buffer).

Activating all the embedded tags and all 100 Extended Tags at 32bit the maximum number of rows that can be stored in the internal flash is $16384/8=2048$, a new row will overwrite the oldest (circular buffer).

10.1. THE EVENT LOGGER

The event logger works defining Events (Digital input/output Events, Blackout, Analog Alarms etc...) with the SEAL software configuration.

When an event is created a new row text (with the Timestamp) is inserted into the log, the event must be configured with the SEAL software.

The event logger can be sent a minimum of 1 time for day if files are sent to FTP, E-MAIL or microSD card.

NOTE:

If no events are generated, the Event logger file will be composed of only 1 row with the text :

INDEX	LEVEL	TIMESTAMP	SOURCE	MESSAGE
140	INFO	06/06/2016 00:00	SYS	OK: No Messages

10.1.1. Sending event logger file to an FTP server

The RTUs are compatible with ftp server configured into passive mode.

If the connection with the server is lost the RTU will accumulate the data and when the connection returns all data is sent up to align to actual acquisition.

An event log can include also the diagnostic, for example:

INDEX	LEVEL	TIMESTAMP	SOURCE	MESSAGE
119	ERR	01/06/2016 14:11	SYS	FTP Connect Error
120	ERR	01/06/2016 20:34	PRT1	Bus Disconnected
121	ERR	01/06/2016 23:05	PRT1	Bus Disconnected
122	ERR	02/06/2016 05:37	PRT1	Bus Disconnected
123	ERR	02/06/2016 06:39	SYS	FTP Connect Error
124	WARN	02/06/2016 06:40	SYS	PING Timeout
125	ERR	02/06/2016 13:14	PRT1	Bus Disconnected
126	ERR	02/06/2016 16:46	PRT1	Bus Disconnected
127	ERR	02/06/2016 19:48	PRT1	Bus Disconnected
128	ERR	02/06/2016 21:26	PRT1	Bus Disconnected

For events (Digital1 and Digital2 alarm state for example):

INDEX	LEVEL	TIMESTAMP	SOURCE	MESSAGE
674	INFO	25/06/2016 00:18:23	SEC2	INPUT 2 ALARM ON!
675	INFO	25/06/2016 00:18:23	SEC2	INPUT 2 ALARM END!
676	INFO	25/06/2016 00:18:24	SEC2	INPUT 2 ALARM ON!
677	INFO	25/06/2016 00:18:25	SEC2	INPUT 2 ALARM END!
678	INFO	25/06/2016 00:18:25	SEC1	INPUT 1 ALARM ON!
679	INFO	25/06/2016 00:18:26	SEC1	INPUT 1 ALARM END!
680	INFO	25/06/2016 00:18:26	SEC1	INPUT 1 ALARM ON!
681	INFO	25/06/2016 00:18:26	SEC1	INPUT 1 ALARM END!
682	INFO	25/06/2016 00:18:28	SEC2	INPUT 2 ALARM ON!
683	INFO	25/06/2016 00:18:28	SEC2	INPUT 2 ALARM END!

The Event Logger filename is:

RTUNAME_msgyyyyMMddhhmmss.csv

Where:

RTUNAME is the name of the RTU

yyyy is the year at the send file

MM is the month at the send file

dd is the day at the send file

hh are the hours at the send file

mm are the minutes at the send file

ss are the seconds at the send file

So the filename for example can be:

ZGPRS3TEST_msg20160606000057.csv

10.1.2. Sending event logger file to an EMAIL server

RTUs are compatible only with SMTP servers without encryption using the Ethernet or GPRS Always ON (PPP) connection.

Z-GPRS3 and Z-UMTS are compatible also with SMTPS server with SSL 3.0 encryption (for example GMAIL™) but only with GPRS connection NOT always ON (PPP must be off)

An example of SMTP server that works without encryption is hMailServer for windows™, for more info: <https://www.hmailserver.com/>.

See the application note for installing and use hMailServer on a windows™ machine.

If the connection with the server is lost the RTU will accumulate the data and when the connection is returned all data is sent up to align to actual acquisition.

A typical mail sent has a text in the body with the timestamp and the log file in attachment.

An event log can include also the diagnostic, for example:

INDEX	LEVEL	TIMESTAMP	SOURCE	MESSAGE
119	ERR	01/06/2016 14:11	SYS	FTP Connect Error
120	ERR	01/06/2016 20:34	PRT1	Bus Disconnected
121	ERR	01/06/2016 23:05	PRT1	Bus Disconnected
122	ERR	02/06/2016 05:37	PRT1	Bus Disconnected
123	ERR	02/06/2016 06:39	SYS	FTP Connect Error
124	WARN	02/06/2016 06:40	SYS	PING Timeout
125	ERR	02/06/2016 13:14	PRT1	Bus Disconnected
126	ERR	02/06/2016 16:46	PRT1	Bus Disconnected
127	ERR	02/06/2016 19:48	PRT1	Bus Disconnected
128	ERR	02/06/2016 21:26	PRT1	Bus Disconnected

For events (Digital1 and Digital2 alarm state for example):

INDEX	LEVEL	TIMESTAMP	SOURCE	MESSAGE
674	INFO	25/06/2016 00:18:23	SEC2	INPUT 2 ALARM ON!
675	INFO	25/06/2016 00:18:23	SEC2	INPUT 2 ALARM END!
676	INFO	25/06/2016 00:18:24	SEC2	INPUT 2 ALARM ON!
677	INFO	25/06/2016 00:18:25	SEC2	INPUT 2 ALARM END!
678	INFO	25/06/2016 00:18:25	SEC1	INPUT 1 ALARM ON!
679	INFO	25/06/2016 00:18:26	SEC1	INPUT 1 ALARM END!
680	INFO	25/06/2016 00:18:26	SEC1	INPUT 1 ALARM ON!
681	INFO	25/06/2016 00:18:26	SEC1	INPUT 1 ALARM END!
682	INFO	25/06/2016 00:18:28	SEC2	INPUT 2 ALARM ON!
683	INFO	25/06/2016 00:18:28	SEC2	INPUT 2 ALARM END!

The Event Logger filename is:

RTUNAME_msgyyyyMMddhhmmss.csv

Where:

RTUNAME is the name of the RTU

yyyy is the year at the send file

MM is the month at the send file

dd is the day at the send file

hh are the hours at the send file

mm are the minutes at the send file

ss are the seconds at the send file

So the filename for example can be:

ZGPRS3TEST_msg20160606000057.csv

10.1.3. Saving event logger file to the microSD card

RTUs are compatible only with microSD card formatted in FAT32 (FAT16 filesystem is not recommended).

The event log files are stored into the /SYS directory.

The file name is different from the name that is sent to the FTP/EMAIL and is

Exxxxxxx.csv

Where xxxxxxx is an incremental number.

10.2. THE DATA LOGGER AND THE DATA LOGGER ON TRIGGER

The data logger works defining a Data acquisition time (sample time).

The minimum sample time is 1 minute.

The board can send data in two ways:

- 1) Notification
- 2) Report

The Notification sends data every sample time (minimum = 1 minute), the file will have only 1 row data. This row can be sent to SMS, EMAIL or HTTP POST.

The Report sends data every report time (for sample time = 1 minute and report time = 5 minutes then the report is made of 5 rows data).

The data logger on trigger works defining one or more event trigger actions, when the event trigger action is true a row acquisition is made.

If no event trigger actions are performed, no Notifications or Reports are sent.

NOTE:

For http POST function only the Notification data can be used so only one row will be sent at a time.

10.2.1. Sending data logger file to a FTP server

Z-GPRS3 is compatible with ftp server configured into passive mode.

If the connection with the server is lost the RTU will accumulate the data and when the connection is returned all data is sent up to align to actual acquisition.

A tipical Data logger file when is open with excel™ is:

INDEX	TYPE	TIMESTAMP	DIN1	DIN2	DIN3	DIN4	DOUT1	DOUT2	VBAT	POW	VAL1	AVG1	MIN1	MAX1
51764	LOG	05/06/2016 14:36	0	0	0	0	0	0	1	1	43	43	42	44
51765	LOG	05/06/2016 14:37	0	0	0	0	0	0	1	1	43	43	43	44
51766	LOG	05/06/2016 14:38	0	0	0	0	0	0	1	1	43	43	42	44
51767	LOG	05/06/2016 14:39	0	0	0	0	0	0	1	1	43	43	42	44
51768	LOG	05/06/2016 14:40	0	0	0	0	0	0	1	1	43	43	42	44

Where:

INDEX is a progressive acquisition number.

LOG is a constant text.

TIMESTAMP is the Real Time Clock when the acquisition is made.

The others values are the TAG name and variables entered by the user in the SEAL configuration.

The Data Logger on Trigger file when is open with excel™ is:

INDEX	TYPE	TRIGGER	TIMESTAMP	POW	VBAT	DIN1	DIN2	DIN3	DIN4	DOUT1	DOUT2	VAL1	AVG1	MIN1	MAX1
1	ASYNC	A-----	05/12/2016 16:11	1	1	1	0	0	0	0	0	-4	-3	-5	-3
2	ASYNC	A-----	05/12/2016 16:11	1	1	1	0	0	0	0	0	-5	-3	-5	-3
3	ASYNC	A-----	05/12/2016 16:11	1	1	1	0	0	0	0	0	-5	-3	-5	-3
4	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3
5	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3

6	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3
7	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3
8	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3
9	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3
10	ASYNC	AB-----	05/12/2016 16:11	1	1	1	1	0	0	0	0	-4	-3	-5	-3

A New column named Trigger is the Trigger Source that generated the log line.

For example the line indexed 9 is generated from the “B” trigger (DIN2 HIGH).

The line indexed 10 is generated from “A” and “B” trigger at the same time (DIN1 and DIN2 HIGH).

Note that the RTU directly calculates Average/Minimum/Maximum of an embedded analog input.

The Data Logger filename is:

RTUNAME_logyyyyMMddhhmmss.csv

Where:

RTUNAME is the name of the RTU

yyyy is the year of the first row data in the file

MM is the month of the first row data in the file

dd is the day of the first row data in the file

hh are the hours of the first row data in the file

mm are the minutes of the first row data in the file

ss are the seconds of the first row data in the file

So the filename of the first example can be:

ZGPRS3TEST_log20160605143600.csv

10.2.2. Sending data logger and data logger on trigger data to an E-MAIL server


RTUs are compatible only with SMTP servers without encryption using the Ethernet or GPRS/UMTS+ Always ON (PPP) connection.

Z-GPRS3 and Z-UMTS are compatible also with SMTPS server with SSL encryption (for example GMAIL™) but only with GPRS/UMTS+ connection NOT always ON (PPP must be off).

An example of SMTP server that works without encryption is hMailServer for windows™ , for more info: <https://www.hmailserver.com/>.

If the connection with the server is lost the RTU will accumulate the data and when the connection is returned all data is sent up to align to actual acquisition.

A typical mail sent has a text in the body with the timestamp and the log file in attachment:



A typical Data logger file when is open with excel™ is:

INDEX	TYPE	TIMESTAMP	DIN1	DIN2	DIN3	DIN4	DOUT1	DOUT2	VBAT	POW	VAL1	AVG1	MIN1	MAX1
51764	LOG	05/06/2016 14:36	0	0	0	0	0	0	1	1	43	43	42	44
51765	LOG	05/06/2016 14:37	0	0	0	0	0	0	1	1	43	43	43	44
51766	LOG	05/06/2016 14:38	0	0	0	0	0	0	1	1	43	43	42	44
51767	LOG	05/06/2016 14:39	0	0	0	0	0	0	1	1	43	43	42	44
51768	LOG	05/06/2016 14:40	0	0	0	0	0	0	1	1	43	43	42	44

Where:

INDEX is a progressive acquisition number.

LOG is a constant text.

TIMESTAMP is the Real Time Clock when the acquisition is made.

The others values are the TAG name and variables entered by the user in the SEAL configuration.

The Data Logger on Trigger file when is open with excel™ is:

INDEX	TYPE	TRIGGER	TIMESTAMP	POW	VBAT	DIN1	DIN2	DIN3	DIN4	DOUT1	DOUT2	VAL1	AVG1	MIN1	MAX1
1	ASYNC	A-----	05/12/2016 16:11	1	1	1	0	0	0	0	0	-4	-3	-5	-3
2	ASYNC	A-----	05/12/2016 16:11	1	1	1	0	0	0	0	0	-5	-3	-5	-3
3	ASYNC	A-----	05/12/2016 16:11	1	1	1	0	0	0	0	0	-5	-3	-5	-3
4	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3
5	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3

6	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3
7	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3
8	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3
9	ASYNC	-B-----	05/12/2016 16:11	1	1	0	1	0	0	0	0	-4	-3	-5	-3
10	ASYNC	AB-----	05/12/2016 16:11	1	1	1	1	0	0	0	0	-4	-3	-5	-3

A New column named Trigger is the Trigger Source that generated the log line.

For example the line indexed 9 is generated from the “B” trigger (DIN2 HIGH).

The line indexed 10 is generated from “A” and “B” trigger at the same time (DIN1 and DIN2 HIGH).

Note that the RTU directly calculates Average/Minimum/Maximum of an embedded analog input.

If the Data Logger file is sent to an ftp server or by email the filename is:

RTUNAME_logyyyyMMddhhmmss.csv

Where:

RTUNAME is the name of the RTU

yyyy is the year of the first row data in the file

MM is the month of the first row data in the file

dd is the day of the first row data in the file

hh are the hours of the first row data in the file

mm are the minutes of the first row data in the file

ss are the seconds of the first row data in the file

So the filename of the example can be:

ZGPRS3TEST_log20160605143600.csv

10.2.1. Sending data logger and data logger on trigger data to an HTTP server

Data logger Logs are sent using the Notification (connection is made every sample time).

The standard used for send data is the JSON.

For more info refers to the SENECA CLOUDBOX user manual.

10.2.2. Saving data logger data to the microSD card

Z-GPRS3 is compatible only with microSD card formatted in FAT32 (FAT16 filesystem is not recommended).

The log files are stored into the /LOG directory.

If the log report must be sent more frequently than daily, the RTU will create a directory for every days, for example:

ROOT

```
--LOG
    --20160618
    --20160619
    --20160620
```

The file name is different from the name that is sent to the FTP/EMAIL and is

Lxxxxxxx.csv

Where xxxxxxx is an incremental number.

11. HOW MANY LOGS IN A SINGLE MICROSD?

A microSD is pre-formatted FAT32 with allocation unit that depends from the constructor.

The number of logs data that can be stored in a microSD card depends from the microSD and the allocation unit size.

Using a classic microSD of 4GBytes formatted with a file allocation of 32768 bytes, the number of allocation are about:

$4\ 000\ 000\ 000 / 32768 = \text{about } 122070 \text{ allocation units}$

Typically the RTU can save data to a microSD every 15 minutes, in this case the microSD will be full in:

$122070 / 96 \text{ files for day} = \text{about } 1272 \text{ days} = \text{about } 3.5 \text{ years}$

Writing to a microSD every 1 minute, in this case the microSD will be full in:

$122070 / 3600 \text{ files for day} = \text{about } 34 \text{ days}$

If you need to increase the number of log that can be stored, you must format the microSD with the minimum allocation unit size.

In a dos shell “cmd” type:

```
format x: /FS:FAT32 /A:1024 /Q
```

Where “x” is the microSD drive letter

You will obtain an allocation unit of 1024bytes so the number of allocation units is:

$4\,000\,000\,000 / 1024 = \text{about } 3906250$ allocation units.

Saving a file every 15 minutes will create a file of about 10K so use 10 allocation unit:

$3906250 / (10 \text{ allocation units} * 96 \text{ file for day}) = \text{about } 4096 \text{ days} \Rightarrow \text{about } 11 \text{ years}$

The minimum unit size are typically:

512 Bytes for 2GB microSD

1024 Bytes for 4GB microSD

12. ACTIONS AND MESSAGES

The SEAL software configurator can manage Actions, and Messages.

12.1. ACTIONS

Actions are commands that must be executed from the RTU when an event is TRUE or FALSE.

Example of actions are: writing to a modbus register, Toggle the digital output 1, reset a totalizer etc...

12.2. TEXT AND AUDIO MESSAGES

Messages are text that must be sent from the RTU when an event is TRUE or FALSE.

A Messages can be sent to: EMAILS, SMS, AUDIO CALL and HTTP POST

Example of messages are: sending a text alarm “Input 1 high ALARM!” when the analog input 1 is higher than 15 mA.

Audio messages are located into the /AUDIO directories, a preset of audio messages are loaded with seal but can be edited.

13. SENDING AUDIO (DTMF) COMMANDS TO Z-GPRS3 and Z-UMTS

Z-GPRS3 and Z-UMTS can receive audio calls for executing commands using DTMF code.

When a RTU is called the audio file in SD card:

/AUDIO/80.pcm

Now the RTU can execute the FAST COMMANDS from 0 to 15 simply typing the command number and then confirm with the “*”, use “#” for cancel.

The FAST COMMANDS are editable from SEAL in the APP icon -> Fast command, for example:



14. THE WEBSERVER

The Webserver is reachable from the Ethernet or from the Modem PPP connection.

There are 2 different webserver:

A Maintenance Webserver and a Custom Webserver.

CAUTION!

The webserver must be enabled from the SEAL software (default is webserver OFF).

14.1. MAINTENANCE WEBSERVER

The maintenance webserver can be used for maintenance and debug purposes, for accessing this webserver type in a browser (with default ip address):


<http://192.168.1.101/maintenance/index.html>

192.168.1.101 must be replaced with the Ethernet or the Modem PPP IP address.

With the webserver is possible to download all the log files that are store in SD card:

The screenshot shows the SENECA web interface. On the left is a navigation menu with items: Status, Set Real Time Clock, Digital I/O, Analog In, Counters, Extended Variables, Diagnostic Messages, Download Files, and Upload Files. The main content area is titled 'Z-GPRS3 SD-CARD Log Files' and displays a directory listing for 'SD-CARD/LOG/'. The listing includes a column for file numbers (1-26), folder names (starting with '.' and then dates from 20160611 to 20160623), and a column of red 'x' marks. An 'OK' button is visible at the bottom of the listing.

File Number	File Name	Download Status
1	.	
2	..	
3	20160611	x
4	20160612	x
5	20160613	x
6	20160614	x
7	20160615	x
8	20160616	x
9	20160530	x
10	20160617	x
11	20160618	x
12	20160531	x
13	20160601	x
14	20160602	x
15	20160603	x
16	20160604	x
17	20160605	x
18	20160606	x
19	20160607	x
20	20160608	x
21	20160610	x
22	20160619	x
23	20160620	x
24	20160621	x
25	20160622	x
26	20160623	x



By clicking on the file is possible to download or delete a single log file.

For debug you can see in real time all the external/internal TAGs values in the “Extended Variables”/ “Status” / “Digital IO” / “Analog IN” / “Counters” sections.

The last 16 Diagnostic Messages can be viewed in the “Diagnostic Messages” section.

The “Upload file” section can be used for sending a new configuration or a new firmware to the Z-GPRS3 RTU.

14.2. CUSTOM WEBSERVER

The custom webserver is located in the provided microSD card (/WEB directory).


For accessing this webserver type in a browser (with default ip address):

<http://192.168.1.101/index.html>

192.168.1.101 must be replaced with the Ethernet or the Modem PPP IP address.

Various Custom webserver can be downloaded from:

<http://www.seneca.it/products/z-gprs3/>




For example is possible to write directly to an external modbus tag entering in upper right corner a tag name and the new value.

An example of real time graph is also provided:


SENECA Z-GPRS3 ver. 1.00

Send Read

Analog



Digital I/O



Counters and Totalizers



15. SEAL (Seneca Advanced Language)

Seal is a programming environment for the Seneca RTU, for more info refers to the SEAL help.

The last Seal software version can be downloaded from:

<http://www.seneca.it/en/linee-di-prodotto/software/seal/>

For more info install SEAL and go to the on line help.

CAUTION!

For a full support of SEAL the microSD card must be inserted!

16. FIRMWARE UPDATE

In order to include new functions, the system includes Z-GPRS3 firmware update options.

Various different update modes are available for firmware:

Via Webserver: Connect to the section “Upload File” for updating the firmware


Via USB: A complete update takes about 8 minutes. Z-GPRS3 / Z-Logger must be connected to a PC with SEAL software installed.

Via microSD card: A complete update takes about 20 seconds. A microSD adapter for PC (many mobile phones can also read/write microSD) is required.

Via FTP Server: When the RTU is not reachable directly, the firmware update can be made by sending a SMS or a HTTP command, then the update file is downloaded directly by the Z-GPRS3 RTU from a FTP server.

16.1. Firmware update by Webserver

- 1) Download and Install the last SEAL software from Seneca Website (the last firmware is located in C:\Program Files\Seneca\SeAL\devices).
- 2) Connect to the RTU webserver at address:
http://ipaddress/maintenance/index.html
where “ipaddress” is the PPP modem or Ethernet ip address.
- 3) Go to the “Upload File” section.



- 4) Under “Firmware Binary File” select the “fw.bin” file from the last firmware folder and then click “UPLOAD”
- 5) The RTU will reboot with the new firmware.

16.2. Firmware update by microSD card

Firmware can be updated via microSD card formatted with the FAT16 or FAT32 filesystem (purchased microSD cards are usually already formatted this way).

Proceed as follows to update firmware:

1. Copy the file called “fw.bin” containing the firmware to a microSD card, The file must be copied to the main microSD folder.
2. With the Z-GPRS3 RTU OFF, insert the microSD card in the slot
3. Turn ON the Z-GPRS3 RTU.
4. The SD/STS led starts to flash at 1 second intervals for about 20 seconds. The new firmware is written in flash memory during this phase.
5. When finished, the SD/STS led starts to flash fast
6. At this point, remove the microSD
7. The green PWR led starts to flash fast (several times a second); in this phase the module is copying firmware from flash to the microprocessor flash.
8. When finished, the module automatically turns off and back on

The firmware update can be checked:

-Connecting the module to SEAL software, the firmware version has changed.

CAUTION!

-BEFORE UPDATING firmware, copy the current configuration.

-Once the firmware is updated, the previous setup may be deleted so Z-GPRS3 must be re-configured.

17. SEAL PROGRAM AND SEAL CONFIGURATION REMOTE UPDATE

17.1. SEAL PROGRAM AND SEAL CONFIGURATION UPDATE FROM WEBSERVER


You can update a SEAL program and or configuration from the Z-GPRS3 Webserver.

For update a new program and configuration follow the procedure:

- 1) In SEAL create a new program or change the parameters configuration
- 2) Go to Build -> Generate
- 3) Now Seal will create 3 files: .seal, .debug, .out
- 4) Rename the .out file to “setup.tag”
- 5) Connect to the webserver at address:
<http://ipaddress/maintenance/index.html>

where “ipaddress” is the PPP modem or Ethernet ip address.

6) Go to the “Upload File” section.



7) Under “Configuration Tags File” select the “setup.tag” file and then click “UPLOAD”

8) The RTU will restart with the new SEAL Program/Configuration

CAUTION!


When use this feature with Remote RTU be sure that the connection parameters are correct before upload the new SEAL Program/Configuration or the RTU will be unreachable!

17.2. UPLOAD A PROJECT BACKUP TO THE RTU

You can create a backup file for the SEAL program (.seal file) for archive and upload it to the RTU.

For to do that follow the procedure:

- 1) Connect to the webserver at address:
http://ipaddress/maintenance/index.html
where “ipaddress” is the PPP modem or Ethernet ip address.
- 2) Go to the “Upload File” section.



- 3) Under “Configuration SEAL File” select the “.seal” file and then click “UPLOAD”
- 4) The RTU will store the .seal file to the SD card

CAUTION!

When a “.seal” file is uploaded the RTU will not change the actual program/configuration.


This operation is only for backup purpose, for changing the program/configuration you must upload the “setup.tag” file (see chapter 17.1)

18. MODBUS TCP-IP SERVER AND MODBUS RTU SLAVE

The RTUs can activate a Modbus TCP-IP Server and a Modbus RTU Slave (on serial ports) for accessing the Embedded and Modbus I/O.

The server accept up to 2 clients from Ethernet or Modem (PPP) connection.

The external variables addresses are placed from the SEAL compiler so, after compiling, the addresses can be showed:



277	Notice	Build	Slave Address PHASE B:PRT2 1:S203TA/RC-D 40137:PHASE B Mapped to 41003
278	Notice	Build	Slave Address POWER B:PRT2 1:S203TA/RC-D 40169:POWER B Mapped to 41005
279	Notice	Build	Slave Address POWER ABC:PRT2 1:S203TA/RC-D 40173:POWER ABC Mapped to 41007
280	Notice	Build	Slave Address CH1:PRT2 2:Z-4RTD2 40003:CH1 Mapped to 41009
281	Notice	Build	Slave Address CH2:PRT2 2:Z-4RTD2 40004:CH2 Mapped to 41010
282	Notice	Build	Slave Address CALCULATION1:CALCULATION1 Mapped to 41011
283	Notice	Build	Slave Address CALCULATION2:CALCULATION2 Mapped to 41012
284	Info	Build	Time elapsed 0:0:0.5

18.1. MODBUS ADDRESSES TABLE

ADDRESS	OFFSET	TAG	REGISTER TYPE	RO/RW	INFO
40001	0	MACHINE ID	UNSIGNED 16	READ ONLY	INTERNAL CODE
40002	1	FIRMWARE CODE	UNSIGNED 16	READ ONLY	INTERNAL CODE
40003	2	FIRMWARE MAJOR REVISION	UNSIGNED 16	READ ONLY	(EXAMPLE 204 = 2.04)
40004	3	FIRMWARE MINOR REVISION	UNSIGNED 16	READ ONLY	In decimal format KMMBB Where: K=4= Bugfix Release K=3= New Release MM = Minor Revision BB = Build Example: Value = 40110 4 = Bugfix Release 01 = Minor revision 1 10 = Build 10

40008	7	DIGITAL INPUTS AND SIGNALS	BIT	READ ONLY	Digital Inputs Bit 0 = INPUT1 VALUE Bit 1 = INPUT2 VALUE Bit 2 = INPUT3 VALUE Bit 3 = INPUT4 VALUE Bit 7 = EXTERNAL POWER Bit 8 = BATTERY GOOD
40009	8	DIGITAL OUTPUTS	BIT	READ ONLY	Bit 14 = DIGITAL OUTPUT 1 VALUE Bit 15 = DIGITAL OUTPUT 2 VALUE
40015	14	CLOCK YEAR	SIGNED 16 BITS	READ ONLY	Year
40016	15	CLOCK MOUNTH	UNSIGNED 8 BITS	READ ONLY	Bit from 0 to 7 (LSB)
40017	16	CLOCK DAY	UNSIGNED 8 BITS	READ ONLY	Bit from 0 to 7 (LSB)
40017	16	CLOCK HOURS	UNSIGNED 8 BITS	READ ONLY	Bit from 8 to 15 (MSB)
40018	17	CLOCK MINUTES	UNSIGNED 8 BITS	READ ONLY	Bit from 0 to 7 (LSB)
40018	17	CLOCK SECONDS	UNSIGNED 8 BITS	READ ONLY	Bit from 8 to 15 (MSB)
40023	22	Totalizer value 1 LSW	UNSIGNED 16 BITS	READ ONLY	Less significant 16 bits
40024	23	Totalizer value 1 MSW	UNSIGNED 16 BITS	READ ONLY	Most significant 16 bits
40025	24	Counter value 1 LSW	UNSIGNED 16 BITS	READ ONLY	Less significant 16 bits
40026	25	Counter value 1 MSW	UNSIGNED 16 BITS	READ ONLY	Most significant 16 bits
40039	38	Worktime 1 LSW	UNSIGNED 16 BITS	READ ONLY	Value in [Seconds] Less significant 16 bits
40040	39	Worktime 1 MSW	UNSIGNED 16 BITS	READ ONLY	Value in [Seconds] Most significant 16 bits
40049	48	Totalizer value 2 LSW	UNSIGNED 16 BITS	READ ONLY	Less significant 16 bits
40050	49	Totalizer value 2 MSW	UNSIGNED 16 BITS	READ ONLY	Most significant 16 bits
40051	50	Counter value 2 LSW	UNSIGNED 16 BITS	READ ONLY	Less significant 16 bits
40050	49	Counter value 2 MSW	UNSIGNED 16 BITS	READ ONLY	Most significant 16 bits
40065	64	Worktime 2 LSW	UNSIGNED 16 BITS	READ ONLY	Value in [Seconds] Less significant 16 bits
40066	65	Worktime 2 MSW	UNSIGNED 16 BITS	READ ONLY	Value in [Seconds] Most significant 16 bits
40075	74	Totalizer value 3 LSW	UNSIGNED 16 BITS	READ ONLY	Less significant 16 bits
40076	75	Totalizer value 3 MSW	UNSIGNED 16 BITS	READ ONLY	Most significant 16 bits
40077	76	Counter value 3 LSW	UNSIGNED 16 BITS	READ ONLY	Less significant 16 bits

40078	77	Counter value 3 MSW	UNSIGNED 16 BITS	READ ONLY	Most significant 16 bits
40091	90	Worktime 3 LSW	UNSIGNED 16 BITS	READ ONLY	Value in [Seconds] Less significant 16 bits
40092	91	Worktime 3 MSW	UNSIGNED 16 BITS	READ ONLY	Value in [Seconds] Most significant 16 bits
40101	100	Totalizer value 4 LSW	UNSIGNED 16 BITS	READ ONLY	Less significant 16 bits
40102	101	Totalizer value 4 MSW	UNSIGNED 16 BITS	READ ONLY	Most significant 16 bits
40103	102	Counter value 4 LSW	UNSIGNED 16 BITS	READ ONLY	Less significant 16 bits
40104	103	Counter value 4 MSW	UNSIGNED 16 BITS	READ ONLY	Most significant 16 bits
40117	116	Worktime 4 LSW	UNSIGNED 16 BITS	READ ONLY	Value in [Seconds] Less significant 16 bits
40118	117	Worktime 4 MSW	UNSIGNED 16 BITS	READ ONLY	Value in [Seconds] Most significant 16 bits
40128	127	Battery Voltage	UNSIGNED 16 BITS	READ ONLY	[mV]
40130	129	Analog input 1	SIGNED 16 BITS	READ ONLY	Value in [mA] or [V]
40131	130	Scaled Analog Input 1	SIGNED 16 BITS	READ ONLY	Custom scaled value
40144	143	Analog input 2	SIGNED 16 BITS	READ ONLY	Value in [mA] or [V]
40145	144	Scaled Analog Input 2	SIGNED 16 BITS	READ ONLY	Custom scaled value
40158	157	GSM Field	SIGNED 16 BITS	READ ONLY	Value in [dBm]
41003 ... 41203	1002 ... 1202	External Variables Tags	-	READ/WRITE	Use the compile output window for Tags address position
49001	9000	COMMAND	UNSIGNED 16 BITS	READ/WRITE	Command Register (see Table with supported commands)

18.2. SUPPORTED COMMANDS FROM MODBUS

If you have enabled the Modbus TCP-IP server by Ethernet connection or the Modbus Slave RTU from a serial port you are able to send commands to RTUs.

The register COMMAND is at holding address 49001 (holding register 9000)

COMMAND	VALUE (decimal)
RESET RTU	1
UNMOUNT SD CARD	7

STOP DATALOGGER	18
START DATALOGGER	17
COPY ALL LOGS FROM INTERNAL FLASH TO microSD CARD	19
RESET LOG SESSION	20
ERASE ALL LOG FROM INTERNAL FLASH	16
FORCE MODEM RESET	65
STOP MODBUS TCP-IP AND MODBUS RTU LOG	98
START MODBUS TCP-IP AND MODBUS RTU LOG	97
DOWNLOAD AND UPDATE FIRMWARE FROM REMOTE FTP SERVER	112
DOWNLOAD AND UPDATE FIRMWARE AND SETUP FROM REMOTE FTP SERVER	113
DOWNLOAD AND UPDATE SETUP FROM REMOTE FTP SERVER	114
DOWNLOAD AND UPDATE PHONEBOOK FROM FTP SERVER	83
UPDATE FIRMWARE FROM SD	116
UPDATE SETUP FROM SD	117
UPDATE PHONEBOOK FROM SD	118
EXECUTE RING COMMAND	33
EXECUTE FAST COMMAND 0	48
EXECUTE FAST COMMAND 1	49
EXECUTE FAST COMMAND 2	50
EXECUTE FAST COMMAND 3	51
EXECUTE FAST COMMAND 4	52
EXECUTE FAST COMMAND 5	53
EXECUTE FAST COMMAND 6	54
EXECUTE FAST COMMAND 7	55
EXECUTE FAST COMMAND 8	56

EXECUTE FAST COMMAND 9	57
EXECUTE FAST COMMAND 10	58
EXECUTE FAST COMMAND 11	59
EXECUTE FAST COMMAND 12	60
EXECUTE FAST COMMAND 13	61
EXECUTE FAST COMMAND 14	62
EXECUTE FAST COMMAND 15	63
CLOSE DIGITAL OUTPUT1	Write with Write Multiple Register: write 32 in register 49001 write 32 in register 49002 write 512 in register 49003
OPEN DIGITAL OUTPUT1	Write with Write Multiple Register: write 32 in register 49001 write 16 in register 49002 write 512 in register 49003
CLOSE DIGITAL OUTPUT2	Write with Write Multiple Register: write 32 in register 49001 write 8192 in register 49002 write 512 in register 49003
OPEN DIGITAL OUTPUT2	write 32 in register 49001 write 4096 in register 49002 write 512 in register 49003

19. SUPPORTED SMS COMMANDS (Z-GPRS3 and Z-UMTS only)

19.1. Set the Telephone Sms Character Alphabet

Some Smartphones send SMS with UNICODE characters instead of using the GSM alphabet.

Z-GPRS3 only runs SMS commands with GSM alphabet.

In most cases, SMS characters are set to GSM alphabet by default. If Z-GPRS3 does not recognise any SMS command, check the alphabet used by the phone.

For Android smartphones:

Press the Message icon -> Settings -> Change writing -> GSM alphabet

19.2. List of Supported Sms Commands

Z-GPRS3 lets you run commands if the SMS sender number is enabled.

Command list:

SMS COMMANDS FOR DIGITAL INPUTS/COUNTERS/TOTALIZERS	
GET DIN	<i>Status from all counters</i>
GET DINn	<i>All nth input counter status</i>
GET DINn.TOT	<i>All nth input totalizers status</i>
GET DINn.CNT	<i>All nth input counters status</i>
RESET DIN	<i>Reset all counters</i>
RESET CNTn	<i>Reset the nth counter</i>

SMS COMMANDS FOR DIGITAL INPUTS/COUNTERS/TOTALIZERS	
GET DIN	<i>Status from all counters</i>
GET DINn	<i>All nth input counter status</i>
GET DINn.TOT	<i>All nth input totalizers status</i>
GET DINn.CNT	<i>All nth input counters status</i>

RESET DIN	<i>Reset all counters</i>
RESET CNTn	<i>Reset the nth counter</i>

SMS COMMANDS FOR READ/WRITE EXTENDED VARIABLES

GET TAG <VARIABLE_LABEL>	<p><i>Returns by SMS the value of the extended variable named <VARIABLE_LABEL></i></p> <p><i>For example:</i></p> <p><i>GET TAG PIPPO</i></p> <p><i>Returns the PIPPO extended variable value</i></p>
SET TAG <VARIABLE_LABEL> <VALUE>	<p><i>Write <VALUE> to the external variable named <VARIABLE_LABEL></i></p> <p><i>For example:</i></p> <p><i>SET TAG PIPPO 345</i></p> <p><i>Write 345 to the PIPPO extended variable</i></p>

SMS COMMANDS FOR DIGITAL OUTPUTS

SET DOUTn.OPEN	<i>Opens the nth digital output</i>
SET DOUTn.CLOSE	<i>Closes the nth digital output</i>
SET TOGGLEn	<i>Toggle the nth digital output</i>

SET PULSEn.OPEN	<i>Opens the nth timed output</i>

SMS COMMANDS FOR ADDRESS BOOKS	
SET PHONE +nnnnnnn	Add number +nnnnnn to address book as administrator
RESET PHONE +nnnnnnn	Remove number +nnnnnn from the address book
SET EMAIL nnn@nnn.nnn	Add email nnn@nnn.nnn to address book as administrator
RESET EMAIL nnn@nnn.nnn	Delete email nnn@nnn.nnn from the address book

VARIOUS SMS COMMANDS	
<i>CREDIT</i>	Returns residual credit (for top-up SIM CARD only)
<i>STATUS</i>	Returns the variables set by setup software. All available variables can be included. If the SMS text exceeds 160 characters, it will be truncated (three dots “...” at the end of the SMS).
SET GSM.APN apn_name user password	Set the APN with the APN name, user and password. For example, set vodafone APN that does not require user name and password: SET GSM.APN web.omnitel.it
SET GSM.FTP path name_ip port user password	Set FTP connection settings: path the FTP server folder where files are sent name_ip IP address or FTP server name port FTP server gateway user FTP server login user name password FTP server login password for example: SET /prova/ 192.168.180.33 21 pippo pluto
SET GSM.SMTP name_ip port user password	<i>set SMTP server connection settings to send emails</i> <i>name_ip IP address or FTP server name</i> <i>port smtp server gateway</i> <i>user FTP server login user name</i> <i>password smtp server login password</i> <i>for example:</i> <i>SET GSM.SMTP out.alice.it 25 pippo pluto</i>
<i>GET AIN</i>	<i>Returns the two analog input values</i>
<i>EMAIL TEST</i>	<i>Forces an email sent with an attachment to the first administrator in the email address book</i>

<i>FTP TEST</i>	<i>Forces a text file sent to the currently set ftp server</i>
<i>EMAIL TAG</i>	<p><i>Sends the value indicated by "TAG" to the first email contact</i></p> <p><i>EMAIL AIN sends an email with the value of the 2 analogs</i></p> <p><i>EMAIL AIN1 sends an email with the value of the analog 1</i></p> <p><i>EMAIL AIN2 sends an email with the value of the analog 2</i></p> <p><i>EMAIL DIN sends an email with the value of the digital inputs</i></p> <p><i>EMAIL DIN1 sends an email with the value of the digital input 1</i></p> <p><i>EMAIL DIN2 sends an email with the value of the digital input 2</i></p> <p><i>EMAIL DIN3 sends an email with the value of the digital input 3</i></p> <p><i>EMAIL DIN4 sends an email with the value of the digital input 4</i></p> <p><i>EMAIL TEMP sends an email with the internal temperature sensor value</i></p>
<i>EMAIL SYSLOG</i>	<i>Sends the last week syslog.csv log file on microSD via email (first administrator address in the address book)</i>
<i>FTP SYSLOG</i>	<i>Sends the last week syslog.csv log file in the microSD via FTP</i>
<i>UPLOAD LOG</i>	<i>Create a dump of the actual internal flash log into the microSD logdump.csv, then Sends this file to the actual upload channel (E-MAIL or FTP).</i>
<i>DOWNLOAD FW</i>	<p><i>The RTU will download from the FTP download folder the "RTUNAME_fwupdt.bin" firmware file (where RTUNAME is the name inserted in the "Cloud" SEAL section) Then (if the release is different from the installed) a firmware update is done.</i></p> <p><i>for example:</i></p> <div data-bbox="552 1637 1086 1697" style="border: 1px solid #ccc; padding: 5px; margin: 10px 0;"> RTU Name <input style="border: 1px solid #add8e6; padding: 2px 10px;" type="text" value="Datalogger005"/> </div> <p><i>The firmware file must be:</i></p> <p><i>"Datalogger005_fwupdt.bin"</i></p> <p><i>Note that if in the "Cloud" SEAL section you have flagged one of the followed flags:</i></p>

	<div style="border: 1px solid gray; padding: 2px; background-color: #f0f0f0; margin-bottom: 5px;"> <input type="checkbox"/> Add IMEI to Folders <input type="checkbox"/> Add MAC to Folders <input type="checkbox"/> Add RTU Name to Folders </div> <p>The firmware file must be only "fwupdt.bin"</p>
DOWNLOAD SETUP	<p>The RTU will download from the FTP download folder the "RTUNAME_setup.tag" setup file (where RTUNAME is the name inserted in the "Cloud" SEAL section) Then a configuration update is done.</p> <p>For example:</p> <div style="border: 1px solid gray; padding: 5px; margin: 10px 0;"> <div style="border-bottom: 1px solid gray; padding-bottom: 2px;">RTU Name</div> <div style="border: 1px solid blue; padding: 2px; display: inline-block;">Datalogger005</div> </div> <p>The setup file must be:</p> <p>"Datalogger005_setup.tag"</p> <p>Note that if in the "Cloud" SEAL section you have flagged one of the followed flags:</p> <div style="border: 1px solid gray; padding: 2px; background-color: #f0f0f0; margin: 10px 0;"> <input type="checkbox"/> Add IMEI to Folders <input type="checkbox"/> Add MAC to Folders <input type="checkbox"/> Add RTU Name to Folders </div> <p>The setup file name must be only "setup.tag"</p>
DOWNLOAD FW-SETUP	<p>The RTU will download from the FTP download folder the firmware AND the setup file. Then (if the release is different from the installed) the firmware and the configuration are updated.</p>
DOWNLOAD DATA	<p>The RTU will download from the FTP download folder the "data.bin" with the extended ring action phonebook (up to 1000 users). Then the extended phonebook is updated.</p>
RESET	<p>Reset the RTU</p>
NET	<p>RTU will send actual Ethernet and modem PPP IP address</p>

NOTE

If the command is not recognized by Z-GPRS3, an error SMS will be sent:

"COMMAND NOT RECOGNIZED"

You can configure Z-GPRS3 to send a confirmation (SMS or ring) when the command is successfully completed.

CAUTION!

When a command is successfully completed, a ring can only be generate when a voice SIM is used (data SIM do not permit voice call service).

20. EMERGENCY MODE

From firmware 1.2.1 Z-UMTS and 2.4.2 Z-GPRS3/Z-LOGGER3 it's possible to disable the SEAL program execution putting ALL dip switches to ON at boot-up.

This emergency mode is useful if a SEAL program does not allow to connect to SEAL (for example because the board will reboot continuously).

In emergency mode the SEAL program is not executed and the datalogger is stopped.

For enter in the emergency mode follow the steps:

- 1) Power Down the Board
- 2) Put ALL the dip switches to "ON"
- 3) Power ON the Board
- 4) PWR led will flash until you exit from the emergency mode
- 5) Now you can connect to SEAL and send a new program

For exit from the emergency mode:

- 1) Power Down the Board
- 2) Put ALL the dip switches to "OFF"
- 3) Power ON the Board
- 4) Now the SEAL program is in execution

21. Z-GPRS3 POWER ESTIMATE FOR USE WITH SOLAR PANELS

The following table is obtained using a Modbus TCP-IP client connection with the Modbus TCP-IP Z-GPRS3 server using the GPRS connection.

Test condition:

-internet connection is always ON

-Outputs OFF

-No Ethernet connected

-No 12VDC (Screw 1) connected

VOLTAGE	GSM SIGNAL	MODBUS REQUEST EVERY	MODBUS REGISTERS REQUEST	TYPICAL AVERAGE POWER
12V DC	-56 dBm (7/7)	60 seconds	10	1,49 W
12V DC	-86 dBm (3/7)	60 seconds	10	1,5 W
12V DC	-86 dBm (3/7)	Continuous	10	1,9 W

22. TROUBLESHOOTING

PROBLEM	SOLUTION
<p>Sending the SMS command:</p> <p>email test</p> <p>no email reaches the administrator's email address</p>	<ul style="list-style-type: none"> -Make sure the set APN corresponds to the mobile service provider's and whether access requires authorisation. See: http://wiki.apnchanger.org/Main_Page -Make sure the GSM signal is over 2/7 -The email ended up in SPAM -The SMTP server supports SSL protection and the gateway was not correctly set
<p>Using the configuration software in the "Test configuration" section when you launch the command:</p> <p>TEST E-MAIL COMMAND</p> <p>no e-mail arrives at the administrator e-mail address</p>	<p><i>If you send Log via Ethernet, Seneca recommended to use an owner SMTP server.</i></p> <ul style="list-style-type: none"> -The email is in the SPAM directory -The SMTP server supports only SSL security, in the ethernet port or Modem PPP connection you can not enable SSL protection
<p>Sending the SMS command:</p> <p>ftp test</p> <p>no ftp file reaches the set ftp server</p>	<ul style="list-style-type: none"> -The FTP server folder does not exist. Create the folder on the ftp server first. -Make sure the ftp server IP address/name are correct -Make sure the ftp server login user name/password are correct

<p>Using the configuration software in the "Test configuration" section when you launch the command</p> <p>TEST FTP</p> <p>no ftp file arrives in the configured ftp server</p>	<ul style="list-style-type: none"> -The folder on the FTP server on which you created the file does not exist, first create the folder in the ftp server -Check the correctness of the IP / name of the FTP server -Make sure that the username / password to access the ftp server are correct
<p>The GSM signal is always 0/7 and the GSM led continues to flash fast</p>	<ul style="list-style-type: none"> -The inserted SIM is not recognised. Clean or replace the SIM -The SIM PIN is enabled. Insert the SIM in a mobile phone and disable the PIN or enable it and insert the PIN code in the setup software
<p>The GSM signal is too low</p>	<ul style="list-style-type: none"> -Wait at least 10 minutes from turning on the device before reading the GSM value -Try using another mobile service provider's SIM -Move the Z-GPRS3 installation -Use an optional external antenna: for further information, contact Seneca or visit the Z-GPRS3 section at www.seneca.it.
<p>Residual credit is not sent for the SIM</p>	<ul style="list-style-type: none"> -Check the method used to receive residual credit from the mobile service provider (ring or SMS, SMS request text). -The SIM is not top-up but subscription
<p>Z-GPRS3 or Z-UMTS worked correctly for a few days/months but stopped sending SMS and logs.</p>	<ul style="list-style-type: none"> -No SIM credit. Top-up the SIM card. -The SIM card expired, replace the SIM card or contact your mobile phone provider.
<p>You get the "NTP error"</p>	<p>The clock synchronization is activated, via ethernet this is done via NTP (network time protocol), but you can not contact the NTP server:</p> <ul style="list-style-type: none"> -Make sure that the UDP port 123 is open -Check the configured NTP server address

<p>The device is unable to send emails or ftp files on the Internet through the Ethernet port but a PC connected to the same LAN can send emails and ftp files.</p>	<ul style="list-style-type: none">-Try to change Router/Modem-Update the Router/Modem Firmware-Keep open on the router the ports: UDP/TCP 25 UDP/TCP 21 UDP 123
---	--