USER MANUAL

MSC-D

MULTIFUNCTION SMART CALIBRATOR



SENECA S.r.I.

Via Austria 26 – 35127 – Z.I. - PADOVA (PD) - ITALY Tel. +39.049.8705355 – 8705355 Fax +39 049.8706287

www.seneca.it

User Manual

CAUTION

SENECA does not guarantee that all specifications and/or aspects of the product and firmware, included in them, will meet the requirements of the actual final application even if the product referred to in this documentation is in compliance with the technological state of the art.

The user assumes full responsibility and/or risk with regard to the configuration of the product to achieve the intended results in relation to the specific installation and/or end application.

SENECA may, with prior agreement, provide consultancy services for the successful completion of the final application, but under no circumstances can it be held responsible for its proper functioning.

The SENECA product is an advanced product, the operation of which is specified in the technical documentation supplied with the product itself and/or can be downloaded, if desired prior to purchase, from the www.seneca.it website.

SENECA has a policy of continuous development and accordingly reserves the right to make and/or introduce - without prior notice - changes and/or improvements to any product described in this documentation.

The product described in this documentation may solely and exclusively be used by personnel qualified for the specific activity and in accordance with the relevant technical documentation, with particular attention being paid to the safety instructions.

Qualified personnel means personnel who, on the basis of their training, competence and experience, are able to identify risks and avoid potential hazards that could occur during the use of this product.

SENECA products may only be used for the applications and in the manner described in the technical documentation relating to the products themselves.

To ensure proper operation and prevent the occurrence of malfunctions, the transport, storage, installation, assembly, maintenance of SENECA products must comply with the safety instructions and environmental conditions specified in this documentation.

SENECA's liability in relation to its products is governed by the general conditions of sale, which can be downloaded from www.seneca.it.

Neither SENECA nor its employees, within the limits of applicable law, will in any case be liable for any lost profits and/or sales, loss of data and/or information, higher costs incurred for goods and/or replacement services, damage to property and/or persons, interruption of activities and/or provision of services, any direct, incidental, pecuniary and non-pecuniary, consequential damages in any way caused and/or caused, due to negligence, carelessness, incompetence and/or other liabilities arising from the installation, use and/or inability to use the product.

CONTACT US	
Technical support	supporto@seneca.it
Product information	commerciale@seneca.it







Document revisions

DATE	REVISION	NOTES	AUTHOR
28/01/2025	0	First revision	MM
18/02/2025	1	Modified for firmware release 130	MM
08/09/2025	2	Values correction chapter 2 measurement of signals.	AC

This document is the property of SENECA srl. Copies and reproduction are prohibited unless authorised.



TABLE OF CONTENTS

1.	DEVICE HARDWARE REVISION	6
2.	CALIBRATOR ACCURACY AND RESOLUTION	7
3.	SAFETY INFORMATION	10
4.	DESCRIPTION	12
4.1.	LEDS, BUTTONS, PORTS AND BUSHINGS	13
4.1.1	1. ON/OFF BUTTON AND LED	13
4.1.2	2. PORTS, SOCKETS AND BUSHINGS	14
5.	USER GUIDE	15
6.	USING THE DISPLAY	16
6.1.	Home screen	
6.1.1	1. THE SCROLLING MENU	17
7.	MAIN MENU	
7.1.	GENERAL SETTINGS	19
7.2.	ETH. SETTINGS	
7.3.	WIFI. SETTINGS	
	1. WI-FI STATION	
	2. WI-FIACCESS POINT	
7.3.3 7.4.	3. WI-FI SCAN	
7. 4 . 7.5.	FACTORY SETTINGS	
8.	CALIBRATOR FUNCTIONS	24
8.1.	HOW THE CALIBRATOR WORKS AS A SIGNAL METER	
8.1.1	1. CHECKS COMMON TO ALL MEASUREMENTS	25
8.1.2	2. DATALOGGER	28
8.2.	OPERATION OF THE CALIBRATOR AS A SIGNAL GENERATOR	28
	1. CHECKS COMMON TO ALL GENERATIONS	
8.2.2	2. THE RAMP GENERATOR	30
9.	THE WEBSERVER	33
9.1.	LOCAL/REMOTE CONTROL OF THE CALIBRATOR	
9.2.	ACCESS TO THE WEB SERVER	34
10.	MEASUREMENT AND GENERATION ERRORS	35





User Manual


11.	ETHERNET PORT	35
12.	FIRMWARE UPDATE	35
13.	SUPPORTED MODBUS COMMUNICATION PROTOCOLS	36
13.1.	SUPPORTED MODBUS FUNCTION CODES	
14.	INFORMATION ABOUT MODBUS REGISTERS	37
14.1.	NUMBERING OF "0-BASED" OR "1-BASED" MODBUS ADDRESSES	
14.2.	NUMBERING OF MODBUS ADDRESSES WITH "0-BASED" CONVENTION	
14.3.	NUMBERING OF MODBUS ADDRESSES WITH "1 BASED" CONVENTION (STANDARD)	
14.4.	BIT CONVENTION WITHIN A MODBUS HOLDING REGISTER	
14.5.	MSB and LSB BYTE CONVENTION WITHIN A MODBUS HOLDING REGISTER	40
14.6.	REPRESENTATION OF A 32-BIT VALUE IN TWO CONSECUTIVE MODBUS HOLDING REGISTERS	40
15.	MANAGING MSC-D FROM MODBUS REGISTERS	41
15.1.	DESCRIPTION	41
15.2.	USE OF MSC TO TAKE MEASUREMENTS	41
15.2.	1. MEASUREMENT MIN/MAX/AVG VALUES	41
15.2.		
15.2.3		
15.2.		
15.2.		
15.2.0		
15.2.		
15.2.8		
15.2.		
	USE OF MSC TO GENERATE SIGNALS	
15.3.		
15.3.		
15.3.		
15.3.4		
15.3.		
15.3.0		
15.3.	7. NUMBER OF PULSES GENERATION	58



1. DEVICE HARDWARE REVISION

With a view to continuous improvement, Seneca updates and makes the hardware of its devices increasingly more sophisticated. It is possible to know the hardware revision of a product via the label on the side of the device.

A label example is for instance:



The label also shows the firmware revision present in the device (in this case 2.0.1.0) at the time of sale, the hardware revision (in this case) is E00.

To improve performance or extend functionality, Seneca recommends updating the firmware to the latest available version (see the section dedicated to the product on www.seneca.it).



2. CALIBRATOR ACCURACY AND RESOLUTION

The accuracy and resolution of the signals are represented in the following tables:

SIGNAL GENERATION

		RANGE	ACCURACY*	RESOLUTION			CMRR-
FUNCTIONS	M.U.	(Generation)	(Generation)	(Generation)	Note	STANDARD	NMRR
VOLTAGE [hi		0-26					
range]	[dc V]	(minimum)	0,02% + 3 mV	1 mV	1	-	>100 dB
VOLTAGE					_		
[lo range]	[dc mV]	-10 +90	0.03% + 15 μV	5 μV	2	-	>100 dB
ACTIVE			0.040/ 0.4				66 15
CURRENT	[dc mA]	0.1 ÷ +24	0.04% + 3 μA	1 μΑ	3	-	>60 dB
PASSIVE	[A]	0.4 2.4	0.040/ . 2 . 4	4 4	4,21,2		
CURRENT	[dc mA]	0.1 ÷ +24	0.04% + 3 μΑ	1 μΑ	2	-	>60 dB
Pt100	[°C]	-200 ÷ +859	0.03% + 0.2°C	0,1 °C	5,19	IEC 60751	>140 dB
Pt500	[°C]	-200 ÷ +859	0.03% + 0.2°C	0,1 °C	5,20	IEC 60751	>140 dB
Pt1000	[°C]	-200 ÷ +859	0.03% + 0.2°C	0,1 °C	5,20	IEC 60751	>140 dB
						GOST	
CU50, CU100	[°C]	-180 ÷ +200	0.03% + 0.2°C	0,1 °C	15,19	6651-2009	>140 dB
Ni100, Ni120	[°C]	-80 ÷ +260	0.03% + 0.2°C	0,1 °C	16,19	DIN 43760	>100 dB
						EN 60584-	
TERMOCUPLE J	[°C]	-210 ÷ +1200	0.03% + 0.2°C	0,1 °C	12,2	1:1997	>100 dB
						EN 60584-	
TERMOCUPLE K	[°C]	-270 ÷ +1372	0.03% + 0.2°C	0,1 °C	12,2	1:1997	>100 dB
						EN 60584-	
TERMOCUPLE T	[°C]	-270 ÷ +400	0.03% + 0.1°C	0,1 °C	12,2	1:1997	>100 dB
						EN 60584-	
TERMOCUPLE E	[°C]	-270 ÷ +1000	0.03% + 0.2°C	0,1 °C	12,2	1:1997	>100 dB
				_		EN 60584-	
TERMOCUPLE N	[°C]	-270 ÷ +1300	0.03% + 0.2°C	0,1 °C	12,2	1:1997	>100 dB
						EN 60584-	
TERMOCUPLE R	[°C]	-50 ÷ +1768	0.03% + 0.3°C	0,5 °C	12,2	1:1997	>100 dB
	[0.0]			0 = 00	400	EN 60584-	400 15
TERMOCUPLE S	[°C]	-50 ÷ +1768	0.03% + 0.3°C	0,5 °C	12,2	1:1997	>100 dB
	[0.0]	0 . 4000	0.000/ 0.000	0.5.00	40.0	EN 60584-	400 10
TERMOCUPLE B	[°C]	0 ÷ +1820	0.03% + 0.3°C	0,5 °C	12,2	1:1997	>100 dB
						GOST	
	[00]	200 + 1900	0.030/ 1.0.15°C	0.1 %	12.2	8.585-	>140 dp
TERMOCUPLE L	[°C]	-200 ÷ +800	0.03% + 0.15°C	0,1 °C	12,2	2001	>140 dB
LOAD CELL 350 Ohm	[m\//\/]	0 ÷ +3	0.05%	0,001	12.0		>100 dB
PULSES/FREQU	[mV/V]	U 7 #3	0.05%	0,001	13,8	-	>100 MB
ECY	[Hz]	0.1÷1000	0.02%	SEE MANUAL	1	_	
ECT	[П۷]	0.1-1000	0.02/0	JLE IVIANUAL	1	-	-





SIGNAL MEASUREMENT

						Notes	
		RANGE	ACCURACY	RESOLUTION		(Measurement	CMRR-
FUNCTIONS	M.U.	(Measurement)	(Measurement)	(Measurement)	STANDARD)	NMRR
VOLTAGE [hi	[dc	0-26					>100
range]	V]	(minimum)	0,02% + 3 mV	1 mV	-	9	dB
VOLTAGE [lo	[dc						>100
range]	mV]	-10 +90	0.02% + 10 μV	5 μV	-	9	dB
ACTIVE	[dc						
CURRENT	mA]	0 ÷ +24	0.04% + 3 μΑ	1 μΑ	-	17	>60 dB
PASSIVE	[dc						
CURRENT	mA]	0 ÷ +24	0.04% + 3 μA	1 μΑ	-	18	>60 dB
							>140
Pt100	[°C]	-200 ÷ +850	0.03% + 0.2°C	0.03 °C	IEC 60751	6	dB
							>140
Pt500	[°C]	-200 ÷ +850	0.03% + 0.2°C	0.1 °C	IEC 60751	6	dB
							>140
Pt1000	[°C]	-200 ÷ +850	0.03% + 0.2°C	0.03 °C	IEC 60751	7	dB
					GOST		>140
CU50, CU100	[°C]	-180 ÷ +200	0.03% + 0.2°C	0.06 °C , 0.03 °C	8651-2009	6,15	dB
							>100
Ni100, Ni120	[°C]	-60 ÷ +250	0.03% + 0.2°C	0.02 °C	DIN 43760	6,16	dB
TERMOCUPLE		-210 ÷			EN 60584-		>100
J	[°C]	+1200	0.03% + 0.2°C	0.01 °C	1:1997	9,12	dB
TERMOCUPLE		-200 ÷			EN 60584-		>100
K	[°C]	+1372	0.03% + 0.2°C	0.05 °C	1:1997	9,12	dB
TERMOCUPLE					EN 60584-		>100
Т	[°C]	-200 ÷ +400	0.03% + 0.1°C	0.05 °C	1:1997	9,12	dB
TERMOCUPLE		-200 ÷			EN 60584-		>100
E	[°C]	+1000	0.03% + 0.2°C	0.05 °C	1:1997	9,12	dB
TERMOCUPLE		-200 ÷			EN 60584-		>100
N	[°C]	+1300	0.03% + 0.2°C	0.05 °C	1:1997	9,12	dB
TERMOCUPLE					EN 60584-		>100
R	[°C]	-50 ÷ +1768	0.03% + 0.3°C	0.05 °C	1:1997	9,12	dB
TERMOCUPLE					EN 60584-		>100
S	[°C]	-50 ÷ +1768	0.03% + 0.3°C	0.05 °C	1:1997	9,12	dB
TERMOCUPLE					EN 60584-		>100
В	[°C]	250 ÷ +1820	0.03% + 0.3°C	0.05 °C	1:1997	9,12	dB
TERMOCUPLE					Gost 8.585-		>140
L	[°C]	-200 ÷ +800	0.03% + 0.15°C	0.05 °C	2001	9,12	dB
LOAD CELL	[mV/						>100
350 Ohm	[V]	0 ÷ +2.4	0.05%	0.001	-	9,14	dB
PULSES/FREQ	•					,	
UECY	[Hz]	0.1÷10000	0.03% + 3 LSD	10e-6 Hz	-	10,11	-





NOTE

- 1 loutMAX = 20mA per V < 20; loutMAX =10mA per 20 < V <25; loutMAX = 5mA per V > 25; output impedance < 50 m Ω
- 2 IoutMAX = 10mA; output impedance < 100 m Ω
- 3 RLoad < $1K\Omega$
- 4 3V minimum loop voltage, 28V maximum
- $5 \alpha = 0.00385$
- 6 Measurement current: 1 mA
- 7 Measurement current: 250 uA
- 8 Excitation voltage: from 5 to 10 V
- 9 Input impedance: ~ 10 $M\Omega$
- 10 Input impedance: 1 M Ω ; Voltage from 1 to 24 V
- 11 Max frequency measurement 1 kHz
- 12 Cold junction error: 1°C between 10 and 35°C ambient, 2°C between -20 and 10°C and between 35 and 50°C ambient
- 13 Output impedance: 300 Ω
- 14 Excitation voltage < 8V
- $15 \alpha = 0.00428$
- $16 \alpha = 0.006178$
- 17 Voltage drop < 3.5 V
- 18 Minimum voltage supplied: 24 V
- 19 Accuracy defined with 1 mA measurement current and respected polarity
- 20 Accuracy defined with 250 uA measurement current and respected polarity
- 21 Output impedance: 3.75 $M\Omega$
- 22 Accuracy defined with 26 V loop supply voltage



3. SAFETY INFORMATION

This manual contains safety rules that must be complied with to safeguard personal safety and to prevent damage to property. The indications to be followed to guarantee personal safety are highlighted by a triangle with the following meanings:



The symbol associated with the word 'warning' indicates conditions or actions that put the user's safety at risk.



The symbol associated with the word 'caution' indicates conditions or actions that might damage the calibrator or equipment tested.

A QUALIFIED PERSONNEL

The product covered by this documentation may only be used by qualified personnel for the respective assigned task, in compliance with the documentation relating to the task, and especially with the safety warnings and the precautions contained therein. By virtue of their training and experience, qualified personnel can recognize the risks related to the use of this product and avoid possible dangers.

DISCLAIMER

We have checked that the contents of this documentation correspond to the hardware and software described. However, since we cannot rule out any differences, we cannot guarantee a perfect match. However, the content of this documentation is periodically checked and any corrections or changes are inserted in subsequent editions.

WARNING

- Do not apply different voltages or higher voltages than indicated between terminals, or between any terminal and earth (voltages greater than 50Vdc)
- Do not use the calibrator if damaged, or if signs of possible damage are visible on it.
- Do not remove the internal battery.
- Do not use the calibrator if it runs abnormally.
- Use the reset button if there is an anomaly in the operation.
- Do not touch the calibrator terminals during use
- To carry out the measurements, use the cables supplied or anyway adequate for the measurements to be taken.
- Select the appropriate range for the desired measurement or generation.



ACAUTION

- Make sure the internal battery is charged if you intend to use the calibrator without power from the USB port
- Use the calibrator as described in this manual.
- Before each measurement or generation, refer to the electrical connections shown in the manual.
- Do not use the calibrator in environments containing combustible/explosive dust, gas or vapour.

The MSC calibrator has been designed according to EN 6101-1 standards



User Manual

4. DESCRIPTION

The MSC calibrator is a portable multi-function instrument for the generation and measurement of signals commonly found in automation systems.

It was designed to help professionals who have to verify and develop signal processing equipment connected to automatic control devices.

Unlike what the market offers, the MSC calibrator combines simulations and measurements in one instrument through an intuitive and modern interface.

The MSC multifunction process calibrator is a hand-held instrument, powered by rechargeable batteries, used to measure and generate electrical quantities.

Calibrator also has the following characteristics:

- Input/output terminal for thermocouples (TC) and isothermal internal block with automatic temperature compensation of the reference junction.
- 4 standard 4mm diameter bushings for 2-3-4 wire sizes. Protection against overvoltages up to 250 Vac.
- Ethernet and Wi-Fi connection.
- Management of universal signals (analog, digital, pulse, electrical, weight, temperature)
- High accuracy class: 0.05% basic class for each type of input/output.
- Micro USB connector for power supply.
- Ethernet port and Wi-Fi for connection to PCs or mobile devices
- Modbus TCP-IP protocol supported
- Colour touch screen

The analog signals managed both in measurement and generation are:

- mA (dc) current
- V, mV (dc) voltage
- Thermocouples, two/three or four-wire heating elements
- 350 Ω bridge extensometer (LOAD CELL)

The following are also managed:

- Pulse generation with duration, voltage amplitude and variable duty cycle
- Pulse measurement with adjustable threshold
- Frequency measurement and generation

The device is protected against damage due to incorrect connections such as short circuits and overvoltages applied to the inputs (e.g. 230 Vac).

The device supports the industrial Modbus TCP-IP protocol and can therefore be controlled via Ethernet or Wi-Fi from machines external to the device.

Also via the Ethernet or Wi-Fi port it is also possible to connect multiple calibrators to the devices and control them individually.

MSC-D



4.1. LEDS, BUTTONS, PORTS AND BUSHINGS


4.1.1. ON/OFF BUTTON AND LED



- 1 Power button, press the button until the screen lights up and then release. Press again for a few seconds to turn off the calibrator.
- 2 Device Power LED
- 3 Active datalogger LED
- 4 External Power Supply LED



4.1.2. PORTS, SOCKETS AND BUSHINGS



- 1 Socket for thermocouple measurement/generation
- 2 Measurement/generation bushing -EX
- 3 Measurement/generation bushing -SN
- 4 Measurement/generation bushing +SN
- 5 Measurement/generation bushing +EX
- 6 10/100Mbit Ethernet port
- 7 LED status of internal battery charging, it lights up if the battery is charging, it turns off if charging is complete
- 8 Micro USB connector for power supply
- 9 Reset button

User Manual

5. USER GUIDE

The calibrator is a device that can measure or generate electrical quantities to test devices. To proceed with the correct use of the instrument, make sure to follow the following steps:

- Turn on the device.
- Wait at least 5 minutes for the appliance temperature to stabilize.
- Connect the cables correctly, according to the type of measurement or generation to be carried out: refer to the connection diagrams

It is however necessary, before use, to make sure that the battery is fully charged so as to guarantee its life of the generations or measurements that will be carried out. Before each use it is advisable to recharge the instrument using the USB cable supplied, until the LED battery charge indicator on the bottom of the calibrator goes off. The calibrator can maintain the signals to be generated (set by the user) within a determined error range. During generation, the calibrator will constantly check the generated signal, warning about any generation error (where provided for).



The calibrator is protected against the risk of applying temporary overvoltages. However, it is good to remember that in this case the device needs 15-20 minutes to restore the normal conditions. If this period of time is not observed, the accuracy of the measurements and/or generations cannot be guaranteed.



Since the negative of the MSC-D device is not at the same potential as the negative of the USB port, it is not advisable to connect it to the USB port of a PC, since this working condition may interfere with the correct operation of the calibrator.



6. USING THE DISPLAY

The display is equipped with capacitive touch and allows access to the device's functions.

6.1. Home screen

The home screen is as follows:



User Manual

Where:

- 1 Icon of the type of port enabled between Ethernet, Wi-Fi Station or Wi-Fi Access Point
- 2 Icon with the battery charge level
- 3 Button for the signal measurement function menu
- 4 Button for the signal generation function menu
- 5 Scrolling menu

In addition to this, there is some basic information about the device.




6.1.1. THE SCROLLING MENU

The scrolling menu is always present in the device pages:



Once pressed, it allows you to select the following icons:



Where:

- 1 Returns to the previous screen
- 2 Returns to the main screen
- 3 Enters the options (the options change depending on the screen)
- 4 Displays the connection information (depending on the type of generation / measurement being performed)
- 5 Closes the scrolling menu



7. MAIN MENU

The main menu can be accessed from the calibrator's main page by pressing the scrolling menu button:





The menu allows you to select 3 different categories of configurations:



7.1. GENERAL SETTINGS

Groups the following general settings:

LANGUAGE

Allows you to choose the interface language

ENABLE ERROR SOUND ALARM

Enables or disables the sound alarm in the event of a measurement/generation error

ENABLE BATTERY SOUND ALARM

Enables or disables the sound alarm in the event of a low battery

ENABLE SOUND DURING SWITCH-ON

Enables or disables the emission of a sound during switch-on

TYPE OF SWITCH-ON

Allows you to select whether the switch-on is Portable or Automatic.

In the case of Portable switch-on, even if external power is supplied, the device will not switch on unless the appropriate button is pressed. To switch off, you must also press the appropriate button.

In the case of Automatic switch-on, the device will switch on automatically once the power cable is inserted and will switch off once the external power is disconnected (to be used on automatic testing machines).

USE ROTARY MEMORY BUFFER

When using the datalogger the device saves the data in an internal memory, once finished the instrument can overwrite (rotary buffer ON) or not (rotary buffer OFF) the data on the recordings already made.

BRIGHTNESS

Sets the screen brightness, the higher the brightness the shorter the battery life.

ENABLE AUTO POWER OFF

This function allows you to set a time after which, if there are no interactions with the screen, the instrument will automatically turn off. In the case of remote connection, disable this function.

DATALOGGER SAMPLING TIME

Sets the datalogger sampling time

TEMPERATURE MEASUREMENT UNIT

Selects the temperature measurement unit

DISPLAY OFF





MSC-D

Selects the time in minutes after which the screen turns off if it has not been touched. Once the screen is off, to turn it back on just touch it. This parameter is important for battery life.

REMOTE CONTROL

Allows you to enable or disable the remote control function from the device's web server.

When the remote control function is active, it is not possible to modify the generation or measurement of signals locally; when the function is deactivated, it is not possible to modify the generation or measurement of signals locally. The basic functions of the web server (firmware update, configuration and download of log files) are, however, always available.



7.2. ETH. SETTINGS

Allows you to set the configuration of the Ethernet port



The Ethernet port and WIFI port cannot be enabled at the same time

Ethernet Enabled

Enables or disables the Ethernet port

DHCP

Enables the DHCP client to retrieve the IP address automatically, if disabled the IP is static and it is possible to set the parameters:

ΙP

IP static address of the Ethernet port

MASK

Mask of the Ethernet port

GW

Ethernet port Gateway

DNS

Ethernet port Domain Name System

7.3. WIFI. SETTINGS

Allows you to set the configuration of the WI-FI port



The Ethernet port and WIFI port cannot be enabled at the same time

The calibrator's Wi-Fi port can be configured in Wi-Fi "Station" and Wi-Fi "Access Point" modes.

In Station mode, the Wi-Fi port connects to an existing Wi-Fi router (access point).

In Access Point mode, the Wi-Fi port accepts connections from other devices, allowing Wi-Fi connections from devices such as PCs or mobile devices equipped with Wi-Fi.

User Manual

7.3.1. WI-FI STATION

It allows the calibrator to connect to an existing Wi-Fi network through a router set in access point mode. When the mode is activated, it is possible to manually enter the configuration of the router to connect to.

7.3.2. WI-FIACCESS POINT

It allows the creation of a new Wi-Fi network to which Wi-Fi devices such as PCs or tablets, cell phones etc. can be connected.

The calibrator's IP address is:

192.168.4.1

7.3.3. **WI-FI SCAN**

When the Station or Access Point mode is activated, it is possible to scan the network to connect the device to an existing Wi-Fi network.

Press the "SCAN" button and wait for the found networks to be displayed. Then enter the network password (the other parameters are automatically retrieved).

At this point the calibrator will restart in Wi-Fi Station mode and connect to the indicated network.



It is not possible to activate WI-FISCAN mode without first activating the WI-FI port in Station or Access Point mode



7.4. RTC SETTINGS

Allows you to set the date and time of the device to be used for the datalogger's time tag. In addition to date insertion, it is possible to enable the connection with an NTP server in order to acquire the date via internet.

User Manual

NTP ENABLED

If not enabled ON/OFF, if OFF if OFF, allows to manually enter date/time.

SRV1

IP address of the primary NTP Server

SRV2

IP address of the secondary NTP server (to be used in case of primary fail)

SYNCHRONISATION

Set date/time synchronisation interval

GMT (min)

Sets the time zone with respect to GMT in minutes (e.g. for Italy GMT= 60 minutes in the case of standard time)

7.5. FACTORY SETTINGS

Resets all configuration parameters to default.



8. CALIBRATOR FUNCTIONS

MEASUREMENT FUNCTIONS:

The MSC calibrator allows measuring the following signals:

- Passive current (with power supplied externally to the calibrator)
- Active current (with power supplied by the calibrator)
- Voltage 0 V/ +27 V
- Voltage -10 mV/ +90 mV
- Thermocouple
- Thermoresistance
- Load cell (strain gauge)
- Frequency/pulses

GENERATION FUNCTIONS

The MSC calibrator allows generating the following signals:

- Passive current (with power supplied externally to the calibrator)
- Active current (with power supplied by the calibrator)
- Voltage 0 V/ +27 V
- Voltage -10 mV/ +90 mV
- Thermocouple
- Thermoresistance
- Load cell
- Frequency/pulses



8.1. HOW THE CALIBRATOR WORKS AS A SIGNAL METER

8.1.1. CHECKS COMMON TO ALL MEASUREMENTS

The following are the checks that are common to all measurements:



Where:

- 1 Type of measurement
- 2 Primary measured value
- 3 Button to switch between primary and secondary measurement
- 4 Minimum average maximum statistical values
- 5 Datalogger/Statistics menu button
- 6 Secondary measured value




Pressing the Datalogger/Statistics menu button gives:



Where:

- 1 Start/Stop button of the data logger
- 2 Button to delete all logs in the memory
- 3 Display of the statistics of the data logger
- 4 Resets the Minimum Average Maximum values
- 5 Pauses or restarts the calculation of the Minimum Average Maximum values

In all measurements by pressing the button:



It is possible to press the icon and access a whole series of configuration parameters relating to the measurement in use such as the measurement filtering setting, the type of cold junction etc.





Wait until the device reaches a stable thermal condition before taking measurements with the thermocouples (typically at least 30 minutes).

ATTENTION!

If the thermocouple does not have its own connector, use the innermost bushings SN+ SN- as an alternative, bearing in mind that the compensation of the cold junction in this case may be less precise.

ATTENTION!

The 4-wire measurement of the load cell is influenced by the resistance of the conductors supplying it.

If it is not possible to shorten the connections between the load cell and the MSC calibrator, by
measuring the resistance only of the conductors that supply the load cell (conductors +EX and -EX),
the correction coefficient can be calculated:

$$K = \frac{350 + R_{+EX} + R_{-EX}}{350}$$

The obtained coefficient must be multiplied with the value measured by the calibrator to obtain the real value.



8.1.2. DATALOGGER


The calibrator allows you to perform recording sessions using the appropriate button as already described. The minimum acquisition time is 1 second.

The download of the datalogger file in csv text format is possible via the appropriate webserver page.

8.2. OPERATION OF THE CALIBRATOR AS A SIGNAL GENERATOR

8.2.1. CHECKS COMMON TO ALL GENERATIONS

The following are the checks that are common to all generations:



Where:

- 1 Generation type
- 2 Buttons to increase the value of the single digit
- 3 Output generated value
- 4 Buttons to decrease the value of the single digit
- 5 Button to switch between primary and secondary generation value
- 6 Ramp menu
- 7 Enables or disables the output
- 8 Quick keys to generate the output in percentage
- 9 Keyboard to enter the value to generate
- 10 Secondary value generated



In all generations by pressing the button:



You can press the icon and access a whole series of configuration parameters relating to the generation in use.

ATTENTION!

It is important to note that in frequency generation the time resolution according to which the square wave signal is generated is 50 µs.

This implies an error that is dependent on the numeric value set.

For instance, you want to generate a signal with a frequency of 150 Hz whose corresponding period is 6,666 ms; the number of counts necessary to obtain this frequency is obtained through:

The system then rounds off to the nearest whole number (133) which it will use to generate the output signal.

The output frequency will have the value:

$$Fout = \frac{1}{133 * 50 \ \mu s} = 150.37 \ Hz$$

The firmware will automatically show the value actually generated.



8.2.2. THE RAMP GENERATOR

The calibrator allows you to generate ramps through the interface described here











Where:


- 1 Activates or deactivates the ramp loop (if OFF once the ramp is finished it does not restart automatically)
- 2 Currently generated value
- 3 Start/Stop ramp
- 4 Loads a ramp configuration from a previously saved file
- 5 Saves the current ramp configuration to a file

Sends the current ramp configuration to the motherboard

- 6 N-th ramp point
- 7 Time in seconds
- 8 % value of the generation compared to full scale
- 9 Value that the output value must take on
- 10 Previous ramp point
- 11 Next ramp point



For example, we want to generate a voltage ramp of the type:



We then enter the coordinates of the points, the starting point of the ramp (time = 0) has the value of 5 V, we then enter point 1 with time = 0s, Value = 5V

After 5 seconds the value is stable at 5V so we enter time = 5s, value = 5V

After another 5 seconds the value goes from 6V so we enter time = 5s, value = 6V until we obtain the following table:

Point Number	Time [s]	Value [V]
1	0	5
2	5	5
3	5	6
4	5	1
5	5	3

Now we can save this ramp in the file from 1 to 5 so that we can load it in the future with the "Save" button.

Now we send the ramp to the motherboard with the "Send" button.

At this point we are ready to generate the ramp with the "Start" button.

To repeat the execution of the same ramp it is not necessary to send the ramp to the motherboard again but it will be enough to press the "Start" button again.

9. THE WEBSERVER

The calibrator has a webserver that allows you to:

- Control and configure the calibrator remotely
- Download the data from the datalogger in CSV text format
- Update firmware

9.1. LOCAL/REMOTE CONTROL OF THE CALIBRATOR

The webserver allows you to remotely control and configure the generator using a web browser. Using Wi-Fi, for example, you can control the calibrator from a mobile phone.

The graphic interface is similar to that of the display and allows the same functions.

To control the calibrator remotely, you need to set the "Remote Control" parameter in the "General Settings" menu to "ON".



It is not possible to control the calibrator simultaneously from the local display and from the webserver.

If the "Remote Control" parameter is "ON" the message "REMOTE MODE" appears on the initial page of the display. To restore the display operation, it is necessary to return the "Remote Control" parameter to "OFF".







9.2. ACCESS TO THE WEB SERVER

To access the webserver, you need to know the IP address of the device and have a web browser (for example Chrome).

In the case of connection via ethernet port with the default address, access to the webserver occurs at the address:

http://192.168.90.101

In case of connection via Wi-Fi port with the calibrator in Access Point mode, the calibrator web server address is:

http://192.168.4.1

In the case of connection via Wi-Fi port with the calibrator in Station mode, the IP address is typically provided by the router's DHCP server. To find out the set IP address, access the WI-FI Station menu of the display's main menu.

Once you have accessed the webserver, when prompted for the user name and password, enter:

User name: admin Password: admin



10. MEASUREMENT AND GENERATION ERRORS

The calibrator can detect errors both in generation and measurement of a signal.

The table shows the types of errors detected:

TYPE OF ERROR	MEANING
Generation error	The set generation is not guaranteed within the
	declared error
Measurement error	The measured signal is out of range

An error is also detected when the externally generated loop voltage exceeds 29 V.

11. ETHERNET PORT

The factory configuration of the Ethernet port is:

STATIC IP: 192.168.90.101 SUBNET MASK: 255.255.255.0 GATEWAY: 192.168.90.1

Multiple devices must not be inserted on the same network with the same static IP.



DO NOT CONNECT 2 OR MORE FACTORY-CONFIGURED DEVICES ON THE SAME NETWORK, OR THE

DEVICE WILL NOT WORK

(CONFLICT OF IP ADDRESSES 192.168.90.101)

12. FIRMWARE UPDATE

In order to improve, add or optimize the functions of the product, Seneca releases firmware updates on the device section on the www.seneca.it website

The firmware update is performed via the webserver.



IN ORDER NOT TO DAMAGE THE DEVICE, THE BATTERIES MUST BE CHARGED AND THE EXTERNAL POWER SUPPLY MUST BE PRESENT.

It is possible to update both the display board firmware and the motherboard firmware.

The display board firmware update can be done directly from the webserver, the motherboard update is done via a command sent from the webserver and then connecting the USB port of the device to a software on the PC.



User Manual

13. SUPPORTED MODBUS COMMUNICATION PROTOCOLS

The Modbus communication protocols supported are:

 Modbus TCP-IP Server (from Ethernet port or Wi-Fi) with support for up to 8 remote Modbus TCP-IP Clients

For more information on these protocols, see the website:

http://www.modbus.org/specs.php.

13.1. SUPPORTED MODBUS FUNCTION CODES

The following Modbus functions are supported:

Read Holding Registers (function 3)
 Write Single Register (function 6)
 Write Multiple Registers (function 16)



All 32-bit variables are contained in 2 consecutive Modbus registers All 64-bit variables are contained in 4 consecutive Modbus registers



14. INFORMATION ABOUT MODBUS REGISTERS

The following abbreviations are used in the following chapter:

MS	Most Significant
LS	Least Significant
MSBIT	Most Significant Bit
LSBIT	Least Significant Bit
MMSW	"Most" Most Significant Word (16bit)
MSW	Most Significant Word (16bit)
LSW	Least Significant Word (16bit)
LLSW	"Least" Least Significant Word (16bit)
RO	Read Only
RW*	Read-Write: REGISTERS CONTAINED IN FLASH MEMORY: WRITABLE ABOUT
IXVV	10,000 TIMES MAXIMUM
RW**	Read-Write: REGISTERS THAT CAN BE WRITTEN ONLY AFTER WRITING THE
1700	COMMAND "ENABLE WRITE CUSTOM ENERGIES = 49616"
UNSIGNED 16 BIT	Unsigned integer register that can assume values from 0 to 65535
SIGNED 16 BIT	Signed integer register that can take values from -32768 to +32767
UNSIGNED 32 BIT	Unsigned integer register that can assume values from 0 to 4294967296
SIGNED 32 BIT	Signed integer register that can take values from -2147483648 to 2147483647
UNSIGNED 64 BIT	Unsigned integer register that can assume values from 0 to 18446744073709551615
SIGNED 64 BIT	Signed integer register that can assume values from -2^63 to 2^63-1
FLOAT 32 BIT	32-bit, single-precision floating-point register (IEEE 754)
I LOAT 32 DIT	https://en.wikipedia.org/wiki/IEEE_754
BIT	Boolean register, which can take the values 0 (false) or 1 (true)

14.1. NUMBERING OF "0-BASED" OR "1-BASED" MODBUS ADDRESSES

According to the Modbus standard the Holding Registers are addressable from 0 to 65535, there are 2 different conventions for numbering the addresses: "0-BASED" and "1-BASED".

For greater clarity, Seneca shows its register tables in both conventions.



ATTENTION!

CAREFULLY READ THE DOCUMENTATION OF THE MODBUS MASTER DEVICE IN ORDER TO UNDERSTAND WHICH OF THE TWO CONVENTIONS THE MANUFACTURER HAS DECIDED TO USE

SENECA USES THE "1 BASED" CONVENTION FOR ITS PRODUCTS

14.2. NUMBERING OF MODBUS ADDRESSES WITH "0-BASED" CONVENTION

The numbering is:

HOLDING REGISTER MODBUS ADDRESS (OFFSET)	MEANING
0	FIRST REGISTER
1	SECOND REGISTER
2	THIRD REGISTER
3	FOURTH REGISTER
4	FIFTH REGISTER

Therefore, the first register is at address 0.

In the following tables, this convention is indicated with "ADDRESS OFFSET".



14.3. NUMBERING OF MODBUS ADDRESSES WITH "1 BASED" CONVENTION (STANDARD)

The numbering is that established by the Modbus consortium and is of the type:

HOLDING REGISTER MODBUS ADDRESS 4x	MEANING
40001	FIRST REGISTER
40002	SECOND REGISTER
40003	THIRD REGISTER
40004	FOURTH REGISTER
40005	FIFTH REGISTER

This convention is indicated with "ADDRESS 4x" since a 40000 is added to the address so that the first Modbus register is 40001.

A further convention is also possible where the number 4 is omitted in front of the register address:

HOLDING MODBUS ADDRESS WITHOUT 4x	MEANING
1	FIRST REGISTER
2	SECOND REGISTER
3	THIRD REGISTER
4	FOURTH REGISTER
5	FIFTH REGISTER

14.4. BIT CONVENTION WITHIN A MODBUS HOLDING REGISTER

A Modbus Holding Register consists of 16 bits with the following convention:

| BIT |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |

For instance, if the value of the register in decimal is

12300

the value 12300 in hexadecimal is:

0x300C

the hexadecimal 0x300C in binary value is:

11 0000 0000 1100

So, using the above convention, we get:

| BIT |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |



14.5. MSB and LSB BYTE CONVENTION WITHIN A MODBUS HOLDING REGISTER

A Modbus Holding Register consists of 16 bits with the following convention:

BI	Γ	BIT														
15	5	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

LSB Byte (Least Significant Byte) defines the 8 bits ranging from Bit 0 to Bit 7 included, we define MSB Byte (Most Significant Byte) the 8 bits ranging from Bit 8 to Bit 15 inclusive:

BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	BYTE MSB										BYTE	LSB			

14.6. REPRESENTATION OF A 32-BIT VALUE IN TWO CONSECUTIVE MODBUS HOLDING REGISTERS

The representation of a 32-bit value in the Modbus Holding Registers is made using 2 consecutive Holding Registers (a Holding Register is a 16-bit register). To obtain the 32-bit value it is therefore necessary to read two consecutive registers:

For example, if register 40064 contains the 16 most significant bits (MSW) while register 40065 contains the least significant 16 bits (LSW), the 32-bit value is obtained by composing the 2 registers:

BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	40064 MOST SIGNIFICANT WORD														

BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	40065 LEAST SIGNIFICANT WORD														

$$Value_{32bit} = Register_{LSW} + (Register_{MSW} * 65536)$$

In the reading registers it is possible to swap the most significant word with the least significant word, therefore it is possible to obtain 40064 as LSW and 40065 as MSW.



15. MANAGING MSC-D FROM MODBUS REGISTERS



To control the calibrator from Modbus registers, the "Remote Control" parameter must be set to "ON" and the webserver must be disconnected and not interacting with the device.

15.1. **DESCRIPTION**

The MSC product has Modbus registers that allow you to control the device and read or generate electrical quantities.

The protocol supported by MSC is Modbus TCP-IP server.

The purpose of this chapter is to provide information for the complete control of MSC so that it can be integrated into third-party software.

For .NET developers, various libraries for the Modbus protocol are available.

An example, the Open Source Modbus library is available at this address:

https://github.com/NModbus/NModbus

15.2. USE OF MSC TO TAKE MEASUREMENTS

15.2.1. MEASUREMENT MIN/MAX/AVG VALUES

To reset the Min/Max/Avg values, write the value 5 on CMD register To pause the Min/Max/Avg values write the value 10 in the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40108	107	CMD	16 bit without a sign



15.2.2. DATALOGGER

It is possible to control the datalogger start/stop in this way:

COMMAND	AUX1 REGISTER WRITING VALUE	CMD REGISTER WRITING VALUE
DATALOGGER START	1	3
DATALOGGER STOP	0	3

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40108	107	CMD	16 bit without a sign
40109	108	AUX1	16 bit without a sign

REGISTER	REGISTER	VARIABLE	VARIABLE TYPE	Unit of Measure
ADDRESS	(OFFSET)			
40195-196	194-195	Dimensions of the datalogger file in bytes	32 bit without a sign	Byte



15.2.3. DIAGNOSTICS REGISTER FOR MEASUREMENTS

The reading diagnostics register is:

REGISTER	REGISTER	VARIABLE	VARIABLE TYPE	Unit of Measure
ADDRESS	(OFFSET)			
40103	102	Diagnostics	16 bit without a sign	-

The bit indicating a measurement error is

BIT	BIT	BIT 14	BIT												
16	15		13	12	11	10	9	8	7	6	5	4	3	2	1
-	-	ERROR	-	-	-	-	-	-	-	-	-	-	-	-	-
		MEASUREMENT													

Where if the MEASUREMENT ERROR bit:

is 1 -> Measurement error

is 0 -> Measurement OK

15.2.4. CURRENT/VOLTAGE MEASUREMENTS

The type of measurement is selected by writing the AUX1 register followed by the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40108	107	CMD	16 bit without a sign
40109	108	AUX1	16 bit without a sign

The values to write in the registers for the different types of measurement are:

TYPE OF MEASUREMENT	AUX1 REGISTER WRITING VALUE	CMD REGISTER WRITING VALUE
CURRENT PASSIVE MEASUREMENT 020 mA	1	1
CURRENT ACTIVE MEASUREMENT 020 mA	2	1
VOLTAGE 027 V	3	1
VOLTAGE -1090 mV	4	1



Reading registers:

REGISTER ADDRESS	REGISTER (OFFSET)	VARIABLE	VARIABLE TYPE	Unit of Measure
40137-40138	136-137	Measurement value	Floating Point	mA / V / mV
40133-40134	132-133	Minimum value	Floating Point	mA / V / mV
40135-40136	134-135	Maximum value	Floating Point	mA / V / mV
40171-40172	170-171	Medium value	Floating Point	mA / V / mV

15.2.5. THERMOCOUPLE MEASUREMENTS

The type of thermocouple is selected by writing the AUX1 register followed by the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40108	107	CMD	16 bit without a sign
40109	108	AUX1	16 bit without a sign

The values to write in the registers to select the type of thermocouple are:

THERMOCOUPLE TYPE	AUX1 REGISTER WRITING VALUE	CMD REGISTER WRITING VALUE
J	5	1
K	6	1
Т	7	1
E	8	1
L	9	1
N	10	1
R	11	1
S	12	1
В	13	1







Reading registers:

REGISTER	REGISTER	VARIABLE	VARIABLE TYPE	Unit of Measure
ADDRESS	(OFFSET)			
40137-40138	136-137	Temperature	Floating Point	°C
40117-40118	116-117	Cold junction voltage	Floating Point	mV
40127-40128	126-127	Cold junction	Floating Point	°C
		temperature		
40133-40134	132-133	Minimum	Floating Point	°C
		temperature		
40135-40136	134-135	Maximum	Floating Point	°C
		temperature		
40171-40172	170-171	Average temperature	Floating Point	°C



15.2.6. **RESISTOR E TEMPERATURE METER**


The type of resistance thermometer is selected by writing the AUX1 register followed by the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40108	107	CMD	16 bit without a sign
40109	108	AUX1	16 bit without a sign

The values to write in the registers to select the type of resistance thermometer are:

RESISTANCE TEMPERATURE	AUX1 REGISTER WRITING VALUE	CMD REGISTER WRITING VALUE
METER		
PT100 2 WIRES	14	1
PT100 3 WIRES	15	1
PT100 4 WIRES	16	1
PT500 2 WIRES	17	1
PT500 3 WIRES	18	1
PT500 4 WIRES	19	1
PT1000 2 WIRES	20	1
PT1000 4 WIRES	22	1
PT1000 4 WIRES	22	1
PT1000 4 WIRES	22	1
CU50 2 WIRES	23	1
CU50 3 WIRES	24	1
CU50 4 WIRES	25	1
CU100 2 WIRES	26	1
CU100 3 WIRES	27	1
CU100 4 WIRES	28	1
NI100 2 WIRES	29	1
NI100 3 WIRES	30	1
NI100 4 WIRES	31	1
NI120 2 WIRES	32	1
NI120 3 WIRES	33	1
NI120 4 WIRES	34	1





Reading registers:

REGISTER ADDRESS	REGISTER (OFFSET)	VARIABLE	VARIABLE TYPE	Unit of Measure
40137-40138	136-137	Temperature	Floating Point	°C
40131-40132	130-131	Resistance	Floating Point	Ohm
40133-40134	132-133	Minimum	Floating Point	°C
		temperature		
40135-40136	134-135	Maximum	Floating Point	°C
		temperature		
40171-40172	170-171	Average temperature	Floating Point	°C

15.2.7. LOAD CELL MEASUREMENT

The type of load cell measurement is selected by writing the AUX1 register followed by the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40108	107	CMD	16 bit without a sign
40109	108	AUX1	16 bit without a sign

The values to write in the registers to select the type of load cell measurement are:

TYPE OF	AUX1 REGISTER	CMD REGISTER
MEASUREMENT	WRITING VALUE	WRITING VALUE
LOAD CELL MEASUREMENT	35	1

The measurement is expressed in mV/V and is only gross (tare + net weight):

Reading registers:

REGISTER ADDRESS	REGISTER (OFFSET)	VARIABLE	VARIABLE TYPE	Unit of Measure
40137-40138	136-137	Cell unbalance measurement	Floating Point	mV/V

If the cell is completely unbalanced the measurement is 2 mV/V so the gross weight coincides with the full scale of the cell.

The gross weight can then be calculated according to the formula:

Gross Weight [Kg] = (Cell Full Scale [Kg] * Cell Unbalance Measurement [mV/V]) / 2

For example, if the load cell has a full scale of 100 kg and the unbalance measurement is 1 mV/V you will have:

Gross Weight [Kg] = (100 Kg * 1 mV/V) / 2 = 50 Kg



15.2.8. FREQUENCY MEASUREMENT

The type of frequency measurement is selected by writing the AUX1 register followed by the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40108	107	CMD	16 bit without a sign
40109	108	AUX1	16 bit without a sign

The values to write in the registers to select the type of load cell measurement are:

TYPE OF	AUX1 REGISTER	CMD REGISTER
MEASUREMENT	WRITING VALUE	WRITING VALUE
LOAD CELL MEASUREMENT	36	1

Reading registers:

REGISTER ADDRESS	REGISTER (OFFSET)	VARIABLE	VARIABLE TYPE	Unit of Measure
40165-166	164-165	Frequency	Floating Point	Hz



15.2.9. PULSE NUMBER MEASUREMENT

The type of pulse measurement is selected by writing the AUX1 register followed by the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40108	107	CMD	16 bit without a sign
40109	108	AUX1	16 bit without a sign

The values to write in the registers to select the type of pulse measurement are:

TYPE OF MEASUREMENT	AUX1 REGISTER WRITING VALUE	CMD REGISTER WRITING VALUE
LOAD CELL MEASUREMENT	37	1

Reading registers:

REGISTER ADDRESS	REGISTER (OFFSET)	VARIABLE	VARIABLE TYPE	Unit of Measure
40153-154	152-153	Pulse number with Positive Fronts	32 bit without a sign	Pulse No.
40151-152	150-151	Pulse number with Negative Fronts	32 bit without a sign	Pulse No.

To reset the pulse value counted, write the value 5 in the CMD register To pause the count of the pulses, write the value 10 in the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40108	107	CMD	16 bit without a sign



15.3. USE OF MSC TO GENERATE SIGNALS

15.3.1. DIAGNOSTICS REGISTER FOR GENERATIONS

The generation diagnostics register is:

REGISTER ADDRESS	REGISTER (OFFSET)	VARIABLE	VARIABLE TYPE	Unit of Measure
40103	102	Diagnostics	16 bit without a sign	-

The bit indicating a measurement error is

BIT 16	BIT 15	BIT													
		14	13	12	11	10	9	8	7	6	5	4	3	2	1
GENERATION	SELF-READING	-	-	-	-	-	-	-	-	-	1	-	-	-	-
ERROR	ERROR														

Where if:

The SELF-READING ERROR bit:

is 1 -> Self-reading error of the current generation

is 0 -> Generation OK

The GENERATION ERROR bit:

is 1 -> Generation error

is 0 -> Generation OK

15.3.2. CURRENT AND VOLTAGE GENERATION

The type of generation is selected by writing the AUX1 register followed by the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40208	207	CMD	16 bit without a sign
40209	208	AUX1	16 bit without a sign

The values to write in the registers for the different types of measurement are:

GENERATION TYPE	AUX1 REGISTER WRITING VALUE	CMD REGISTER WRITING VALUE
PASSIVE CURRENT 020 mA	101	1
ACTIVE CURRENT 020 mA	102	1
VOLTAGE 027 V	103	1
VOLTAGE -1090 mV	104	1

Writing registers (the written value is generated to the terminals) for the currents:

REGISTER ADDRESS	REGISTER (OFFSET)	VARIABLE	VARIABLE TYPE	Unit of Measure
40137-40138	136-137	Current value to be generated	Floating Point	mA

Writing registers (the written value is generated to the terminals) for the voltages:

REGISTER ADDRESS	REGISTER (OFFSET)	VARIABLE	VARIABLE TYPE	Unit of Measure
40213-40214	212-2016	Voltage value to be generated	Floating Point	V / mV



15.3.3. THERMOCOUPLE SIGNAL GENERATION

Configuration of the cold junction:

COLD JUNCTION	AUX1 REGISTER WRITING VALUE	AUX2 REGISTER WRITING VALUE	CMD REGISTER WRITING VALUE
INSIDE MSC	2	1	2
OUTSIDE MSC	1	1	2

Where:

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40209	208	AUX1	16 bit without a sign
40210	209	AUX2	16 bit without a sign
40208	207	CMD	16 bit without a sign

In case of manual cold junction compensation, it is possible to enter the compensation value in mV in the register:

REGISTER ADDRESS	REGISTER (OFFSET)	VARIABLE	VARIABLE TYPE	Unit of Measure
40241-40242	240-241	Manual cold junction value	Floating Point	mV

The type of thermocouple is selected by writing the AUX1 register followed by the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40208	207	CMD	16 bit without a sign
40209	208	AUX1	16 bit without a sign





The values to write in the registers to select the type of thermocouple are:

THERMOCOUPLE TYPE	AUX1 REGISTER WRITING VALUE	CMD REGISTER WRITING VALUE
J	105	1
K	106	1
Т	107	1
E	108	1
L	109	1
N	110	1
R	111	1
S	112	1
В	113	1

Writing Registers of the value to be generated:

REGISTER ADDRESS	REGISTER (OFFSET)	VARIABLE	VARIABLE TYPE	Unit of Measure
40221-40222	220-221	Temperature to be generated	Floating Point	°C



15.3.4. RESISTANCE THERMOMETER SIGNAL GENERATION

The type of resistance thermometer is selected by writing the AUX1 register followed by the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40208	207	CMD	16 bit without a sign
40209	208	AUX1	16 bit without a sign

The values to write in the registers to select the type of resistance thermometer are:

RESISTANCE TEMPERATURE METER	AUX1 REGISTER WRITING VALUE	CMD REGISTER WRITING VALUE
PT100 2 WIRES	114	1
PT500 2 WIRES	117	1
PT1000 2 WIRES	120	1
CU50 2 WIRES	123	1
CU100 2 WIRES	126	1
NI100 2 WIRES	129	1
NI120 2 WIRES	132	1

Writing Registers of the value to be generated:

REGISTER	REGISTER	VARIABLE	VARIABLE TYPE	Unit of Measure
ADDRESS	(OFFSET)			
40229-40230	228-229	Temperature	Floating Point	°C

15.3.5. LOAD CELL GENERATION

The type of load cell generation is selected by writing the AUX1 register followed by the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40208	207	CMD	16 bit without a sign
40209	208	AUX1	16 bit without a sign

GENERATION TYPE	AUX1 REGISTER WRITING VALUE	CMD REGISTER WRITING VALUE
LOAD CELL	135	1

The unbalance of the cell must be entered in the register:

REGISTER	REGISTER	VARIABLE	VARIABLE TYPE	Unit of Measure
ADDRESS	(OFFSET)			
40215-40216	214-215	Cell unbalance	Floating Point	mV/V

To generate a value in Kg (gross), use the following relation:

Cell unbalance [mV/V] = (gross Kg to be generated * 2) / Cell Full Scale [Kg]

For example, if you want to simulate a load cell with 100 kg full scale and want to generate 25 gross kg, you will have:

Cell unbalance [mV/V] = (25 Kg * 2) / 100 Kg = 0.5 mV/V



15.3.6. FREQUENCY GENERATION

The type of frequency generation is selected by writing the AUX1 register followed by the CMD register

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40208	207	CMD	16 bit without a sign
40209	208	AUX1	16 bit without a sign

GENERATION TYPE	AUX1 REGISTER	CMD REGISTER
	WRITING VALUE	WRITING VALUE
FREQUENCY	136	1

The frequency value to generate is obtained by writing four registers:

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40255-40256	254-255	TICK1	32 bit without a sign
40257-40258	256-257	TICK2	32 bit without a sign
40263-40264	262-263	% HIGH VOLTAGE	Floating Point 32 bit
40265-40266	264-265	% LOW VOLTAGE	Floating Point 32 bit

Where:

TEMP = Math.Round((20000/ Frequency to generate [Hz]),0)

TICK1 = Math.Floor(TEMP/2)

TICK2 = TEMP-TICK1

% HIGH VOLTAGE is the voltage percentage value of when the signal must be low (0.0 = 0%, 1.0 = 100%) referred to 27V (100%)

% LOW VOLTAGE is the voltage percentage value of when the signal must be low (0.0 = 0%, 1.0 = 100%) referred to 27V (100%)

COMMAND	AUX1 REGISTER	CMD REGISTER
	WRITING VALUE	WRITING VALUE
GENERATION START	1	9

Example:

If you want to generate a 100 Hz frequency with 0-5V band:

TEMP = Math.Round((20000/ 100 [Hz]),0) = 200

TICK1 = Math.Floor(200/2) = 100

TICK2 = 200-100=100

% HIGH VOLTAGE = 0

% LOW VOLTAGE = 0,185



15.3.7. NUMBER OF PULSES GENERATION

The type of pulse generation is selected by writing the AUX1 register followed by the CMD register

	REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
	40208	207	CMD	16 bit without a sign
Ī	40209	208	AUX1	16 bit without a sign

GENERATION TYPE	AUX1 REGISTER	CMD REGISTER
	WRITING VALUE	WRITING VALUE
FREQUENCY	137	1

The number of pulses to generate is obtained by writing 5 registers:

REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40253-40254	252-253	PULSE No. (x2)	32 bit without a sign
40255-40256	254-255	TICK1	32 bit without a sign
40257-40258	256-257	TICK2	32 bit without a sign
40263-40264	262-263	% HIGH VOLTAGE	Floating Point 32 bit
40265-40266	264-265	% LOW VOLTAGE	Floating Point 32 bit

Where:

No. OF PULSES (x2) = Number of pulses to generate multiplied by 2

TICK1 = Duration of the High pulse in how many 50 ms

TICK2 = Duration of the Low pulse in how many 50 ms

% HIGH VOLTAGE is the voltage percentage value of when the signal must be low (0.0 = 0%, 1.0 = 100%) referred to 27V (100%)

% LOW VOLTAGE is the voltage percentage value of when the signal must be low (0.0 = 0%, 1.0 = 100%) referred to 27V (100%)

COMMAND	AUX1 REGISTER WRITING VALUE	CMD REGISTER WRITING VALUE
GENERATION START	2	9
WITH LOW START		
GENERATION START	3	9
WITH HIGH START		
PAUSE / START	4	9

The number of pulses still to generate is represented in the reading register:





REGISTER ADDRESS	REGISTER (OFFSET)	REGISTER NAME	REGISTER TYPE
40251-40252	250-251	REMAINING PULSES / 2	32 bit without a sign

This value must be divided by 2 to obtain the number of remaining registers.

Example:

If you want to generate 500 pulses lasting 500ms High and 500ms Low with 0-10V band:

No. OF PULSES (x2) = 1000

TICK1 = 10

TICK2 = 10

% HIGH VOLTAGE = 0.37

% LOW VOLTAGE = 0.0