

USER MANUAL

T122

TEMPERATURE TRANSMITTER
WITH HART 7 PROTOCOL



SENECA S.r.l.

Via Austria 26 – 35127 – Z.I. - PADOVA (PD) - ITALY
Tel. +39.049.8705355 – 8705355 Fax +39 049.8706287

www.seneca.it

ORIGINAL INSTRUCTIONS

CAUTION

SENECA does not guarantee that all specifications and/or aspects of the product and firmware, included in them, will meet the requirements of the actual final application even if the product referred to in this documentation is in compliance with the technological state of the art.

The user assumes full responsibility and/or risk with regard to the configuration of the product to achieve the intended results in relation to the specific installation and/or end application.

SENECA may, with prior agreement, provide consultancy services for the successful completion of the final application, but under no circumstances can it be held responsible for its proper functioning.

The SENECA product is an advanced product, the operation of which is specified in the technical documentation supplied with the product itself and/or can be downloaded, if desired prior to purchase, from the www.seneca.it website.

SENECA has a policy of continuous development and accordingly reserves the right to make and/or introduce - without prior notice - changes and/or improvements to any product described in this documentation.

The product described in this documentation may solely and exclusively be used by personnel qualified for the specific activity and in accordance with the relevant technical documentation, with particular attention being paid to the safety instructions.

Qualified personnel means personnel who, on the basis of their training, competence and experience, are able to identify risks and avoid potential hazards that could occur during the use of this product.

SENECA products may only be used for the applications and in the manner described in the technical documentation relating to the products themselves.

To ensure proper operation and prevent the occurrence of malfunctions, the transport, storage, installation, assembly, maintenance of SENECA products must comply with the safety instructions and environmental conditions specified in this documentation.

SENECA's liability in relation to its products is governed by the general conditions of sale, which can be downloaded from www.seneca.it.

Neither SENECA nor its employees, within the limits of applicable law, will in any case be liable for any lost profits and/or sales, loss of data and/or information, higher costs incurred for goods and/or replacement services, damage to property and/or persons, interruption of activities and/or provision of services, any direct, indirect, incidental, pecuniary and non-pecuniary, consequential damages in any way caused and/or caused, due to negligence, carelessness, incompetence and/or other liabilities arising from the installation, use and/or inability to use the product.

CONTACT US

Technical support	supporto@seneca.it
Product information	commerciale@seneca.it

This document is the property of SENECA srl.
Duplication and reproduction are prohibited unless authorised.

TABLE OF CONTENTS

1. INTRODUCTION	5
2. PRODUCT DESCRIPTION	5
2.1. Main features	6
3. SENSOR TYPES AND ACCURACY	7
4. MOUNTING AND INSTALLATION	7
5. FIRMWARE UPDATE	8
6. THE CONFIGURATION SOFTWARE “EASY T122”	9
6.1. CONNECTING T122 TO PC	9
6.2. THE MENU	11
6.3. TAB “INFO”	12
6.4. TAB “INPUT”	12
6.5. TAB “OUTPUT/MISC”	14
6.6. TAB “HART”	15
6.7. TAB “Test”	17
6.8. GRAPHICAL EXPLANATION OF THE MAIN CONFIGURATION PARAMETERS	18

1. INTRODUCTION

The T122 is a 2-wire temperature transmitter. The device converts the signal from the sensor into a 4...20 mA current output, while maintaining the possibility of configuration, diagnostics and advanced reading via the HART 7 protocol.

The design is oriented towards industrial applications requiring high reliability, measurement accuracy, remote configuration and integration with DCS/PLC systems or asset management software.

 **WARNING!**

This user manual extends the information from the installation manual on device configuration. Please refer to the installation manual for further information.

 **WARNING!**

In any case, SENECA s.r.l. or its suppliers shall not be liable for loss of data / revenue or for consequential or incidental damages due to negligence or misuse/improper handling of the device, even if SENECA is well aware of these possible damages.

SENECA, its subsidiaries, affiliates, group companies, suppliers and resellers do not guarantee that the functions will fully meet customer expectations or that the device, firmware and software will be error-free or operate continuously.

2. PRODUCT DESCRIPTION

The T122 supports universal inputs for temperature and resistance sensors.

2.1. Main features

Item	Description
Type	2-wire temperature transmitter with HART 7 protocol
Mounting	DIN B head
Supported inputs	RTD, thermocouples, linear resistance, mV
Output	4...20 mA con comunicazione HART™ 7
Configuration	PC software, HART modem/interface, HART communicator, DCS/asset management
Write protection	Via software

WARNING!

- *Verify the compatibility of the sensor with the configured input type.*
- *Use cables and accessories suitable for the installation environment.*
- *In classified areas, comply exclusively with the approvals and installation drawings valid for the purchased version.*
- *Enable write protection once commissioning is complete, where required by company procedure.*

3. SENSOR TYPES AND ACCURACY

FUNCTIONS	UoM	RANGE (Measure)	PRECISION (Measure)	RISOLUTION (Measure)	STANDARD	NOTES	CMRR- NMRR
VOLTAGE	[dc mV]	-10 ÷ 90	0.02% + 10 µV	5 µV	-		>100 dB
Pt100	[°C]	-200 ÷ +850	0.03% + 0.2°C	0.03 °C	IEC 60751		>140 dB
Pt500	[°C]	-200 ÷ +850	0.03% + 0.2°C	0.1 °C	IEC 60751		>140 dB
Pt1000	[°C]	-200 ÷ +850	0.03% + 0.2°C	0.03 °C	IEC 60751		>140 dB
Pt2000	[°C]	-200 ÷ +650	0.03% + 0.2°C	0.02°C	IEC 60751		>140 dB
Cu50, Cu100	[°C]	-180 ÷ +200	0.03% + 0.2°C	0.06 °C, 0.03 °C	GOST 8651- 2009	α = 0,00428	>140 dB
Ni100, Ni120	[°C]	-60 ÷ +250	0.03% + 0.2°C	0.02 °C	DIN 43760	α = 0,006178	>100 dB
Ni1000	[°C]	-60 ÷ +250	0.03% + 0.2°C	0.02°C	DIN 43760		
TERMOCOUPLE J	[°C]	-210 ÷ +1200	0.03% + 0.2°C	0.01 °C	EN 60584- 1:1997	Cold Junction Error: 1°C between 10 and 35°C ambient, 2°C between -20 and 10°C and between 35 and 50°C ambient	>100 dB
TERMOCOUPLE K	[°C]	-200 ÷ +1372	0.03% + 0.2°C	0.05 °C	EN 60584- 1:1997	Cold Junction Error: 1°C between 10 and 35°C ambient, 2°C between -20 and 10°C and between 35 and 50°C ambient	>100 dB
TERMOCOUPLE T	[°C]	-200 ÷ +400	0.03% + 0.2°C	0.05 °C	EN 60584- 1:1997	Cold Junction Error: 1°C between 10 and 35°C ambient, 2°C between -20 and 10°C and between 35 and 50°C ambient	>100 dB
TERMOCOUPLE E	[°C]	-200 ÷ +1000	0.03% + 0.2°C	0.05 °C	EN 60584- 1:1997	Cold Junction Error: 1°C between 10 and 35°C ambient, 2°C between -20 and 10°C and between 35 and 50°C ambient	>100 dB
TERMOCOUPLE N	[°C]	-200 ÷ +1300	0.03% + 0.2°C	0.05 °C	EN 60584- 1:1997	Cold Junction Error: 1°C between 10 and 35°C ambient, 2°C between -20 and 10°C and between 35 and 50°C ambient	>100 dB
TERMOCOUPLE R	[°C]	-50 ÷ +1768	0.03% + 0.3°C	0.05 °C	EN 60584- 1:1997	Cold Junction Error: 1°C between 10 and 35°C ambient, 2°C between -20 and 10°C and between 35 and 50°C ambient	>100 dB
TERMOCOUPLE S	[°C]	-50 ÷ +1768	0.03% + 0.3°C	0.05 °C	EN 60584- 1:1997	Cold Junction Error: 1°C between 10 and 35°C ambient, 2°C between -20 and 10°C and between 35 and 50°C ambient	>100 dB
TERMOCOUPLE B	[°C]	250 ÷ +1820	0.03% + 0.3°C	0.05 °C	EN 60584- 1:1997	Cold Junction Error: 1°C between 10 and 35°C ambient, 2°C between -20 and 10°C and between 35 and 50°C ambient	>100 dB
TERMOCOUPLE L	[°C]	-200 ÷ +800	0.03% + 0.15°C	0.05 °C	GOST 8.585- 2001	Cold Junction Error: 1°C between 10 and 35°C ambient, 2°C between -20 and 10°C and between 35 and 50°C ambient	>140 dB

4. MOUNTING AND INSTALLATION

The T122 HART 7 is designed for DIN B head mounting. Install the device inside an enclosure appropriate for the degree of protection required by the application. Ensure that the terminals are accessible for wiring, testing and maintenance.


5. FIRMWARE UPDATE


In order to include new features, the system provides the possibility of updating the device firmware. To perform the firmware update, follow the procedure below:

- 1) Power off the T122, disconnect the USB cable
- 2) Using a screwdriver, remove the cover as shown in the image:



- 3) Hold down the button as shown in the figure



- 4) Insert the USB cable into the PC (power is supplied by this cable)
- 5) Release the button
- 6) In the Easy T122 software press the button 
- 7) Follow the on-screen instructions

! WARNING!

BEFORE PERFORMING THE firmware UPDATE, make a note of the current configuration. Once the firmware has been updated, the previous configuration may be changed and it is therefore MANDATORY to reconfigure the device.


6. THE CONFIGURATION SOFTWARE “EASY T122”

The “Easy T122” software allows complete configuration of the device; the software can be freely downloaded from the website:

www.seneca.it


6.1. CONNECTING T122 TO PC

To connect the T122 to the PC, follow the wiring diagram below (also shown in the installation manual):



The resistor R must always be present (if absent in the master, it must be added).
The maximum value of R depends on the supply voltage according to the following formula:

$$R_{max}[Ohm] = (Valim - 9) / 0.023$$



Therefore, for example, if $Valim = 22.8 \text{ Vdc}$, R must be between 250 Ohm and 600 Ohm.
The maximum $Valim$ is 30 Vdc.




WARNING!

The permitted range of $Valim$ is from 9 Vdc to 30 Vdc

In the software, select the ComPort corresponding to the HART modem; at this point the PC and T122 are connected.

6.2. THE MENU



File

Allows opening or saving a configuration.

Language

Allows selection of the software interface language

ComPort

Allows selection of the serial/USB port of the HART modem

?

Allows viewing the software credits

“OPEN” BUTTON

Allows opening a previously saved configuration file

“SAVE” BUTTON

Allows saving a configuration file

“READ FROM” BUTTON


Allows reading the configuration from the T122

“SEND TO” BUTTON

Allows sending the current configuration to the T122

“UPDATE FW” BUTTON

Allows updating the firmware of the T122 (see the relevant chapter in this manual for further information)



“PASSWORD” BUTTON

Allows setting a password to lock the writing of parameters.

To unlock a password-protected device, it is possible to enter the previously set write password, or reset the device to factory defaults.

6.3. TAB “INFO”

This section displays information about the connected device.

6.4. TAB “INPUT”

This section allows configuration of the type of sensor connected to the head, the measurement range of the primary variable and any compensations applied to the input signal.

Sensor Type

Defines the type of input used by the head.

Number of wires

Defines the type of electrical connection of the sensor.

This parameter is particularly important for RTD sensors, because the number of wires affects the cable resistance compensation.

Unit of measurement

Indicates the engineering unit associated with the input measurement.

This unit is used to display the measured value and to define the LRV/URV measurement range.

Error Detection

Allows configuration of the head behaviour in the event of an error on the sensor or the input signal.

No detection means that no specific error detection on the input is enabled.

Sensor Failure, on the other hand, enables detection of sensor breakage, out-of-range detection, short circuit etc...

CJ (Cold Junction Compensation)**Internal**

For thermocouple inputs, CJ compensation is normally required because the thermocouple measurement depends on the temperature of the connection point to the head.

You can choose from:

None: no compensation

Enabled: compensation via sensor internal to the head

CJ (Cold Junction Compensation)***Offset [°]***

Allows a correction to be applied to the cold junction compensation.

This parameter can be used to compensate for small deviations due to installation, wiring or calibration.

Compensation Offset Manual***2 Wire [Ω] - RTD***

Parameter used to compensate for the cable resistance in the case of RTD sensors connected with 2 wires.

With a 2-wire RTD, the cable resistance adds to the sensor resistance and can generate a measurement error.

By entering a value in this field, the device can compensate for this error.

Compensation Offset Manual***Measurement [Ω, %, ...]***

Allows an offset to be applied to the main measurement. The unit of measurement depends on the type of sensor configured. This parameter is used to correct small systematic errors in the measurement chain.

Variable Mapping***PV Mapped to Input 1***

The Primary Value represents the main quantity transmitted by the device and is statically associated with the value measured by the sensor. This parameter cannot be modified.

Variable Mapping***SV Mapped to CJ Value/Electronic Temperature***

The Secondary Variable is statically associated with the value measured by the cold junction or internal electronics temperature. This parameter cannot be modified.

PV Parameters***Filter Time [s]***

Defines the filter time applied to the primary variable.

A low or zero value makes the measurement faster but potentially more sensitive to noise.

A higher value makes the measurement more stable but slower to follow rapid signal variations.

0 s: no filtering.

PV Parameters***High Range - URV***

Defines the upper value of the measurement range of the primary variable.

This value represents the high end of the transmitted range. It is normally associated with the maximum analogue output value, i.e. 20 mA.

PV Parameters**Low Range - LRV**

Defines the lower value of the measurement range of the primary variable.

This value represents the low end of the transmitted range. It is normally associated with the minimum analogue output value, i.e. 4 mA.

Sensor Serial Number

Field used to associate a serial number with the connected sensor.

This parameter can be useful for traceability, maintenance, calibration and identification of the installed sensor.

Read Values**PV (Selected Sensor)**

Displays the instantaneous value of the primary variable.

Read Values**Internal Temp. (CJ)**

Displays the internal temperature of the head or the value used for cold junction compensation.

6.5. TAB "OUTPUT/MISC"

This section shows the various configurations and those relating to the analogue output.

This section defines how the PV measurement range is converted to output current.

PV Current Mapping**OUTPUT (HIGH)****URV mapped to... [mA]**

Defines the current value associated with the upper limit of the measurement range.

This means that when the PV reaches the URV value, the analogue output will equal the output value in mA set here.

PV Current Mapping**LOW OUTPUT****LRV mapped to... [mA]**

Defines the current value associated with the lower limit of the measurement range.

This means that when the PV reaches the LRV value, the analogue output will equal the output value in mA set here.

CURRENT output clipping**High Level [mA]**

Defines the maximum current value that the output can reach during normal operation, regardless of the input value.

CURRENT output clipping***Low Level [mA]***

Defines the minimum current value that the output can reach during normal operation, regardless of the input value.

Device Variable Limits***DV0 High Level***

Defines the high limit of Device Variable 0.

Below this value the input enters an error state and, depending on the configuration, may drive the output to the value of the parameter “Error Value [mA]”

Device Variable Limits***DV0 Low Level***

Defines the low limit of Device Variable 0.

Above this value the input enters an error state and, depending on the configuration, may drive the output to the value of the parameter “Error Value [mA]”

Output Current Level on Error***Error Value [mA]***

Defines the current value that the output must assume in the event of an error.

This value is typically used to indicate a fault condition, for example a failed sensor, below the normal 4–20 mA limit.

Current loop reading

When the “Read Loop mA Value” button is pressed, it shows the current value in [mA] and [%] of the loop current.

6.6. TAB “HART”

This section allows configuration of the communication and identification parameters of the HART device.

HART Device Properties***RSP Preambles***

Defines the number of preambles used in the HART response.

The preamble is an initial sequence used in HART communication to synchronise the receiver. A higher number of preambles can increase compatibility with some masters or modems, but slightly increases communication time.

Polling Address

Defines the HART address of the device.

Address 0 is normally used for point-to-point operation with active 4–20 mA analogue output.

Values other than 0 are typically used in multidrop mode. In multidrop, multiple devices can share the same HART communication loop and the analogue current is fixed at a constant value.

Loop Mode

Defines the operating mode of the current loop:

Analog and Digital: Means that the device uses both the 4–20 mA analogue output and the digital HART communication. This is the typical mode for a HART transmitter in point-to-point connection.

Digital: Means that the device forces the analogue output to a constant value and uses the loop for digital HART communication only. This is the typical mode for multidrop mode.

HART Description / Message**Tag**

Short device identification field.

HART Description / Message**Description**

Descriptive field associated with the device.

HART Description / Message**Long Tag**

Extended device identification field.

The Long Tag allows a longer description to be used compared to the traditional Tag and is useful in modern plants with more descriptive naming.

HART Description / Message**Assembly NR**

Numeric field associated with the assembly or configuration of the device.

Can be used for internal identification, traceability or configuration management.

HART Description / Message**Date**

Date field, provides the date currently configured in the device

HART Description / Message**Message**

HART message field associated with the device. This field can contain free text readable by the HART master, useful for maintenance notes, identification or additional information.

HW/SW Info**Hardware Version**

Shows the hardware version of the device.

HW/SW Info

Software Version

Shows the firmware version of the device.

6.7. TAB “Test”

This section allows verification of the device operation, reading of the primary variable, reading of the loop current or manual forcing of the output current.

Functional Mode

Fixed Loop Current [mA]

Allows manual setting of a fixed output current.

This function is used to test the current loop, the wiring, PLC/DCS inputs or the supervision system.

When this mode is active, the output current does not follow the sensor measurement, but is forced to the set value.

Read PV

Mode that allows reading the primary variable of the device.

When selected, the software reads and displays the PV trend over time.

Read Loop Current

Mode that allows reading the actual loop current.

It is useful to verify that the current generated by the device corresponds to the measurement or forced value.

Normal Mode

Returns the device to normal operation.

In this mode, the analogue output follows the sensor measurement according to the configured LRV/URV and 4–20 mA mapping.

With default values the configuration is:

Parameter	Value
LRV	-150 mV
URV	+150 mV
Corrente a LRV	4 mA
Corrente a URV	20 mA

Therefore:

-150 mV corresponds to 4 mA;

0 mV corresponds to approximately 12 mA;

+150 mV corresponds to 20 mA.

The current is calculated linearly within the configured range.

General formula:

$$I_{out} = 4 \text{ mA} + ((PV - LRV) / (URV - LRV)) \times 16 \text{ mA}$$

In the specific case:


$$I_{out} = 4 \text{ mA} + ((PV - (-150)) / (150 - (-150))) \times 16 \text{ mA}$$

Examples:

PV	Output current
-150 mV	4 mA
-75 mV	8 mA
0 mV	12 mA
+75 mV	16 mA
+150 mV	20 mA

6.8. GRAPHICAL EXPLANATION OF THE MAIN CONFIGURATION PARAMETERS

LRV and URV contribute to the definition of the output line (shown in green in the graph); the output cannot exceed the clipping limits (Output Limit High and Output Limit Low):



In the graph below, when the DVO Low and DVO High limit values are reached, the output value goes to the fail value (Error Output Value):

